# NACHi Standard Hydraulic Equipment

# Using the NACHI Standard Hydraulic Equipment Catalog


As a comprehensive manufacturer of a full range of hydraulic equipment, Nachi-Fujikoshi manufactures, markets, and provides a wide range of other services for a full lineup of outstanding products.

This general catalog introduces standard hydraulic equipment that has been carefully selected from the wide range of products manufactured by Nachi-Fujikoshi. We hope that this catalog will be of assistance in planning your hydraulic system and for providing some guidelines for your inquiries about Nachi-Fujikoshi products.

#### ■ Interpreting Model Numbers

Model numbers are assigned in accordance with Nachi-Fujikoshi standards as described below.

# Example: PVS Series Variable Volume Piston Pump



A change in the right digit of the design number indicates there is no component compatibility. However, installation method compatibility still exists. This is subject to change without notice.

#### ■ Using the Model Number Index

The Model Number Index at the back of this catalog lists the model numbers for NACHI standard hydraulic equipment. Use the index when looking up equipment details.

# **Hydraulic Equipment and Device Safety Precautions**

- Before using any Nachi-Fujikoshi hydraulic equipment or device, carefully read the precautions and the "Handling" section for each of the standard hydraulic equipment products.
- Precautions are classified according to the three types described below. All three indicate important information that you need to know to ensure safety. Be sure to read all precautions and carefully follow the advice that they provide.

<u></u>	Danger	This type of precaution indicates a condition in which incorrect handling creates the immediate risk of death or serious personal injury.
<u></u>	\ Warning	This type of precaution indicates a condition in which incorrect handling creates the risk of death or serious personal injury.
Ţ,	Caution	This type of precaution indicates a condition in which incorrect handling creates the risk of personal injury or material damage.

<sup>\*</sup>Danger, Warning, and Caution precautions are not comprehensive. Other risks may exist, even though they are not specifically mentioned. Before actually using any Nachi-Fujikoshi product, be sure to read its user documentation. You should use the product or device only after you thoroughly understand its user documentation, always keeping safety first and foremost in your mind.

\*Be sure that you always comply with the following laws in order to ensure safe operation of a product.

- · High Pressure Gas Safety Law
- Occupational Safety and Health Law
- Fire Codes
- Hydraulic Operating Fluid Precautions
  - Use of improper hydraulic operating fluid creates the risk of malfunction and breakdown.

<u>Danger</u>	Many hydraulic operating fluids are flammable, so do not use open flame and do not perform welding in the vicinity of hydraulic devices and equipment. Failure to follow this precaution creates the risk of fire.
<b>Caution</b>	Use only anti-wear type hydraulic operating fluid that is ISO3448 viscosity grade VG32 to VG68. Never use any other type of hydraulic operating fluid or fluid that is contaminated with foreign matter. Always check your user documentation for information before using non-mineral type hydraulic operating fluid (water based, synthetic, etc.)
<b>Caution</b>	Use the proper type of hydraulic operating fluid, ensuring that fluid temperature, viscosity, contaminant level, and other factors are all within their prescribed ranges. Using hydraulic operating fluid outside of its prescribed ranges creates the risk of fire due to operational problems, mechanical damage, and fluid leaks.
Caution	Configure circuits and operate the system to ensure that the contamination level of the hydraulic operating fluid being used is always within the manufacturer's recommended values. Check the contamination level and the condition of the filter at regular intervals. Also periodically check hydraulic operating fluid for oxidation, deterioration, and moisture, and replace the hydraulic operating fluid whenever these levels exceed the recommended values of the fluid manufacturer.
<b>?</b> Caution	Whenever changing to another type of hydraulic operating fluid, be sure to thoroughly flush out the interior of the circuit. Never mix hydraulic operating fluids of different types. Continued use creates the risk of malfunction of and damage to the equipment.
<b>Caution</b>	Make sure to avoid splashing hydraulic operating fluid on you and others. Should fluid get on your skin, wash the area thoroughly with soap and water. Allowing hydraulic operating fluid to remain on the skin creates the risk of skin irritation.
<b>Caution</b>	Before replacing the hydraulic operating fluid, allow the fluid in the system to cool sufficiently. Hot fluid creates the risk of burn injury.
<b>Caution</b>	Allowing the hydraulic operating fluid level in the tank to become too low creates the risk of malfunction and breakdown.

■ Precautions when Preparing for a Test Run

Warning Warning	Always leave product installation, removal, piping, wiring, and other work up to specialists.
Warning	Never attempt any unauthorized modification of the hydraulic system or control circuit.
Warning	Never attempt any unauthorized modification of the setting values of the pressure and flow rate adjusting devices.
Caution	Always check new hydraulic devices for looseness of internal components that may have occurred during shipment and check to make sure that all components are fitted securely.
Caution	Whenever suspending a product, make sure that you use all of the attached eye plates or eye bolts. Using any other method (such as using a single eye plate) to suspend the product creates the risk of it falling.

1. Checking the Product Model Number

<b>D</b> anger	In any atmosphere where there is the danger of explosion or fire, be sure to use only products that are designed for operation in such atmospheres.
<b>Caution</b>	Whenever installing a valve, pump, or motor, check its plate and engravings to confirm that it is the proper type. In many cases you cannot tell the difference between different hydraulic equipment types by their outward appearance only.

#### 2. Product Handling

/	<u>î</u>	7	Caut

Never climb onto, strike, tip over, or apply excessive force to a product. Doing so creates the risk of malfunction, damage, fluid leaks, etc.



Caution

Wipe up any hydraulic operating fluid that gets on the product or floor. Failure to do so creates the risk of personal injury due to the product slipping out of your hand and falling, and due to someone slipping on the fluid left on the floor.

#### 3. External Piping



- · Be sure to perform sufficient flushing.
- Anchor pipe supports to a secure surface.
- Use pipe that has sufficient pressure rating. The rated pressure of the pipe should be double the pressure that you plan to be using.
- The finish of the O-ring seal surface should be within the equivalent of 6.3S. Make sure there are no cracks, etc.

#### 4. Electrical



Leave all electrical work up to a qualified professional. Be sure to turn off power before performing electrical work. Failure to do so creates the risk of electric shock.



Warning

Failure to check the condition of the gate valve and relief valve when checking the rotation direction of a hydraulic pump creates the risk of accident, malfunction, and breakdown.

#### 5. Coupling Alignment



Caution

Though motor and pump shaft alignment is checked at the factory prior to shipment, they may go out of alignment during shipping or due to installation conditions. Because of this, you should always check for proper alignment during the test run.

#### 6. Valve, Pump, and Motor Installation

<b>Caution</b>	Make sure installation holes and surfaces are clean. Insufficient bolt tightening torque can allow fluid to leak, creating the risk of fire.
<b>?</b> Caution	Whenever installing a product, always use bolts of the specified strength and specified number, and tighten them to the specified torque. Failure to observer proper specified values during installation creates the risk of fire due to malfunction, mechanical damage, and hydraulic fluid leaks.

During installation and removal, never strike the pump shaft or motor shaft with a hammer or otherwise subject them to impact. Caution Doing so can damage the product.

Caution

In the case of a pump or motor that requires a drain pipe, the drain pipe that is used should not allow the pressure inside the casing to exceed the specified value. In the case of a pump or motor structure where operating fluid needs to be filled within the casing during operation, use a drain pipe that constantly replenishes operating fluid but does not allow air to collect inside of the casing. The drain pipe also should not let the level of operating fluid inside of the case to drop (does not allow fulid to return to the tank) during long periods of non-operation.

#### 7. High-pressure Restrictions



Warning

When using a pump that does not have a pressure compensation function (with maximum pressure adjustment), be sure to install a hydraulic circuit maximum pressure regulating relief valve near the pump discharge side.

# 8. Using an Accumulator

When using an accumulator, use only nitrogen gas. Be sure to read and understand all pertinent user documentation before using an accumulator.



Warning

Never attempt to modify an accumulator by mechanical processing or welding.

#### 9. Fluid Supply



Supply fluid up to the standard quantity through the prescribed oil supply port. Take care to ensure that no foreign matter or moisture contaminates the fluid. Also, check to make sure that the standard oil quantity is maintained even when the actuator

#### ■ Precautions During a Test Run

Warning	Authorized personnel only should be allowed in the vicinity of hydraulic devices during operation. Never touch devices during operation.
Warning Warning	Never remove covers of rotating parts or operate hydraulic devices with covers open.
Warning	Before turning on the power supply, first check to make sure that all operation switches are off.
<b>Caution</b>	Start up a pump while it is in the no-load state, and check to make sure that the rotation direction is correct.
<b>Caution</b>	Valves, pumps, and motor casings can become very hot during operation. Do not touch them.
Caution	Should you ever notice abnormal noise, abnormal heat, abnormal vibration, leaking oil, smoke, abnormal odor, or any other abnormal operation in a valve, pump, or motor, immediately shut down operation and take the necessary steps to correct the condition. Installation of sensors designed to detect abnormalities is recommended. Continued use under the above conditions creates the risk of damage, fire, and personal injury.

#### 1. Hydraulic Pump Operation


Warning	Before starting operation, check to make sure that all stop valves are correctly open or closed as required. Particular attention is required in the case of the suction line and return line.
<b>Caution</b>	Though there is some vibration during normal operation, extreme vibration may indicate a defective fitting. Continued use creates the risk of accident or breakdown.
<b>!</b> Caution	Use a current meter to check for abnormally high loads on the motor. A large load can indicate a defective fitting, sticking, etc. Correct the abnormality before operating the pump.

# 2. Priming (Air Bleeding)

<u>/i</u>	Warning	Set the pressure to a value that does not operate the actuator (normally 72 to 200 psi). Perform operation carefully while monitoring the pressure with a pressure gauge.
<u>/i</u>	Warning	When bleeding air while the actuator is being operated, be careful about the movement of the machinery. Shut down the machinery immediately whenever there is the danger of accident.
<u>/i</u>	Caution	Performing work while operating fluid is below the prescribed level or using a mixture of different types of operating fluid creates the risk of malfunction or breakdown of the pump or other devices.

3. Actuator Operation		
	Warning Warning	Operate the actuator manually at low speed for initial operation. While carefully observing the operation of the machine, perform continuous operation and automatic operation. Trying to perform continuous operation and automatic operation for the initial operation creates the risk of unexpected accident and breakdown.

# 4. Cleaning the Filter



Warning	Use valves within their prescribed maximum operating pressures (including surge pressure).
Warning Warning	Sudden operation of the handle (screw) is dangerous. Be sure to unload the valve before gradually increasing pressure. Never keep a valve at a pressure that is greater than its design specification pressure value.
<b>N</b> Warning	Make sure you understand the hydraulic circuit diagram and switching valve structure, and check the electrical operation circuit and solenoid valve before performing any operation.  • An incorrect switching direction can cause reverse operation of the actuator and create the risk of unexpected accident and breakdown.
Warning	Make sure you understand the hydraulic circuit diagram and flow control valve structure before performing any operations.  • Sudden operation can change the operating speed of the actuator and create the risk of unexpected accident or breakdown.

# Solenoid Valves, Proportional Valves, Servo Valves

Warning Warning	Use valves within their prescribed maximum operating pressures (including surge pressure).
Warning	Never charge both coils of a double solenoid valve at the same time.
<b>Caution</b>	The pump casing and solenoid coil surface can become very hot. Never touch them.
<b>Caution</b>	Be sure to use the appropriate model in environments that require water resistance.

# ■ Maintenance Precautions During Normal Daily Operation

# 1. Operating Fluid

<b>!</b> Caution	In order to ensure proper performance of hydraulic devices, check the fluid temperature, fluid level, and fluid color (for discoloration and deterioration) everyday. Any abnormalities create the risk of malfunction and breakdown.
<b>Caution</b>	Whiteish fluid indicates that water has contaminated the fluid, and blackish fluid indicates that the fluid has been subjected to high temperatures. Replace the operating fluid whenever these symptoms are noticed.
Caution	Operating fluid that is below the prescribed level can cause improper pump suction. Keep fluid filled to prescribed level.
<b>?</b> Caution	As it is used for normal operations, operating fluid deteriorates and gradually loses its rust inhibiting, lubrication, and foam inhibiting characteristics. Deteriorated operating fluid creates the risk of malfunction and breakdown. As a general rule, replace operating fluid at least once a year.

# 2. Hydraulic Pumps

<u>(i)</u>		A very hot hydraulic pump surface indicates the possibility of malfunction and breakdown. Immediately shut down the pump and take steps to correct the problem.
------------	--	---

#### 3. Fluid Leaks



Fluid leaking from welded pipe seams, from a hydraulic pump, from hydraulic machinery, or from other sources creates the risk of serious accident. Always be on the lookout for possible leaks.

#### 4. Filters



Continued use of a clogged filter creates the risk of unexpected accident and breakdown. Replace a filter as soon as possible after it shows signs of clogging. Never operate devices with filter elements removed.

#### 5. Pressure Gauges



Always be sure to tighten the gauge cock whenever you do not need to viewer the pressure gauge. Deflection of the needle can damage the pressure gauge.

#### 6. Tank Interior



Caution

Actual tank inspection needs depend on the contamination level of the operating fluid. As a general rule, the tank should be emptied of fluid and its interior inspected and cleaned once a year.

# 7. Hydraulic Devices



Caution

Never allow cutting oil, grinding oil, clippings, water, or other similar matter to get on hydraulic devices.

#### 8. Coolers



Caution

For a water cooler, adjust the temperature adjusting valve to keep the water temperature below 140° F. Provide a fan cooler to allow proper intake, outflow, and flow of cooling air.

#### ■ Handling Precautions During Non-use



If the system will not be operated for long periods, be sure to take proper anti-rust measures.

- Not operating the system for long periods without taking anti-rust measures creates the risk of malfunction and breakdown due to rust.
- Be sure to flush the system before using it again after a long period of non-use. Failure to flush out rust inhibitors creates the risk of malfunction and breakdown.

#### ■ Disassembly and Inspection Work Precautions

Warning Warning	Never attempt to modify or reconfigure valves, pumps, or motors. Doing so can cause them to operate at levels that are lower than for which they are designed, and creates the risk of malfunction and breakdown.
Warning Warning	All disassembly and inspection work should be left up to persons who possess the required special knowledge for such work.  Attempting disassembly without the required knowledge creates the risk of unexpected accident. Incorrectly performed disassembly and inspection work creates the risk of malfunction and breakdown.
Warning Warning	Before starting disassembly or maintenance work, make sure that all electrical breakers are cut off, and use an electroscope to check for the presence of electricity. Failure to do so creates the risk of unexpected accident to actuator free running, electric shock, etc.
Warning Warning	Performing work while the electrical circuitry is charged creates the risk of unexpected accident due to electric shock.
Warning	Always make sure to release all residual pressure before starting disassembly work. Performing disassembly work without releasing residual pressure creates the risk of accident due to spurting fluid, actuator free running, or dropping, and also creates the risk of malfunction and breakdown.
<b>Caution</b>	Always place valves, pumps, and motors on a secure surface, and never place them on top of hydraulic machinery. Doing so creates the risk of damage to the hydraulic machinery.
<b>Caution</b>	Never strike or drop valves, pumps, or motors, and never subject hydraulic equipment to strong external force.
Caution	During reassembly, failure to tighten to proper torques and contaminants getting into piping creates the risk of malfunction and breakdown.  • Take care to ensure that the tightening torques of hydraulic equipment are uniform and at prescribed levels.  • Take care that sealing materials, welding scales, and other contaminants do not get inside of piping.
<b>Caution</b>	After disassembly and reassembly, double check to make sure that you did not forget to open stopper valves, and that you have properly tightened all bolts, stopper plugs, couplings, and other required parts before performing the first operation.

#### ■ Storage Precautions



Caution

Seals may need to be replaced before using a product for the first time after long storage.

# **Standard Hydraulic Equipment ~ Index**

	NACHI Hydraulic Pumps General Information	A1-A2
Α		Λ± <sup>-</sup> Λ2
	Piston Pumps	
PVS	•	A3 
PZS	•	
PZ	•	np
В	Vane Pumps	•
VDS	·	)B1
103		B1
VDR22	•	umpB6
	·	B12
VDR13	_	PumpB15
VDC		B22 ne Vane PumpB25
VDC	VDC Series High-Pressure Type Variable Volum	•
	9 71	B37
UVN		NSP Uni-Pump)B39
C	Gear Pumps	
IPH	-	C1
	•	
	NACHI Hydraulic Valves	
		D1-D3
	Solonoid Valvos	
	Solenoid Valves	
SS SA		bx) Wet Type Solenoid ValveD4
SE	, , ,	e) Wet Type Solenoid ValveD16 Id Valve
SL	·	ox) Wet Type Solenoid Valve
DSS		ValveD41
SF	SF Series Fine Solenoid Valve	D49
SNH	- · · · · · · · · · · · · · · · · · · ·	D53
SAW SCW	<u> </u>	witch
SK		Monitoring SwitchD71
	Manual Valves	
		E1
F	Modular Valves	
004		F1
G01 G03		F4 F6
G04		F9
OR		
ORO		
ORD	ORD Direct Relief Modular Valve	F20
OG		F25
OGB		g Modular ValveF32
OG OGS		F34
<b>-</b> 43	OGO TWO-FTESSUTE REGUCTING MOUGHAT VAIVE	

Q	OQ Sequence Modular ValveF-	44	Diaton Dunon
CO	OCQ Counter Balance Modular ValveF-		Piston Pumps
W	OW Pressure Switch Modular ValveF		
	OY, OCY Flow Regulator Modular ValveF		
,	OF, OCF Flow Control Modular Valve (Pressure and temperature compensated)Fi		Vane Pumps
	OC, OCV Check Modular ValveF		
CP	OCP Pilot Operated Check Modular Valve		
K	OK Gauge Modular BlockF		
к В	OB High-Low System BlockF		Gear Pumps
IOB	MOB End Plate, Free Flow Plate, 03/01 Change PlateF		
	OTH, OTD Valve Installation Bolt List		
n, oid IOB	MOB 01, 03 Base BlockF		
			Solenoid Valves
35	M35 High Pressure ModulesF	92	
	Proportional Valves Congret Information	C1	
חמ	General Information		Manual Valves
PR	EPR Electro-Hydraulic Proportional Pilot Relief Valve		
3	ER Electro-Hydraulic Proportional Relief Valve		
βB	EGB Electro-Hydraulic ProportionalRelief and Reducing Valve		Modulan Value
5	ES Electro-Hydraulic Proportional Flow Control Valve		Modular Valves
SR	ESR Load Response Electro-Hydraulic Proportional Relief and Flow Control Valve		
SD	ESD Electro-Hydraulic Proportional Relief and Flow Control Valve	14	
	ESD Pressure Compensation Valve Kit		Proportional
OG	EOG Modular Type Electro-Hydraulic Proportional Reducing Valve	22	Valves
)F	EOF Modular Type Electro-Hydraulic Proportional Flow Control ValveG	24	
A, EMC	EMA, EMC Power Amplifier Series for Electro-Hydraulic Proportional Valve DriveG	26	
A, EDC	EDA, EDC Small Type Multi-Function Power AmplifierG	30	Subplates
SH	ESH G01 High-Response Proportional Flow Control Valve	38	Subplates
	ESH G03, 04, 06 High-Response Proportional Flow Control Valve	40	
НА	EHA High-Speed Response Proportional Control Valve		D
A	EA Electro-Hydraulic Servo Valve Driver Servo Amplifier		Pressure Control Valves
1 9	Subplates Part Number Index		
	Subplates Part Number Index	Н1	Flow Control
	Pressure Control Valves		Valves
	R Series Relief Valve	.11	
	RI Series Relief Valve (ISO Mounting, Balanced Piston Type)	15	Check Valves
		15	Check Valves
2	RI Series Relief Valve (ISO Mounting, Balanced Piston Type)	I5 I8	Check Valves
C SS	RI Series Relief Valve (ISO Mounting, Balanced Piston Type)	I5 I8 10	Check Valves
I C SS IS	RI Series Relief Valve (ISO Mounting, Balanced Piston Type)	I5 I8 10 15	Check Valves Hydraulic Units
I C SS IS G	RI Series Relief Valve (ISO Mounting, Balanced Piston Type)	I5 I8 10 15 18	
C SS IS G	RI Series Relief Valve (ISO Mounting, Balanced Piston Type)	l5 l8 10 15 18 23	
C SS S S R Q	RI Series Relief Valve (ISO Mounting, Balanced Piston Type)	l5 l8 10 15 18 23	
C SS S S R Q	RI Series Relief Valve (ISO Mounting, Balanced Piston Type)	I5 I8 10 15 18 23 25	Hydraulic Units
C SS S S R Q	RI Series Relief Valve (ISO Mounting, Balanced Piston Type)	I5 I8 10 15 18 23 25	Hydraulic Units
C SS IS G R Q	RI Series Relief Valve (ISO Mounting, Balanced Piston Type)	I5 I8 10 15 18 23 25 .J1	Hydraulic Units Wheel Motors
C SS IS G R Q	RI Series Relief Valve (ISO Mounting, Balanced Piston Type)	I5 I8 10 15 18 23 25 .J1 .J4	Hydraulic Units
C SS IS G R Q	RI Series Relief Valve (ISO Mounting, Balanced Piston Type)	I5 I8 10 15 18 23 25 .J1 .J4	Hydraulic Units Wheel Motors
C SS IS G R Q	RI Series Relief Valve (ISO Mounting, Balanced Piston Type)	I5 I8 10 15 18 23 25 .J1 .J4 .J4 .J8	Hydraulic Units Wheel Motors
C SS IS G R Q	RI Series Relief Valve (ISO Mounting, Balanced Piston Type)	I5 I8 10 15 18 23 25 .J1 .J4 .J4 .J8	Hydraulic Units  Wheel Motors  Technical Data
R T N	RI Series Relief Valve (ISO Mounting, Balanced Piston Type)	I5 I8 10 15 18 23 25 .J1 .J4 .J8 11	Hydraulic Units Wheel Motors

K Check Valves	
CA, CN CA, CN Series Right Angle Check Valve In-Line Check Valve  CP CP Series Pilot Check Valves  K2 K2 Gauge Cock  CA Flange Type Check Valve	K4 K7
NACHI Hydraulic Power Units	
L Power Units	
NV NV Vertical Units  NH NH Horizontal Units  NCP NCP Series Standard Variable Pump Unit  NSP NSP Series Compact Variable Pump Unit  NSP-L NSP-L Series Compact Variable Pump Unit  NSP-I NSP-I Series Energy-Saving Variable Pump Unit with Inverter Drive  NN NN Pack High-Pressure Standard Variable Pump Unit  ND/NNP NCP/NNP Series Energy-Saving Variable Pump Unit with Inverter Drive  Power Meister  Powerfit  NACHI Wheel Motors	L5 L26 L32 L34 L38 L43
M Wheel Motors	
PHV-1 PHV-1 PHV-2 PHV-2 PHV-3 PHV-3 PHV-4 PHV-4	M4 M7
N Technical Data	
Operating Fluid	N3
Model No. Index	
Model Number Index	01

# **NACHI Hydraulic Pumps**

#### **Features**

- 1 Nachi Fujikoshi hydraulic pumps are finished by high-grade, precision machining technology unique to the comprehensive manufacturer Nachi Fujikoshi using carefully selected materials and traditional heat treatment technology. High performance and quality are assured with all models of Nachi Fujikoshi hydraulic pumps.
- Noise has been thoroughly reduced on hydraulic pumps, a general source of noise on machinery and equipment. All models such as the low-noise type IP series can be operated quietly with little noise.
- Attention has been paid to surface <sup>3</sup> treatment and selection of materials in NACHI hydraulic pumps so that they can be applied extensively with fire-resistant hydraulic operating fluid.

# Installation and Maintenance

- 1 Limit the eccentricity between the drive shaft and hydraulic pump shaft to .001 in., keep the angle error within 1° and use flexible couplings for connections.
- 2 When operating hydraulic pumps with belts, gears and chains, prevent a radial or thrust load exceeding the allowable value from being applied on the pump shaft. Also, if necessary, install a device that prevents a load (bending force) from being applied at right angles on the shaft. Mount hydraulic pumps so that the pump shaft is horizontal.
- 3 Use a rigid pump mounting base.
- 4 The direction of rotation is determined on each hydraulic pump. Operate the hydraulic pump in the correct direction of rotation after checking the indicated model No. on the nameplate or the arrow indicating the direction of rotation on the body. The direction of rotation is clockwise when viewed from the shaft end.
- 5 Limit the suction pressure to within the range 4.3 psi.
- 6 With external drain type hydraulic pumps, directly connect the drain to the tank, insert the drain pipe under the oil level, and limit the drain back pressure to 4.3 psi.
- When connecting steel pipes to the suction and discharge sides, prevent force pressure from being applied on the hydraulic pump by the piping.
- 8 Set the clamping length of couplings and hydraulic pump shafts so that it is within at least 2/3 or more of the coupling width. Also, use a size of coupling that matches the shaft diameter.

- 9 When inserting couplings into shafts, insert them gently. When removing couplings from shafts, be sure to use a pulley extractor. Avoid hitting the shaft when attaching or removing couplings.
- 10 Connect to the suction port above the horizontal to keep oil inside hydraulic pumps.
- 11 Provide an air bleed valve in circuits where it is difficult to release air at startun
- 12 Be sure to use only specified bolts on hydraulic pumps. Use grade 8 or equivalent.

# **Uni-pumps**

Uni-pumps are compact pump/motor units which have a motor directly coupled to the hydraulic pump.

Variable discharge volume type vane pumps and piston pumps are available. As each of these pumps are ideally integrated with the motor, they can be easily installed, and more compact equipment configurations can be achieved economically.

· Standard Motor:

totally-enclosed splashproof housing surface flange cooled self-actuating type (totally enclosed fan-cooled type)

5 hp to 4P or less: Class E insulation

7 hp to 4P or more: Class B insulation

Voltage 200V··· 50/60 Hz 220V··· 60 Hz

# Management of Hydraulic Operating Fluid

- 1 Use mineral oil-based hydraulic operating fluid.
- 2 Provide a suction filter of about 100 to 150 mesh on the suction port.
- 3 When operating hydraulic pumps at a high pressure or when using fire-resistant hydraulic operating fluid, oil contamination greatly affect pump service life. So, use a filter of 10 μm or less.
- 4 Consult your agent when using fire-resistant hydraulic operating fluid. When using water- or glycol-based hydraulic operating fluid, refer to page N-3 for details on applicable models of hydraulic pumps.
- For details on the viscosity of hydraulic operating fluid, refer to the separate item "Hydraulic Operating Fluid."

# **Terms Used in This Catalog**

The following describes the meanings of the terms used in this catalog:

• Rated Pressure:

The maximum pressure at which a hydraulic pump can be used continuously.

• Maximum Operating Pressure:

The maximum pressure (including surge pressure) at which a hydraulic pump can be used within six seconds at most within 1/10 of the cycle time.

• Allowable Peak Pressure:

The maximum pressure (set pressure + surge pressure) that can be momentarily allowed.

The following shows the standards in Lists of Sealing Parts:

JIS standardB2401 (O-ring)
JIS standardB2407 (backup ring)
SAE standardAS568 (O-ring)

Pipe apertures mentioned in this catalog that are indicated as "G\*/\*" comply with JIS B2351 O-ring seal systems. Note, however, that G3/4 adopts dimensions before JIS revisions were made in 1990. Nachi Fujikoshi adopts P24 as the O-ring size whereas P22.4 is stated in current JIS standards.

# Calculation Formula Required when Selecting Hydraulic Pumps and Motors

1. Pump Discharge Flow Rate

$$Qp = (\frac{q \cdot N \cdot \eta v}{231} \text{ gal/min})$$

q = discharge volume per rotation (cu in/rev)

N = revolution speed (min<sup>-1</sup>)

 $\eta v = volume efficiency$ 

2. Power Required for Pump Drive

$$W_{P1} = \frac{P \cdot Qp}{1714} \text{ (hp)}$$

p = discharge pressure (psi)

 $\eta$  = overall efficiency

3. Motor Revolution Speed

$$N = (\frac{120 \cdot f}{P} \cdot (1 - S) (min^{-1})$$

f = frequency (50Hz, 60 Hz)

P = number of motor poles

S = slip rate

Catalog 1501

# **Hydraulic Pump Selection Table**


Pump Type	Name	Type Classifi- cation	Rated Pressure psi	Displacement cu in / rev  .12 .30 .61 1.2 3.0 6.1 12.2 30.5 61.0 122.0 305	Page
sdu	PVS series variable piston pump	PVS	3000	.21 2.74	A-3
ton pur	Uni-pump	UPV	3000	.21 2.74	A-19
Variable piston pumps	PZS series variable piston pump	PZS	3000	2.56 13.4	A-22
Vari	PZ load-sensitive variable piston pump	PZ	3000	.48 13.4	A-35
	VDS series compact variable vane pump	VDS	1015	.18 .5	B-1
s	Uni-pump	USV	1015	.18 .5	B-4
Variable discharge volume vane pumps	VDR22 design series variable vane pump	VDR	2030	.3 2.7	B-6
ıme van	Uni-pump	UVD	1015	.3 2.0	B-12
rge volu	VDR13 design series variable vane pump	VDR	870	1.69	B-15
discha	Uni-pump	UVD	870	1.69	B-22
/ariable	VDC series high-pressure variable vane pump	VDC	2030	.3 5.42	B-25
	Uni-pump	UVC	1015	.3 2.0	B-37
	UVN series variable vane uni-pump	UVN	1160	.49 1.59	B-39
rnal gear pump	IPH series IP pump	IPH	3625	.21 7.68	C-1
Internal gear pump	IPH series double IP pump	IPH	3045	.43 15.36	C-14

**Piston Pumps** 

# **PVS Series Variable Volume Piston Pumps**

.48 to 2.74 cu in/rev 3045 psi





- 🜣 Design No. 30 is applied on PVS-0B to make the pump more compact and lighter, and reduce noise.
- Production of PVS-3B has been discontinued. Use PZS-3B.
- Tressure adjustment 3 type has been added to PVS-1B-22 and PVS-2B-45. (Design No. 20 is applied only on PVS-2B-45\*3)

# **Features**

# **Energy-saving Type with Drastically Reduced Loss**

A NACHI-proprietary semi-circular barrel swash plate that receives pressure on its surface ensures a stable discharge volume at all times. This eliminates excess discharge volume, and enables the

effective use of power corresponding to the load cycle.

This "energy-saving type" conserves energy, reduces power loss, and helps to reduce hydraulic costs.

# Silent Type That Demonstrates Its Power Quietly

Proprietary low-noise mechanisms are incorporated on the shoe, swash plate, valve plate, and other locations to ensure silent operation. In particular, a semi-circular barrel swash plate stabilizes operation characteristics to ensure silent operation.

# **Specifications**

Model No.	Volume in³/rev	Discharge volume at no-load gpm			Pressure adjustment range psi	Permitted peak pressure	Rotating speed min <sup>1</sup>		Mass	
	(cm³/rev)	1000min <sup>-1</sup> 1200min <sup>-1</sup> 1500min <sup>-1</sup> 1800min <sup>-1</sup>			psi	Min.	Max.			
PVS-0B-8*0-E30 1 2 3	.1848 (8.0)	2.1	2.5	3.2	3.8	290 to 507 290 to 1015 435 to 2030 435 to 3045	3625	500	2000	17
PVS-1B-16*0-(*)-E13 1 2 3	.3 - 1.0 (16.5)	4.4	5.2	6.5	7.8	290 to 507 290 to 1015 435 to 2030 435 to 3045	3625	500	2000	23
PVS-1B-22*0-(*)-E13 1 2 3	.42 - 1.34 (22.0)	5.8	7.0	8.7	10.5	290 to 507 290 to 1015 435 to 2030 435 to 3045	3625	500	2000	23
PVS-2B-35*0-(*)-E13 1 2 3	.48 - 2.1 (35.0)	9.2	11.1	13.9	16.6	290 to 507 290 to 1015 435 to 2030 435 to 3045	3625	500	2000	51
PVS-2B-45*0-(*)-E13 1 2 3 -(*)-E20	.67 - 2.74 (45.0)	11.9	14.3	17.9	21.5	290 to 507 290 to 1015 435 to 2030 435 to 3045	3625	500	2000	51

Note: Direction of rotation is clockwise when viewed from the shaft end.

- Handling
- Cautions during Pump Installation and Piping
- 1 Use flexible couplings for connecting the pump shaft to the drive shaft, and prevent a radial or thrust load from being applied on the pump shaft.
- 2 For centering of the pump shaft, limit the eccentricity between the drive shaft and hydraulic pump shaft to .002 in, and keep the angle error within 1°.
- 3 Set the clamping length of couplings and hydraulic pump shafts so that it is within at least 2/3 or more of the coupling width.
- 4 Use a sufficiently rigid pump mounting base.
- 5 Set the pressure on the pump suction side to 4.3 or more (suction port flow velocity within 6 ft/sec).
- 6 Raise part of the drain piping to above the topmost part of the pump body, and

insert the return section of the drain piping into the hydraulic operating fluid. Also, observe the values in the following table to limit the drain back pressure to 14 psi.

Model No.	PVS-0B PVS-1B	PVS-2B
Pipe joint size	3/8" or more	1/2" or more
Pipe I.D	3/8"	1/2"
Pipe length	39"	39"

- Management of Hydraulic Operating Fluid
- 1 Use good-quality hydraulic operating fluid, and use within a kinematic viscosity range of 20 to 200 centistokes during operation. Use an R&O type and antiwear hydraulic fluid of ISO-VG32 to 68.

The optimum kinematic viscosity during

- operation is 20 to 50 centistokes.
- 2 The operating temperature range is 40 to 190° F. When the oil temperature at startup is 40° F or less, warm up the hydraulic pump by low-pressure, low-operation speed operation until the oil temperature reaches 40° F.
- 3 Provide a suction strainer with a filtering grade of about 100µm (150 mesh). Be sure to provide a return line filter of grade 10µm or less on the return line to the tank. (When the hydraulic pump is used at a high pressure of 2000 psi or more, we recommend providing a filter of 10µm or less
- 4 Manage the hydraulic operating fluid so that contamination is maintained at class NAS10 or lower.
- 5 Use hydraulic operating fluid within an operating ambient temperature of 32 to 140° F.

(continued on following page)

- Caution at Startup NACHI-proprietary 1 Before you start pump operation, fill the
- pump body with clean hydraulic operating fluid via the lubrication port.

Model No.	Injection amount cu in
PVS-0B-8	13
PVS-1B-16, 22	18
PVS-2B-35, 45	39

- 2 An unload is required when the motor is started under condition WYE.Delta Start. Consult your agent regarding the circuit.
- 3 Make sure that the pump operates in the direction of rotation the same as that indicated by the arrow on the pump body.

**Explanation of Model No.** 

PVS - 1 B - 16 N 2 - (\*) - 12

- 4 Air entering the pump or pipes may cause noise or vibration. At startup, set the pump discharge side to a no-load state, and operate the pump in the inching mode to release any air in the pump or pipes.
- 5 Provide an air bleed valve in circuits where it is difficult to release air at startun
  - · How to Set Pressure and Discharge Volume

The default pump discharge volume is set to "maximum" and default discharge pressure is set to "minimum". Change the discharge volume and discharge pressure settings according to your particular operating conditions.

12: PVS-1B, PVS-2B (BSPT piping)

E13: PVS-1B, PVS-2B (SAE piping)

E20: PVS-2B -45N3

Z: Axial port type

A: Mounting foot type

Design No. 30: PVS-0B

Auxiliary Symbol None: Side port type

Pressure Adjustment Range [Note] Reference

Variable Control Mechanism [Note] Reference

Nominal 8, 16, 22, 35, 45

Max. Pump Capacity (cm3/rev)

B: Mounting flange type

C2: 429-2000pg

sol"ON

sol"OFF" Discharge pressure

Mounting Method

Pump Size 0,1,2

PVS Series Variable Piston Pump


PVS-1B-16C2S2 Solenoid specifications

120V 50/60Hz

SS-G01

[Pressure adjustment] Turning the pressure adjusting screw CW increases the pressure.

[Discharge volume adjustment] Turning the flow rate adjusting screw CW decreases the discharge volume.



#### Note:

- · For details regarding the relationship between flow rate adjustment length I and pump capacity q, see the tables provided in the installation dimension drawings for each of the pumps.
- · Firmly tighten the lock nuts after you have finished adjustments.
- · Variable control mechanism

#### Standard Type

N\* Pressure compensation type (manual modė)

# Option type

P\* Pressure compensation type

(remote control mode)

R Load Sense

N\*0\* 2-pressure, 2-flow rate control

A⊛ R\* Solenoid cutoff control

W\* 8 ⊛ 2-pressure control

RQ\*S ⊕ 2-pressure, 2-flow rate control w/ solenoid cutoff

C\* 8€ 2-cutoff control

• \*: Pressure adjustment range

0:286-500

1:286-1000

2:429-2000

3:429-3000


• (a): Applicable to solenoid specifications A, S

A ⊕: SA-G01 S®: SS-G01

1:100V 50/60Hz

2:200V 50/60Hz

3: DC12V



R, load sense available for all PVS models.

■ NQ, RS, WS, RQS and CS types are not available for the PVS-0B-8.

 $\blacksquare$  NQ, RQS and CS types are not available for the PVS-1B-  $\frac{16}{22}$  -Z and PVS-2B-  $\frac{35}{45}$  -Z.

A 4

# **Variable Control Mechanisms**

Symbol External View Characteristics **Hydraulic Circuit** Explanation Pressure Pressure compensation type volume Drain port adjusting screw Standard type port Flow rate (manual system) adjusting scre When the discharge pressure Discharge reaches the preset volume (4) set by the pressure compensator, the discharge volume is N automatically reduced to hold the pressure at the set ய் Drain ⊕ἶ⊕ Suction pressure. Discharge pressure port Discharge Differential pressure Pilot port Drain port volume Pressure compensation type Flow rate adjusting screw (adjustment forb port (remote control mode) adjusting so This mode demonstrates the Discharge same characteristics as the Option type manual mode. Р The discharge pressure can be adjusted by external pilot pressure. The discharge volume Suction can be adjusted manually. Discharge pressure q1 flow rate adjusting screw 2-pressure, 2-flow rate control P2 pressure q2 flow rate Discharge port Discharge volume Drain port **type**The discharge volume changes adjusting screw adjusting screw **q1** in two stages by the pump's built-in sequence valve. This NO allows conventional high/low pressure control to be performed on a single pump ці Drain unit, and save energy in the hydraulic circuit. Discharge pressure P1 pressure adjusting screw port port Discharge port volume Solenoid cutoff control type Pressure adjusting screw A solenoid valve for unload is integrated into the pressure Drain port (at solenoid ON) Discharge RS compensation type to minimize SOL SOL (RA) energy loss when pump output Flow rate adjusting scre is not required. Only a slight amount of heat is generated. ய் Drain Suction Discharge pressure port Discharge port volume Pressure 2-pressure control type Pressure adjusting screw adjusting screw Two pressure compensation (at solenoid OFF) (at solenoid ON) types can be obtained by **Discharge** ws switching the solenoid valve ON/OFF. Two types of output Drain port SOL SOL (WA) Flow rate "ON' "OFF control are possible with the adjusting screw actuator set to a constant Suction Discharge pressure port port P2 pressure 2-pressure, 2-flow rate control adjusting screw Discharge volume Discharge port type w/ solenoid cutoff
The discharge volume can be (at solenoid ON) q2 flow rate Drain port changed in two stages by the adjusting screw ROS sequencer valve and solenoid P1 SOL ON (RQA) <u>q2</u> valve for unload mounted on q1 flow rate the pump, and unloading is adjusting screw Suction possible when pressure oil is SOL OFF P2 port port not required. P1 pressure adjusting screw Discharge pressure q1 flow rate adjusting screw Discharge volume g2 flow rate Drain port adjusting screw

(adjustment forbidden) Discharge port 2-cutoff control type adjusting screw Two types of pressure - flow rate characteristics can be CS obtained by the solenoid valve q2 SOL ON and cylinder mounted on the (CA) pump. Φ Φ Suction Drain P1 SOL OFF port Discharge pressure P2 pressure adjusting screw Discharge Differential pressure Load sense type volume Flow rate adjusting screw This mode demonstrates the adjusting scre same characteristics as the Discharge manual mode. R The discharge pressure can be adjusted by external pilot pressure. The discharge volume can be adjusted manually. Note 2) Discharge pressure

Note 1: Many other variable control mechanism are also available in addition to those in the above table. Please consult your agent for details.

Note 2: We recommend ZR-T02-\*-5895\* as the remote control valve. For details, consult your agent. Prevent the pipe volume up to the remote control valve from falling below 10 cu in.


# **Pressure Compensation Type**


Manual Mode: Standard Type

PVS-0B-8N\*-30

2 Bolt SAE A Mount


# **Installation Dimension Drawing**





Set a flow rate adjustment length within the above range. Oil will leak if the pump is operated below the adjustment range

# **Cross-Sectional Drawing**



Part No.	Part Name	Part No.	Part Name	Part No.	Part Name
1 2 3 4 5 6 7 8 9 10 11 12 13	Body Case Shaft Cylinder barrel Valve plate Piston Shoe Shoe holder Barrel holder Swash plate Thrust bush Spring holder Gasket	15 16 17 18 19 20 21 22 23 24 25 26 27	Spring S Control piston Guide pin Parallel key Retainer Needle Ball bearing Needle bearing Oil seal Snap ring Snap ring Snap ring O-ring	29 30 31 32 33 34 35 36 37 38 39	Parallel pin Spring pin Hexagon socket head bolt Cross-recessed countersunk head screw Hexagon socket set screw Hexagon nut Hexagon plug Metal plug Nameplate Lubrication port plate CAUTION plate
14	Spring C	28	O-ring	40	Rivet


#### Seal Kit Part No. PSS-100000

	Part	Part Name	Q'ty	PVS-0B-8	
	No.	T art ivallie	Qty	Size	Remarks
*	13	Packing	1	PSC46-100000	3 Bond
	23	Oil seal	1	TCV-254511	N.O.K
	27	0-ring	1	1B-P9	JIS B 2401
	28	0-ring	1	1B-P11	JIS B 2401

Parts marked by an asterisk "\*"are not available on the market. Consult your agent.

# **Pressure Compensation Type**


# Typical characteristics at hydraulic operating fluid kinematic viscosity of 32 centistokes




# **Installation Dimension Drawing**

# PVS-1B- $\frac{16}{22}$ N\*-(Z)-E13

SAE A Mount (side port type)




Relationship between flow rate adjustment length (  $\!\ell\!)$  and pump capacity (q)




Flow rate adjustment length  $\ell$  in

Set a flow rate adjustment length within the above range. Oil will leak if the pump is operated below the adjustment range lower limit.

#### (Axial Port Type)



# **Cross-Sectional Drawing**




Part No.	Part Name	Part No.	Part Name
1	Body	22	Ball bearing
2	Case	23	Needle bearing
3	Shaft	24	Oil seal
4	Cylinder barrel	25	Snap ring
5	Valve plate	26	Snap ring
6	Piston	27	Snap ring
7	Shoe	28	O-ring
8	Shoe holder	29	O-ring
9	Barrel holder	30	O-ring
10	Swash plate	31	Pin
11	Thrust bush	32	Hexagon socket head bolt
12	Seal holder	33	Cross-recessed coun-
13	Gasket		tersunk head screw
14	Spring C	34	Hexagon socket set screw
15	Spring S	35	Metal plug
16	Control piston	36	Nameplate
17	Needle	37	CAUTION plate
18	Key	38	Spring holder
19	Nut	39	Lubrication port plate
20	Retainer	40	Rivet
21	Plug	41	Guide pin


# List of Sealing Parts (Kit Model Number PSS-101000-2A)


	Part No.	Name	Q'ty	Size	Remarks
*	13	Gasket	1	PS46-101000	Nihon Gasket
	24	Oil seal	1	TCN-254511	N.O.K
	28	0-ring	1	1B-G55	JIS B 2401
	29	0-ring	1	1B-P9	JIS B 2401
	30	0-ring	1	1B-P14	JIS B 2401


Parts marked by an asterisk "\*" are not available on the market. Consult your agent.




# **Installation Dimension Drawing**








#### Relationship between flow rate adjustment length (I) and pump capacity (q)



Set a flow rate adjustment length within the above range. Oil will leak if the pump is operated below the adjustment range lower limit.




art lo.	Part Name	Part No.	Part Name	Part No.	Part Name
1 2 3 4 5 6 7 8 9 10 11 11 11 13 14 15	Body 146 Case 172 Shaft Cylinder barrel Valve plate Piston Shoe Shoe holder Barrel holder Swash plate Thrust bush Seal holder Gasket Spring C Spring S	16 17 18 19 20 21 22 23 24 25 26 27 28 29 30	Control piston Needle Key Nut Retainer Plug Ball bearing Needle bearing Oil seal Snap ring Snap ring Snap ring O-ring O-ring O-ring	31 32 33 34 35 36 37 38 39 40 41 42 43	Backup ring Pin Hexagon socket head bolt Cross-recessed coun- tersunk head screw Flow rate adjust- ing screw Metal plug Nameplate CAUTION plate Spring holder Guide Lubrication port plate Orifice Rivet


# **Cross-Sectional Drawing**

PVS-2B- $\frac{35}{45}$ N*-(Z)-E13
35 (19) (31) (30) (32) (42) (16) (36)

# **SAE B Mount**



#### PVS-2B-45N3-(Z)-E13



#### List of Sealing Parts (Kit Model Number PSS-102000-2A)

	Part No.	Part Name	Q'ty	PVS-2B-35/45	
	r are ivo.	rarchanic	Qty	Size	Remarks
*	13	Gasket	1	PS46-102000-0A	Nihon Gasket
*	24	Oil seal	1	TCN-305011Z	N.O.K
	28	0-ring	1	1B-G70	JIS B 2401
	29	0-ring	1	1B-P14	JIS B 2401
	30	0-ring	1	1B-P11	JIS B 2401
	31	Backup ring	1	T2-P11	JIS B 2407


Parts marked by an asterisk "\*" are not available on the market. Consult your agent.

Part No.	Part Name	Part No.	Part Name	Part No.	Part Name
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16	Body Case Shaft Cylinder barrel Valve plate Piston Shoe Shoe holder Barrel holder Swash plate Thrust bush Seel holder Gasket Spring C Spring S Control piston	17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32	Needle Key Nut Retainer Plug Roller bearing Oil seal Snap ring Snap ring Snap ring O-ring O-ring O-ring Backup ring Pin	33 34 35 36 37 38 39 40 41 42 43 44 45 46	Hexagon socket head boit Cross-recessed countersunk head screw Flow rate adjusting screw Metal plug Nameplate CAUTION plate Spring holder Guide Lubrication port plate Orifice Rivet Orifice Pin O-ring
				47	Plug


# List of Sealing Parts (Kit Model Number PSBS-102220)

	Part No.	Part Name	Q'ty	PVS-2B-45N3	
	r are ivo.	rarename	Qty	Size	Remarks
*	13	Gasket	1	PS46-102000-0A	Nihon Gasket
*	24	Oil seal	1	TCN-305011Z	N.O.K
	28	0-ring	1	1B-G70	JIS B 2401
	29	0-ring	1	1B-P14	JIS B 2401
	30	O-ring	1	1B-P11	JIS B 2401
	46	0-ring	2	1B-P5	JIS B 2401
	31	Backup ring	1	T2-P11	JIS B 2407

Parts marked by an asterisk "\*" are not available on the market. Consult your agent.




# **Response Performance**



Model No.	Response	Surge Pressure psi	
Model No.	tı	t <sub>2</sub>	Ps
PVS-0B-8	0.03 to 0.04	0.04 to 0.06	290 to 580
PVS-1B-16	0.05 to 0.06	0.07 to 0.08	580 to 1000
PVS-1B-22	0.05 to 0.06	0.07 to 0.08	725 to 1160
PVS-2B-35	0.05 to 0.06	0.05 to 0.07	870 to 1300
PVS-2B-45	0.05 to 0.06	0.05 to 0.07	870 to 1300

Response performance changes according to pipe volume and size. Use a surgeless valve to prevent surge pressure.

# **Pressure Compensator**



Part No.	Part Name	Part No.	Part Name
1	Body	8	Nut
2	Spool	9	O-ring
3	Holder	10	O-ring
4	Plunger	11	O-ring
5	Spring	12	Plug
6	Retainer	13	Plug
7	Pressure	14	Mounting bolt
	adjusting bolt	1	

# Replacement Items

# **PVS Rotating Group**

PVS-0B-8\*E30 PSCG-100000-0F PVS-1B-16\*E13 PSG-101100-0A PVS-1B-22\*E13 PSG-101200-1E PVS-2B-35\*E13 PSG-102100-0A PVS-2B-45\*E13 PSG-102200-0A PVS-2B-45N3\*E20

Includes Items 4,5,6 & 7

# PVS Thrust Plate Item 11

PVS-0B-8*E30	PSC69-100000
PVS-1B-16*E13	PS69-101000
PVS-1B-22*E13	PS69-101000
PVS-2B-35*E13	PS69-102000
PVS-2B-45*E13	PS69-102000


# List of Sealing Parts

Part No.	Name	Q'ty	Size For OB, 1B, 2B
9	0-ring	1	1A-P14
10	0-ring	3	1B-P6
11	0-ring	1	1B-P10


Note: O-ring 1A/B-\*\* refers to JIS B2401-1A/B.

# **Compensator Part Numbers**

NO - PSN-101000	P - ZR-G01-P-E2405C
N1 - PSN-101010	R - ZR-G01-R3-E2171B
N2 - PSN-101020	
N3 - PSN-101030	




# 2-Pressure, 2-Flow Rate Control Type



# **Installation Dimension Drawing**


PVS-1B- 16 N\*Q\*-E13

**SAE A Mount** 



PVS-2B-  $\frac{35}{45}$  N\*Q\*-E13(E20)


SAE B Mount




Pump Model No.	q <sub>2</sub> Adjustment Range (in <sup>3</sup> /rev)	Default q 2 (Setting in <sup>3</sup> /rev)
PVS-1B-16	.12 to 0.6	.2
PVS-1B-22	.12 to .79	.26
PVS-2B-35	.12 to 1.16	.42
PVS-2B-45	.18 to 1.46	.54

Note 1: The setting range of maximum pump capacity  $q_1$  varies according to the setting of  $q_2$ .


Note 2: Overall efficiency at a low flow rate is worse than at the maximum flow rate. Pay attention to this when selecting the motor capacity for the drive.




# **Solenoid Cutoff Control Type**



# **Installation Dimension Drawing**










■ The coil surface temperature increases if this pump is kept continuously energized. Do not touch the surface of the coil directly with your hands.

# **2-Pressure Control Type**




# **Installation Dimension Drawing**





PVS-2B-  $^{35}_{45}$  W\* $^{A}_{S}$ \*-E13


SAE B Mount



■ The coil surface temperature increases if this pump is kept continuously energized.

Do not touch the surface of the coil directly with your hands.


# 2-Pressure, 2-Flow Rate Control Type w/Solenoid Cutoff




# **Installation Dimension Drawing**

PVS-1B- 16 RQ\* 8\*-E13


**SAE A Mount** 






PVS-2B-35 RQ\*A\*-E20

SAE B Mount



■ The coil surface temperature increases if this pump is kept continuously energized. Do not touch the surface of the coil directly with your hands.


# 2-Cutoff Control Type




# **Installation Dimension Drawing**

PVS-1B-  $^{16}_{22}$  C\*  $^{A_*}_{S}$ -E13


**SAE A Mount** 





PVS-2B-  $^{35}_{45}$  C\*  $^{A}_{5}$ -E20


SAE B Mount



■ The coil surface temperature increases if this pump is kept continuously energized.

Do not touch the surface of the coil directly with your hands.

# **Foot Mounting Kit**




Kit Model No.	Applicable Pump Model No.	Accessories				Dimensions				
KIL WIOGEI NO.	Applicable Fullip Model No.	Bolt	Q'ty	Washer	Q'ty	Α	В	С	Е	F
IHM-2-10	PVS-0B PVS-1B	TB-10 ×30	2	WP-10	2	127	152.5	69.8	1	50.8
IHM-4-10	PVS-2B	TB-12 ×30	2	WP-12	2	220.7	246	107.95	1	114.3

							Dimer	nsions							Weight
Kit Model No.	Н	(1)	(J)	К	N	Р	Q	(S)	Т	φD	<i>φ</i> d₁	φd₂	<i>φ</i> d₃	<i>φ</i> d₄	kg
IHM-2-10	96	64.5	32	17.5	13	M10	135	32.5	36.5	82.6	22	11	106.4	50	2.0
IHM-4-10	140	56.7	44	16	16	M12	195.5	12.7	53	101.6	22	11	146	40	5.5

When only the mounting feet are required, the pump mounting bolts, washers and other parts are sold together as the Foot Mounting Kit.

# Piping Flange Kit

For PVS-1B, 2B




Applicable Pump Model No.	PVS-1B	-16/22	PVS-2B	3-35/45		
Plunger Kit model No.	PSF-10	01000	PSF-102000			
Fluilger Kit moder No.	Suction port	Discharge port	Suction port	Discharge port		
A	70	65	79	70		
В	59	52	73	59		
С	52.4	47.5	58.7	52.4		
D	26.2	22.0	30.2	26.2		
Т	24	24	28	24		
<i>φ</i> d <sub>1</sub>	φ11	φ11	φ11	φ11		
$\varphi d_2$	φ28	φ22	φ37	φ28		
X	1	3/4	1-1/4	1		
Mounting bolt	TH-10 ×40	TH-10 ×40	TH-10 ×45	TH-10 ×40		
Washer	WS-B-10	WS-B-10	WS-B-10	WS-B-10		
0-ring	1B-G35	1B-G30	1B-G45	1B-G35		
Weight lbs	1.3	1.1	1.6	1.3		

Notes: 1. The piping flange is on sale in the Flange Kit which includes mounting bolts, washers and O-rings.

- O-ring 1B/B-\*\* refers to JIS B2401-1B.
   For details on tightening torque, see page C-11.

# **Uni-Pump Specifications**

Explanation of Model No.:



<sup>\*</sup>This Uni-Pump is the metric version from Japan

# Motor selection curves

o


870

1450

Discharge pressure P psi

2300

3000



How to select the motor

The lower side of the output curves for each of the motors shown above indicates the operation.

The lower side of the output curves for each of the motors shown above indicates the operation.

The lower side of the output curves for each of the motors shown above indicates the operating range under rated output for that motor.

Discharge pressure P psi

870 1450

2300

3000


0


Discharge pressure P psi

0

<sup>\*</sup> Select a uni-pump that has a pressure and flow rate that is within the range of the drive so that the drive will not overload

# **Installation Dimension Drawings**





1 hp Electric drive

1 hp Electric drive

Note: A terminal measurements are in parentheses ( ).

- \*These Pumps are Metric Versions from Japan
- 1. Drive motor is fully enclosed fan cooled, 1 to 5 hp is E type, and 7 to 10 hp is B type.
- 2. Standard voltage for drive motor is 200 VAC, 50/60 Hz or 220 VAC, 60 Hz; EM 230 VAC, EG 460 VAC
- 3. Viewed from the pump side, suction port is on the left and discharge port is on the right.
- 4. Broken lines indicate instances for the A terminal. Broken lines pass through to the other side of the pump along its center.

# **Motor Specifications**

Output								Motor	Dimensi	ons								Frame	Weight
hp	А	IL	С	D	Е	F	G	Н	I	J	L	М	N	S×T	KD	KL	0	No.	lbs
1	133	107.5	80	170	62.5	50	4.5	165	-	35	240.5	165	130	18 <sup>X</sup> 10	φ27	157	27.5	80M	14.5
2	143	118.5	90	198	70	62.5	10	190	-	40	261	176	150	12×10	φ27	159	-	90L	16
3	157.5	133	100	198	80	70	12	200	-	40	290.5	200	168	14 <sup>X</sup> 12	φ27	159	-	100L	21
5	186	143.5	112	214	95	70	12	-	261	40	329.5	220	168	14 <sup>X</sup> 12	φ27	166	-	112M	27
7	210.5	163.5	132	252	108	70	15	-	303	50	374	260	175	14 <sup>X</sup> 12	<i>φ</i> 35	240	-	132S	42
10	229.5	182.5	132	252	108	89	15	-	303	50	412	260	213	14 <sup>X</sup> 12	φ35	240	-	132M	48

#### Characteristics of drive motor for unipump (domestic standard 3 rating)

Output hp	Poles	(Note1) Model Number TYPE (N)	Voltage [V]	Frequency [Hz]	Current rating [A]	RPM rating [min <sup>-1</sup> ]	Heat resistance		
		VBDA	200	50	2.2	1400			
.5	4	(VDS series only)	200	60	2.0	1680	В		
		(VD3 series only)	230-460	60	2.0	1710			
			200	50	3.8	1410			
1	4	V*DA-*A4*07	200	60	3.4	1690	В		
			230-460	60	3.4	1720			
		4 V*DA-*A4*15	200	50	7.0	1410			
2	4		200	60	6.2	1690	В		
			230-460	60	6.0	1710			
			200	50	9.8	1400			
3	4	V*DA-*A4*22	200	60	8.9	1680	В		
			230-460	60	8.5	1710	1		
			200	50	16.0	1410			
5	4	V*DA-*A4*37	200	60	14.8	1690	В		
			230-460	60	14.0	1710	1		
			200	50	23.8	1430			
7	4	V*DA-*A4*55	200	60	21.0	1730	В		
			230-460	60	20.0	1740			
			200	50	31.8	1435			
10	4	V*DA-*A4*75	200	60	28.2	1730	В		
			230-460	60	27.0	1740	]		

The asterisks \* indicate variations in the hydraulic pump series, size, and position of terminal box. Check the ratings sticker on the top of the drive motor.

2.Contact us for variations in voltage.

# **PZS Series Variable Volume Piston Pumps**

4.27 to 13.47 cu in/rev 4.27 to 6.10 cu in/rev 4085 psi 7.93 to 13.42/rev 3642 psi





#### **Features**

1 High pressure, high reliability

ΝΔΟΗί

These pumps deliver the perfect combination of high pressure (4085 psi maximum) and high reliability.

Hydraulic device energy efficiency is ensured because variable volume capabilities provide the means to keep the discharge rate to the desired level.

2 Low noise, low vibration operation The semi-cylindrical swash plate of the PVS series provides high support and rigidity, making it possible to increase the number of pistons (from nine to 11) and equip optimal valve plates, all of which make low-noise operation possible.

3 High reliability, long life O-ring seals used for mating surfaces eliminate worries about oil leaks. A spherical valve plate maintains optimal hydraulic pressure balance, for stable operation across a wide range and better contamination resistance characteristics.

4 A wide range of possible applications In addition to use as a stand-alone pump, a PZS Series pump can be combined with another IP pump in a wide range of possible applications with an adapter kit.

# **Specifications**

		Pump	Rated	Maximum		Revolution	Speed min -1		Fixed Discharge	Pump (Note 1)	
IV	Aodel No.	Capacity in³/rev (cm³/rev)	Pressure psi	Working Pressure psi	Pressure Adjustment Range psi	Min.	Max.	Weight (Ibs)	Capacity cu in/rev	Pressure psi	GPM
PZS-3B-	70* 1-E4481A 3-E4481A 4-E10	2.74 - 4.27 (70)	3000	4085	291 - 1000 291 - 3000 291 - 4085	500	1800	81	3.6 to 15.8 (IPH- 2.3 type)	21 {214}	32
PZS-4B-	100* 1-E4481A 3-E4481A 4-E10	2.44 - 6.10 (100)	3000	4085	291 - 1000 291 - 3000 291 - 4085	500	1800	128	3.6 to 15.8 (IPH- 2.3 type)	21 {214}	46
PZS-5B-	130* 1-E10 3-E5533A 4	3.11 - 7.93 (130)	3000	3642	291 - 1000 291 - 3000 291 - 3642	500	1800	189	3.6 to 32.3 (IPH- 2.3.4 type)	21 {214}	60
PZS-6B-	180* 1-E10 3 4	6.16 - 10.98 (180)	3000	3642	291 - 1000 291 - 3000 291 - 3642	500	1800	271	3.6 to 63.9 (IPH- 2.3.4.5 type)	21 {214}	83
PZS-6B-	220* 1-E10 3 4	7.56 - 13.42 (220)	3000	3642	291 - 1000 291 - 3000 291 - 3642	500	1500	278	3.6 to 63.9 (IPH- 2.3.4.5 type)	21 {214}	87

1. Fixed discharge pump can be configured by combining with an IP pump

- 2. Pump capacity adjustment ranges are for control codes N, RS, and WS. For information about control code NQ, see page A-27.
- 3. Direction of rotation is clockwise when viewed from the shaft end.
- Handling
- Cautions during Pump Installation and **Piping**
- 1 Use flexible couplings for connecting the pump shaft to the drive shaft, and prevent a radial or thrust load from being applied to the pump shaft.
- 2 Eccentricity between the drive shaft and pump shaft should be no greater than .001 in, with an eccentric angle error of 1° or less.
- 3 Set the clamping length of couplings and pump shafts at least 2/3 the length of the coupling width.
- 4 Use a sufficiently rigid pump mounting base.
- 5 Set the pressure on the pump suction side to -5 psi or more (suction port flow velocity within 6 ft/sec).
- 6 Raise part of the drain piping to above the topmost part of the pump body, and

insert the return section of the drain piping into the hydraulic operating fluid. Also, observe the values in the following table to limit the drain back pressure to 14.5 psi.

Model No.	3B, 4B, 5B	6B		
Pipe joint size	at least 3/4"	at least 1"		
Pipe I.D	5/8	7/8		
Pipe length	1m or less	1m or less		

- 7 Mount the pump so the pump shaft is oriented horizontally.
- 8 Use of rubber hose is recommended in order to minimize noise and vibration.
- 9 Check valve is located on the discharge side of the pump. (To prevent reverse rotation and damage to the pump when it is off)

- Management of Hydraulic Operating Fluid
- 1 Use only good-quality hydraulic operating fluid with a kinematic viscosity during operation within the range of 20 to 200 centistokes. Normally, you should use an R&O type and wear-resistant type of ISOGV32 to 68 or equivalent. The optimum kinematic viscosity during operation is 20 to 50 centistokes.
- 2 The operating temperature range is 40 to 140°F. When the oil temperature at startup is 5 °C or less, run the pump at low pressure and low speed until the oil temperature reaches 40°F.
- 3 Provide a suction strainer with a filtering grade of about 100µ (150 mesh).

(continued on following page)

- 4 Manage hydraulic operating fluid so contamination is maintained at class NAS10 or lower.
- 5 Use hydraulic operating fluid when the operating ambient temperature is in the range of 32 to 140°F.
  - · Startup Precautions
- 1 Before starting up the pump, fill the pump body with clean hydraulic operating fluid through the lubrication port.

Model No.	Oil Amount cu in			
PZS-3B	61			
PZS-4B	110			
PZS-5B	134			
PZS-6B	183			

- 2 An unload circuit is required when the motor is started under condition WYE Delta. Contact your agent about the unload circuit.
- 3 Check to make sure that the rotation

- direction of the pump is the same as the rotation direction indicated by the arrow on the pump body.
- 4 Air entering the pump or pipes can cause noise or vibration. At startup, set the pump discharge side to a no-load state, and operate the pump in the inching mode to remove any air that might be in the pump or pipes.
- 5 Equip an air bleed valve in circuits where it is difficult to release air before startup.
  - (See "IP Pumps" on page C-13.)
- 6 Install a check valve on the discharge side to protect the pump if the load is large or if there is an accumulator in the circuit on the discharge side of the pump.
- 7 Do not release the pressure in the hydraulic circuit by switching the solenoid valve (RS/WS type) on the pump.
- 8 Provide a return filter of 10µm or less

 Configuring Pressure and Discharge Rate Settings

The factory default pump discharge rate setting is the setting's maximum value, while the default discharge pressure is the settings minimum value. Change the discharge rate and discharge pressure settings in accordance with your particular operating conditions.

[Pressure Adjustment] Rotating the pressure adjusting screw clockwise increases pressure.


[Discharge Volume Adjustment] Rotating the flow rate adjusting screw clockwise decreases the discharge rate. Pressure adjustment range

Note:


Securely tighten the lock nut after making adjustments.

# **Understanding Model Numbers**


Standard Type, Pressure compensation(N)




# P-Q characteristics




Discharge pressure psi




# Option type, 2-Pressure, 2-Flow Rate Control Type (NQ)



#### P-Q characteristics




Discharge pressure psi




Suction port Drain port

#### Solenoid Cutoff Control Type (RS) PZS - 4 B - 100 R \* S \* - E10 Design Number E-5533A Thru Drive 5B Note: Thru Drive for SAE A - E4481A (3B-4B Solenoid power supply 1: AC100-115V Pressure adjustment range 2: AC200-230V 1: 291 - 1000 3: DC12V 291 - 3000 4. DC24V 4: 291 - 4085 Note: PZS-5B/6B maximum operating pressure: 3625 psi Variable Control Mechanisms RS: Solenoid cutoff control (S: SS-G01) Pump capacity (cu in/rev) 70, 100, 130, 180, 220 Mounting method B: Flange type mounting A: Foot type mounting -Pump size 3, 4, 5, 6


■ Do not use the solenoid valve to release the pressure in the hydraulic circuit.







Suction port Drain port

# 2-Pressure Control System (WS)









# **Installation Dimension Drawings**

The ZR-T02-\*-5895\* is the recommended remote control valve. Provide piping to the remote control valve at a pipe volume of 9 cu in or less.

#### **Pressure Compensation Type**


Installing a remote control relieve valve to the pilot port provides remote control of pressure compensation. (PZS series "P type") PZS-3B-70N\*-E10 (E4481A Thru Drive)






# 2-Pressure, 2-Flow Rate Control Type PZS-3B-70N\*Q\*-10 (E4481A Thru Drive)

#### (will fit) 2 Bolt SAE C Mount




# PZS-4B-100N\*Q\*-10 (E4481A Thru Drive)

#### 4 Bolt SAE D Mount



#### PZS-5B-130N\*Q\*-10 (E5533A Thru Drive)

#### 4 Bolt SAE E Mount



#### **Pump Volume Adjustable Range**

Pump Model No.	Volume Adjustmer	Volume Adjustment Range cu in/rev					
Tump Woder No.	q⊩ Note 1	q∟ Note 2	q∟ Setting (cu in/rev)				
PZS-3B-70N*Q*-10	.3 to 4.2	.3 to 2.4	.85				
PZS-4B-100N*Q*-10	.9 to 6.1	.4 to 3.6	1.2				
PZS-5B-130N*Q*-10	1.0 to 7.9	.48 to 4.2	1.5				

Note 1: The setting range for pump maximum capacity  $q_H$  depends on the  $q_L$  setting.

Note 2: Overall efficiency at a low flow rate is worse than at the maximum flow rate. Keep this in


mind when deciding on the drive motor capacity.

Note 3:  $P_L$  is set to 500 psi before shipping. ( $P_H$  is the lowest pressure)

# P-Q characteristics by qH cu in/rev PL PH Discharge pressure psi

#### PZS Pump 2-Pressure 2-Flow Rate Control Flow Rate Adjustment Graph

- Be sure to adjust the low flow rate first, and then adjust the maximum flow rate.
- Remember that the maximum flow rate adjustment range (lower limit) changes in accordance with the low flow rate adjustment. The maximum flow rate adjustment lower limit is equivalent to the low flow rate adjustment length (L1) plus .43".
- Pump efficiency at a low flow rate is worse than at the maximum flow rate. Keep this in mind when deciding on the drive motor capacity.



Adapter with coupling for Thru Drive E4481A & E5533A


E4481A - PZMK SAE A (with 3/4" coupling)


E4481A - PZMK SAE A 5/8 (with 5/8" coupling)

E5533A - JWF-SUB-0187-15-A (SAE A with 7/8" coupling)

E5533A - JWF-SUB-0186-15-A (SAE A with 3/4" coupling)

E5533A - JWF-SUB-0188-15-A (SAE B with 1" coupling)






- Do not touch the surface of the coil directly with your hands.
- Do not use the solenoid valve to release the pressure in the hydraulic circuit

### **Performance Curves**


Typical Characteristics at a Hydraulic Operating Fluid Kinematic Viscosity of 46 centistokes


PZS-3B-70N\*-10





PZS-4B-100N\*-10


Typical Characteristics at a Hydraulic Operating Fluid Kinematic Viscosity of 46 centistokes















PZS-6B-180N\*-10

Typical Characteristics at a Hydraulic Operating Fluid Kinematic Viscosity of 46 centistokes













#### PZS-6B-220N\*-10

#### Typical Characteristics at a Hydraulic Operating Fluid Kinematic Viscosity of 46 centistokes










### **Performance Curves**

PZS-3B-70N\*-10 PZS-4B-100N\*-10 PZS-6B-\*\*N\*-10




Note 1: Contact your agent about this type of O-ring.

Part No.	Part Name	Part No.	Part Name	Part No.	Part Name
1	Body	19	Spring holder	37	0-ring
2	Case	20	Retainer	38	O-ring
3	Shaft	21	Needle	39	O-ring
4	Cylinder barrel	22	Key	40	O-ring
5	Valve plate	23	Plug	41	Backup ring
6	Piston	24	Pin	42	Orifice
7	Shoe	25	Orifice	43	Flat philips head screw
8	Shoe holder	26	Nut	44	Plug
9	Barrel holder	27	Ball bearing	45	Pin
10	Swash plate	28	Needle bearing	46	Bolt
11	Thrust bush	29	Oil seal	47	Plug
12	Seal holder	30	Snap ring	48	O-ring
13	Thrust plate	31	Snap ring	49	Plate
14	Spring C	32	Snap ring	50	Washer
15	Spring S	33	0-ring	51	Bolt
16	Control piston	34	0-ring	52	Eye bolt
17	End plug	35	0-ring		
18	Guide screw	36	O-ring		

List of Sealing Parts (Kit Model Number 3B: PZBS-103000, 4B: PZAS-104100, 5B: PZAS-104000, 6B: PZBS-106000)

	Part	Name			Product Numbe	r			Remarks
	No.	Name	PZS-3B	Q'ty	PZS-4B	Q'ty	PZS-6B	Q'ty	Remarks
	29	Oil seal	TCN-456812	1	TCN-507212	1	TCN-659013	1	NOK
	33	O-ring	1B-G95	1	1B-G105	1	1B-G135	1	JIS B 2401
	34	0-ring	1B-G130	1	1B-G155	1	1B-G200	1	"
	35	0-ring	1B-G50	1	1B-G50	1	1B-G65	1	"
	36	0-ring	1B-P34	1	1B-P36	1	1B-P41	1	"
	37	0-ring	1B-P12	1	1B-P16	1	1B-P16	1	"
*	38	0-ring	1B-P14	2	1B-P14	3	1B-P14	3	"
	39	0-ring	Note 1	1	1B-P9	1	1B-P10	1	"
	40	0-ring	1B-P8	5	1B-P8	5	1B-P8	8	"
	41	Backup ring	T2-P12	1	T2-P16	1	T2-P16	1	JIS B 2407
	48	0-ring	Note 1	1	1B-G85	1	1B-G85	1	JIS B 2401

#### PZS-5B-130N\*-10




PZS-5B (Kit Model Number 5B : PZAS-104000)

Part No.	Name	Q'ty	Size	Remarks
13	Gasket	1	*	3 Bond
30	Oil seal	1	TCN-608212	N. O. K
34	O-ring	1	1B-G125	JIS B 2401
35	O-ring	2	1B-P21	JIS B 2401
36	O-ring	1	1B-P16	JIS B 2401
37	O-ring	1	1B-P42	JIS B 2401
38	O-ring	1	1B-P14	JIS B 2401
39	O-ring	5	1B-P8	JIS B 2401
40	O-ring	2	1B-P7	JIS B 2401
41	Backup ring	1	T2-P16	JIS B 2407
48	O-ring	1	1B-G85	JIS B 2401

Parts marked by an asterisk "\*" are not available on the market. Consult your agent.

## **Pressure Compensator**



Part No.	Part Name	Part No.	Part Name
1	Valve body	12	Collar
2	Spool	13	Plug
3	Spring guide	14	Plug
4	Sprint bearing	15	Nut
5	Spring	16	Socket head screw
6	Retainer	17	0-ring
7	Needle valve	18	0-ring
8	Valve seat	19	0-ring
9	Spring	20	0-ring
10	Adjustment screw kit	21	0-ring
10-1	Adjustment screw	22	Plug
10-2	Nut		
10-3	O-ring		
10-4	Nut		
10-5	Spring pin		
11	Retainer		

Part No.	Part Name	Part No.	Part Name
1	Body	28	Ball bearing
2	Case	29	Needle bearing
3	Shaft	30	Oil seal
4	Cylinder barrel	31	Snap ring
5	Valve plate	32	Snap ring
6	Piston	33	Snap ring
7	Shoe	34	O-ring
8	Shoe holder	35	O-ring
9	Barrel holder	36	O-ring
10	Swash plate	37	O-ring
11	Thrust plate	38	O-ring
12	Seal holder	39	O-ring
13	Gasket	40	O-ring
14	Spring C	41	Backup ring
15	Spring S	42	Bolt
16	Control piston	43	Flat philips head screw
17	End plug	44	Plug
18	Guide screw	45	Plug
19	Thrust bush	46	Plug
20	Spring holder	47	Orifice
21	Retainer	48	O-ring
22	Needle	49	Plate
23	Key	50	Washer
24	Plug	51	Bolt
25	Pin	52	Plug
26	Connector	53	Eye bolt
27	Nut	ı	


### List of Sealing Parts


Part	Name		Part N	umber		Remarks
No.	Name	PZS-3B, 4B	Q'ty	PZS-5B, 6B	Q'ty	Remarks
10-3	0-ring	1B-P10A	1	1B-P10A	1	JIS B 2401
17	0-ring	1B-P8	1	1B-P11	2	"
18	O-ring	1B-P9	4	1B-P9	5	"
19	0-ring	1B-P5	1	1B-P14	1	"
20	0-ring	1B-P12	1	1B-P22	1	"
21	O-ring	1B-P14	1	1B-P14	1	"

## **Foot Mounting Kit**

#### **Foot Mounting Installation Measurement Chart**







Foot Mounting	Applica	ble Pump		Accessories				Measurements (mm)								
Kit Model No.	Mod	del No.		Bolt Q'ty		Wash	ner	Q'ty	Α	В	С	Е	F	G	Н	(1)
PZM-3-10	PZS-3	3B	TH	l-16 ×40	4	WP-16	3	4	295.3	334	152.	4 1	-	139.7	203	104.5
PZM-4-10	PZS-4	4B	TH	l-20 ×45	4	WP-20		4	290	334	160	1	_	135	198	95
IHM-55-10	PZS-	5B , 6B	TH	l-20 ×50	4	WS-B-	20	4	330	370	200	1	125	125	300	40
Foot Mounting						Measurements			(mm)							Weight
Kit Model No.	(J)	K	L	М		Р	Q	R	(	S)	T	φD	<i>φ</i> d₁	<b>φ</b> d₂	<i>φ</i> d₄	kg

1 oot wounting						141	Casarciii	CITCS (ITIII)	•/						Weight
Kit Model No.	(J)	K	L	М	N	Р	Q	R	(S)	T	φD	<i>φ</i> d <sub>1</sub>	<b>φ</b> d₂	<i>φ</i> d₄	kg
PZM-3-10	60	25	128	128	25	M16	259	-	44.5	61	127	35	18	86	13.5
PZM-4-10	62	28	161.6	161.6	25	M20	270	220	33	62	152.4	34	18	<i>φ</i> 152.4	18.0
IHM-55-10	70 (Note)	30	224.6	224.6	30	M20	340	275	20	90	165.1	34	18	140	32.0

Note: The IHM-55-10 (J) dimension (70) is the value for the PZS-5B. This dimension becomes 58 in the case of the PZS-6B. The IHM-55-10 (I) dimension (40) is the value for the PZS-5B. This dimension becomes 28 in the case of the PZS-6B. See the IHM-45-10 on pages B-36 and C-12 to see what the PZM-3-10 looks like.

## **Piping Flange Kit**

#### Screw In Type

Screw In Type	Applicable Pump			IN Flange						
Flange Kit model No.	Model No.	Flange Part No.		Bolt		Washer		O-ring		
PJFE-10300T	PZS-3B	IH03J-100120	1	TH-12 ×55	4	WS-B-12	4	1B-G50	1	
PJFE-10400T	PZS-4B	IH03J-100160	1	TH-12 ×60	4	WS-B-12	4	1B-G60	1	
PJFE-10500T	PZS-5B	IH03J-100200	1	TH-12 ×65	4	WS-B-12	4	1B-G75	1	
PJFE-10600T	PZS-6B	IH03J-100240	1	TH-16 ×75	4	WS-B-16	4	1B-G85	1	

			OUT F	lange				
Flange Part No.		Bolt	Washer		0-ring			
IH03J-100100	1	TH-10 ×55	4	WS-B-10	4	1B-G40	1	
IH03J-100160	1	TH-12 ×60	4	WS-B-12	4	1B-G60	1	
IH03J-100200	1	TH-12 ×65	4	WS-B-12	4	1B-G75	1	
IH03J-100200	1	TH-12 ×65	4	WS-B-12	4	1B-G75	1	

#### Welded Type

Welded Type	Applicable Pump			IN Flange							
Flange Kit model No.	Model No.	Flange Part No.		Bolt		Washer		O-ring			
PJF-10300E	PZS-3B	IH03J-200120	1	TH-12 ×55	4	WS-B-12	4	1B-G50	1		
PJF-10400E	PZS-4B	IH03J-200160	1	TH-12 ×60	4	WS-B-12	4	1B-G60	1		
PJF-10500E	PZS-5B	IH03J-200200	1	TH-12 ×75	4	WS-B-12	4	1B-G75	1		
PJF-10600E	PZS-6B	IH03J-200240	1	TH-16 ×75	4	WS-B-16	4	1B-G85	1		

OUT Flange								
Flange Part No.		Bolt		Washer		0-ring		
IH03J-200100	1	TH-10 ×55	4	WS-B-10	4	1B-G40	1	
IH03J-200160	1	TH-12 ×60	4	WS-B-12	4	1B-G60	1	
IH03J-200200	1	TH-12 ×65	4	WS-B-12	4	1B-G75	1	
IH03J-200200	1	TH-12 ×65	4	WS-B-12	4	1B-G75	1	

See page C-11 for dimensions. O-ring 1B-\*\* refers to JIS B2401-1B-\*\*. See page C-11 for details on tightening torque.

## **Replacement Items**

### **PZS Rotating Group**

PZS-3B-70N\*10 PZBG-103000
PZS-4B-100N\*10 PZG-104100
PZS-5B-130N\*10 PZG-104000
PZS-6B-220N\*10 PZBG-106000
PZS-6B-180N\*10 PZBG-106100

Includes Items 4,5,6 & 7

### PZS Thrust Plate Item 11 (2 required per pump)

PZS-3B-70N\*E30 PZB69-103000 PZS-4B-100N\*E13 PZ69-104100 PZS-5B-130N\*E13 PZ69-104000 PZS-6B-220N\*E13 PZB69-106000 PZS-6B-180N\*E13 PZB69-106000

#### **PZS Compensator Kit**

	N1	N3	N4
PZS-3B-70N*10	ZR-G01-RI-2089C	ZR-G01-R3-2089C	ZR-G01-R4-2089C
PZS-4B-100N*10	ZR-G01-RI-2089C	ZR-G01-R3-2089C	ZR-G01-R4-2089C
PZS-5B-130N*10	ZR-G01-RI-4049B	ZR-G01-R3-4049B	ZR-G01-R4-4049B
PZS-6B-220N*10	ZR-G01-RI-4049B	ZR-G01-R3-4049B	ZR-G01-R4-4049B
PZS-6B-180N*10	ZR-G01-RI-4049B	ZR-G01-R3-4049B	ZR-G01-R4-4049B

## **PZ Series Load Sensitive Variable Piston Pump**

2.13 to 13.42 cu in/rev 3045 psi



#### **Features**

NΔCHi

- 1 The PZ Series load sensitive variable piston pump employs the semi-cylindrical swash plate that is part of the basic technology used by the PVS series variable piston pump. To this it adds a hydrostatic bearing mechanism, valve plate, and other noise reducing mecha-
- nisms for operation that is even quieter than that of PVS Series pumps.
- 2 The pump body houses an electrohydraulic proportional control valve, compensator, and surge cutoff valve, which eliminates the need for superfluous piping.
- 3 The electro-hydraulic proportional control valve uses the proven force feedback system for improved hysteresis, repeatability, and response.
- 4 The ability to create a double pump configuration with an IP pump further expands the range of possible applications.

### **Specifications**

#### **Pump System Specifications**

	Pump	Maximum	Pressure Adjustment	Flow Control	Revolution S	peed min -1	\A/-:	Fixed Discharge Pump Note 1	
Model No.	Capacity cu in/rev	Working Pressure psi	Range psi	Limit Range gpm Note 3	Min.	Max.	Weight Ibs	Capacity cu in/rev	Pressure psi
PZ-2B-*- 35E1A-11 2 3	2.13	3045	290 to 1000 290 to 2000 290 to 3000	.26 to 16.6	600	2000	79	3.6 to 8.18	3000
PZ-2B-*- 45E1A-11 2	2.74	2030	290 to 2000 290 to 3000	.26 to 21	600	2000	79	3.6 to 8.18	3000
PZ-3B-*- 70E1A-10 2 3	4.27	3045	290 to 1000 290 to 2000 290 to 3000	.26 to 33	600	1800	132	3.6 to 15.8	3000
PZ-4B-*-100E1A-10 2 3	6.10	3045	290 to 1000 290 to 2000 290 to 3000	.26 to 47.5	600	1800	167	3.6 to 15.8	3000
PZ-5B-*-130E1A-10 2 (Note 2) 3	7.93	3045	290 to 1000 290 to 2000 290 to 3000	.79 to 61.8	600	1800	220	3.6 to 32.3	3000
PZ-6B-*-180E1A-20 2 3	10.98	3045	290 to 1000 290 to 2000 290 to 3000	.79 to 85.6	600	1800	353	3.6 to 63.9	3000
PZ-6B-*-220E1A-20 2 3	13.42	3045	290 to 1000 290 to 2000 290 to 3000	.79 to 87.1	600	1500	357	3.6 to 63.9	3000

Note 1: Can be used in combination with an IP pump to configure a fixed discharge pump.

Note 2: The PZ-4B-130 model number was changed to PZ-5B-130.

Note 3: Maximum flow rate depends on the revolution speed. Values in the above table are for a speed of 1800min<sup>-1</sup> for the PZ-2B to PZ-6B-180, and 1500min<sup>-1</sup> for the PZ-6B-220.

#### Pressure/Flow Rate Control System Specifications Pressure Control System

,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,					
Pressure Control Range	.26 to 1000 .26 to 2000				
psi	.26 to 3000				
Rated Current mA	800				
Coil Resistance $\Omega$	20 (20° C)				
Hysteresis %	3% max. Note 1				

#### Flow Rate Control System


Valve Differential Pressure	145 Note 2		
Rated Current mA	800		
Coil Resistance $\Omega$	20 (20° C)		
Hysteresis %	3% max. Note 1		


Note 1. Value when a Nachi-Fujikoshi special

amplifier is used (with dithering).
Pressure differential of pump discharge
pressure (valve IN side) and load pressure Note 2


(valve OUT side). For information about power amplifiers, see pages G-26 through G-37. Note 3.

### PZ-2B/3B/5B






#### PZ-4B-100



### **Understanding Model Numbers**



- Handling
- Pump Installation and Piping Precautions
- 1 Use flexible couplings for connecting the pump shaft to the drive shaft, and prevent radial or thrust load from being applied to the pump shaft.
- 2 Eccentricity between the drive shaft and pump shaft should be no greater than 0.01 in, with an eccentric angle error of 1° or less.
- 3 Keep the clamping length of couplings and pump shafts at least 2/3 the length of the coupling width.
- 4 Use a sufficiently rigid pump mounting base.
- 5 Set pump suction side pressure to -4 psi or more (suction port flow velocity less than 6 ft/sec).
- 6 Raise part of the drain piping so it is above the topmost part of the pump body, and insert the return section of the drain piping into the hydraulic operating fluid. Also, observe the values in the following table in order to limit the drain back pressure to 14.5 psi.

Item Model No.	PZ-2B	3B PZ-4B 5B	PZ-6B
Pipe Joint	At least	At least	At least 1"
Size	1/2"	3/4"	
Pipe I.D.	1/2"	5/8"	7/8"
Pipe Length	1 m or less	1 m or less	1 m or less

- 7 Mount the pump so the pump shaft is oriented horizontally.
- 8 Use of rubber hose is recommended in order to minimize noise and vibration.


- Management of Hydraulic Operating Fluid
- 1 Use only good-quality hydraulic operating fluid with a kinematic viscosity during operation within the range of 20 to 200 centistokes.
  - Normally, you should use an R&O type and wear-resistant type of ISOGV32 to 68 or equivalent.
  - The optimum kinematic viscosity during operation is 20 to 50 centistokes.
- 2 The operating temperature range is 41 to 140°F. When the oil temperature at startup is 41°F or less, run the pump at low pressure until the oil temperature reaches 40°F.
- 3 Provide a suction strainer with a filtering grade of about 100µ (150 mesh).

  Provide a return line filter of grade 10µm or less on the return line to the tank.


  (When the pump is used at a high pressure of 2000 psi or greater, a filter of 10µm or less is recommended.)
- 4 Manage hydraulic operating fluid so contamination is maintained at class NAS10 or lower.
- 5 Use hydraulic operating fluid when the operating ambient temperature is in the range of 32 to 140°F.
  - Startup Precautions
- Before starting up the pump, fill the pump body with clean hydraulic operating fluid through the lubrication port.


Model No.	Oil Amount cu in
PZ-2B	39
PZ-3B	61
PZ-4B	110
PZ-5B	134
PZ-6B	183

- 2 Check to make sure that the rotation direction of the pump is the same as the rotation direction indicated by the arrow on the pump body.
- Air entering the pump or pipes can cause noise or vibration. At startup, set the pump discharge side to a no-load state, and operate the pump in the inching mode to remove any air that might be in the pump or pipes.
- 4 Equip an air bleed valve in circuits where it is difficult to release air before startup. (See "IP Pumps" on page C-13.)
- 5 To enable superior pressure and flow control, loosen the air vent when starting up the pump in order to release any air, and fill the inside of the solenoid with hydraulic operating fluid. You can change the position of the air vent by rotating its cover.
- 6 Before adjusting the manual adjusting screw from the first time or when there is no input current to the valve due to electrical malfunction or some other reason, you can control pump pressure and flow rate by rotating the manual adjusting screw. Normally, the manual adjusting screw should be returned completely to its original position and secured with the lock nut.




#### 4 Bolt SAE E Mount





### **Performance Curves**

Typical characteristics at hydraulic operating fluid kinematic viscosity of 32 centistokes



3000

Discharge pressure P psi

0

2000

Discharge pressure P psi

2000


Discharge pressure P psi

2000

Discharge pressure P psi

## **Cross-Sectional Drawing**

## PZ-2B- $^{35}_{45}$ E\*A-11




Part No.	Part Name	Part No.	Part Name
1	Body	24	Oil seal
2	Case	25	Snap ring
3	Shaft	26	Snap ring
4	Cylinder barrel	27	Snap ring
5	Valve plate	28	O-ring
6	Piston	29	O-ring
7	Shoe	30	O-ring
8	Shoe holder	31	Backup ring
9	Barrel holder	32	Pin
10	Swash plate	33	Screw
11	Thrust bush	34	Screw
12	Seal holder	35	Screw
13	Gasket	36	Plug
14	Spring C	37	Plug
15	Spring S	38	Plug
16	Control piston	39	Spring holder
17	Needle	40	Guide
18	Key	41	Hydraulic fluid input seal
19	Nut	42	Orifice
20	Retainer	43	Pin
21	Plug	44	Orifice
22	Ball bearing	45	Connector
23	Needle bearing	46	O-ring
			l

#### List of Sealing Parts (Kit Model Number PSBS-102220)

Part No.	Part Name	Q'ty	Size	Remarks
13	Gasket	1	PS46-102000-0A	3 Bond
24	Oil seal	1	TCN-305011	N. O. K
28	0-ring	1	1B-G70	JIS B 2401
29	0-ring	1	1B-P14	JIS B 2401
30	0-ring	1	1B-P11	JIS B 2401
31	Backup ring	1	T2-P11	JIS B 2407
46	0-ring	2	1B-P5	JIS B 2401

Parts marked by an asterisk "\*" are not available on the market. Consult your agent.

#### PZ-3/5B-\*E\*A-10




Part No.	Part Name	Part No.	Part Name	Part No.	Part Name
1	Body	18	Guide screw	37	0-ring
2	Case	19	Thrust bush	38	0-ring
3	Shaft	20	Spring holder	39	O-ring
4	Cylinder barrel	21	Retainer	40	O-ring
5	Valve plate	22	Needle	41	Backup ring
6	Piston	23	Key	42	Bolt
7	Shoe	24	Plug	43	Screw
8	Shoe holder	25	Pin	44	Plug
9	Barrel holder	26	Connector	45	Plug
10	Swash plate	27	Nut	46	Pin
11	Thrust plate	28	Ball bearing	47	0-ring
12	Seal holder	29	Needle bearing	48	Plate
13	Gasket	30	Oil seal	49	Screw
14	Spring C	32	Snap ring		
15	Spring S	33	Snap ring		
16	Control piston	34	Snap ring		
17	End plug	36	O-ring		
			I		l .

#### List of Sealing Parts (Kit Model Number 3B; PZAS-103200, 5B; PZAS-104000)

Part No.	Part Name	PZ-3B		PZ-5B		Remarks
rait No.		Size	Q'ty	Size	Q'ty	Remarks
13	Gasket	*	1	*	1	3 Bond
30	Oil seal	TCN-456812	1	TCN-608212	1	N. O. K
36	0-ring	1B-G95	1	1B-G125	1	JIS B 2401
37	0-ring	1B-P21	2	1B-P21	2	JIS B 2401
38	0-ring	1B-P12	1	1B-P16	1	JIS B 2401
39	0-ring	1B-P34	1	1B-P42	1	JIS B 2401
40	0-ring	1B-P7	2	1B-P7	2	JIS B 2401
41	Backup ring	T2-P12	1	T2-P16	1	JIS B 2407
47	0-ring	1B-G90	1	1B-G85	1	JIS B 2401

Parts marked by an asterisk "\*" are not available on the market. Consult your agent.

#### PZ-4/6B-\*



#### List of Sealing Parts (Kit Model Number 4B: PZAS-104100, 6B: PZBS-106000)

Part No.	Part Name	Part Name PZ-4B		PZ-6B		Remarks	
Turcivo.	Turcitanic	Size	Q'ty	Size	Q'ty	Remarks	
30	Oil seal	TCN-507212	1	TCN-659013	1	N. O. K	
34	0-ring	1B-G85	1	1B-G85	1	JIS B 2401	
35	0-ring	1B-G105	1	1B-G135	1	JIS B 2401	
36	0-ring	1B-G155	1	1B-G200	1	JIS B 2401	
37	0-ring	1B-G50	1	1B-G65	1	JIS B 2401	
38	0-ring	1B-P36	1	1B-P41	1	JIS B 2401	
39	0-ring	1B-P16	1	1B-P16	1	JIS B 2401	
40	0-ring	1B-P21	3	1B-P21	3	JIS B 2401	
41	0-ring	1B-P9	1	1B-P10	1	JIS B 2401	
42	0-ring	1B-P8	5	1B-P8	8	JIS B 2401	
43	Backup ring	T2-P16	1	T2-P16	1	JIS B 2407	

## **Foot Mounting Kit**

Pump Model No.	Mounting Model No.
PZ-2B	IHM-44-10
PZ-3B	
PZ-5B	IHM-55-10
PZ-6B	
PZ-4B	PZM-4-10

Note: See pages C-12 and A-34 for information about mounting methods.

## **Piping Flange Kit**

Flange Kit model No.	Applicable Pump	IN Flange										
riange Kit model No.	Model No.	Flange Part No.		Bolt		Washer		0-ring				
IHF -4-T-20	PZ-2B-35/45	IH03J-100100 1		TH-10 × 55	4	WS-B-10	4	1B-G40	1			
IHF -5-T-20	PZ-3B-70	IH03J-100120 1		TH-12 × 55	4	WS-B-12	4	1B-G50	1			
PZF -4-T-10	PZ-4B-100	IH03J-100160	1	TH-12 × 60	4	WS-B-12	4	1B-G60	1			
IHF -7-T-10	PZ-5B-130	IH03J-100200	1	TH-12 × 60	4	WS-B-12	4	1B-G75	1			
PZF -6-T-10	PZ-6B-180/220	IH03J-100240	1	TH-16 × 75	4	WS-B-16	4	1B-G85	1			


			OUT FI	ange				Plug		
Flange Part No.		Bolt		Washer		0-ring		, lug		
IH03J-100060	1	TH-10 × 50	4	WS-B-10	4	1B-G30	1	TPHA-1/4	1	
IH03J-100080	1	TH-10 × 50	4	WS-B-10	4	1B-G35	1	TPHA-1/4	2	
IH03J-100080	1	TH-10 × 50	4	WS-B-10	4	1B-G35	1	TPHA-1/4	1	
IH03J-100120	1	TH-12 × 60	4	WS-B-12	4	1B-G50	1	TPHA-1/4	1	
IH03J-100120	1	TH-12 × 60	4	WS-B-12	4	1B-G50	1	TPHA-1/4	1	

1. See page C-11 for dimensions. 2. O-ring 1B/B-\*\* refers to JIS B2401-1B.

3. See page C-11 for details on tightening torque.

Part No.	Part Name	Part No.	Part Name
1	Body	31	Snap ring
2	Case	32	Snap ring
3	Shaft	33	Snap ring
4	Cylinder barrel	34	0-ring
5	Valve plate	35	O-ring
6	Piston	36	O-ring
7	Shoe	37	O-ring
8	Shoe holder	38	O-ring
9	Barrel holder	39	O-ring
10	Swash plate	40	O-ring
11	Thrust bush	41	O-ring
12	Seal holder	42	O-ring
13	Sleeve	43	Backup ring
14	Spring C	44	Orifice
15	Spring S	45	Screw
16	Control piston	46	Plug
17	End plug	47	Pin
18	Guide screw	48	Bolt
19	Spring holder	49	Plug
20	Thrust plate	50	Plate
21	Retainer	51	Washer
22	Needle	52	Bolt
23	Key	53	Eye bolt
24	Plug	54	Electro-hydraulic proportional valve
25	Pin		
26	Orifice		
27	Nut		
28	Ball bearing		
29	Needle bearing		

Oil seal





### VDS Series Small Variable Volume Vane Pump

0.5 in³/rev 3.94 gpm 1015 psi





#### **Features**

## High efficiency operation with minimal power loss

All the performance of the original new VDR series mechanisms combines with precision machining for a pump that minimizes power loss, especially at full cutoff.

#### Quiet operation

Journal bearings with a proven record on IP pumps plus new suction and discharge port configurations reduce operating noise and deliver quiet operation with minimal vibration, even in the high-pressure range.

## Compact and simple design, easy operation

Compact and quiet, VDS Series variable vane pumps are economical and easy to handle. A simple design allows use in a wide range of hydraulic systems.

## Precise characteristics, prompt response

Prompt response at both ON-OFF

and OFF-ON ensures instantaneous, stable, high-precision operation.

## Solidly built for high efficiency and long life

VDS Series pumps are built to last, with a design that incorporates years of NACHI experience and know-how. Specially selected materials and skilled workmanship provide outstanding durability along with stable, high-efficiency operation.

## **Specifications**

	Model No.	Capacity in <sup>3</sup> /rev		No-load Disc	harge Rate om		Pressure Allowable Adjustment Peak Range Pressure		Revolution S	Weight Ibs	
	III / iev	111 / 164	1000min <sup>-1</sup>	1200min <sup>-1</sup>	1500min <sup>-1</sup>	1800min <sup>-1</sup>	psi	psi	Min.	Max.	3
•	VDS-0A(B)-1A1-E11  " -1A2-E11  " -1A3-E11	.50	2.1	2.6	3.2	3.94	145 ~ 290 317 ~ 507 435 ~ 1015	2030	800	1800	A:14.3 B:9.9


- Handling
- The direction of rotation for this pump is clockwise (rightward) when viewed from the shaft side.
- 2 Drain piping must be direct piping up to a point that is below the tank fluid level, and back pressure due to pipe resistance should not exceed 4.3 psi.
- 3 When adjusting pressure, pressure is increased by clockwise (rightward) rotation of the adjusting screw and decreased by counterclockwise (leftward) rotation.
- 4 When adjusting the flow rate, the flow rate is decreased by clockwise (rightward) rotation of the adjusting screw and increased by counterclockwise (leftward) rotation. The graph on the right provides general guidelines for the relationship between the rotation angle of the flow rate adjusting screw and the noload discharge rate.
- 5 Factory Default P-Q Settings (Standard Model)
  - Flow Rate Setting = Maximum flow rate for model as indicated in the catalog.
  - Pressure Setting = Pressure shown in table below.

Factory Default	Ī
Pressure Settings	
kgf/cm² (psi)	
1 + 20 4 (200)	

1:20.4 (290) 2:35.7 (507) 3:71.4 (1015) Flow rate gpm =  $\frac{\text{in}^3 \text{ x rpm}}{231}$ 

Q: No-load Discharge Rate (gpm)

q: Capacity (in<sup>3</sup>/rev)



The values indicated above are at maximum pump discharge volume with the flow volume adjusting screwat the 0° position. The broken line shows the flow volume adjustment range lower limit value.

6 Thrust Screw The thrust screw is precision adjusted at the factory during assembly. Never touch the thrust screw. See callout 9 in the cross-section diagram on page B-4.

7 Initial Operation

Before operating the pump for the first time, put the pump discharge side into the no-load state and then repeatedly start and stop the motor to bleed all air from inside the pump and the suction piping. After confirming that the pump is discharging oil, continue the no-load operation for at least 10 minutes to discharge all the air from the circuit.

- 8 For the hydraulic operating fluid, use an R&O type and wear-resistant type of ISO VG32 to 68 or equivalent (viscosity index of at least 90). Use hydraulic operating fluid that provides kinematic viscosity during operation in the range of 20 to 150 centistokes.
- 9 The operating temperature range is 59 to 140°F. When the oil temperature at startup is 59°F or less, perform a warm-up operation at low pressure until the oil temperature reaches 59°F. Use the pump in an area where the temperature is within the range of 59 to 140°F.

(continued on following page)

Catalog 1501


- 10 Suction pressure is 4.35 psi, and the suction port flow rate should to greater than 6 ft/sec.
- 11 Avoid pulley, gear, and other drive systems that impart a radial or thrust load on the end of the pump shaft.

  Mount the pump so its pump shaft is oriented horizontally.
- 12 Provide a suction strainer with a filtering grade of about 100  $\mu m$  (150 mesh). For the return line to the tank, use a 10  $\mu m$  line filter.
- 13 Manage hydraulic operating fluid so contamination is maintained at class NAS10 or lower. Take care to avoid contamination with water or other foreign matter, and watch for discoloration. Whitish fluid indicates that air has contaminated the fluid, and brownish fluid indicates the fluid is dirty.
- 14 Contact your agent about using waterand glycol-based hydraulic operating fluids.
- 15 At startup, repeat the inching operation

- (start-stop) to bleed air from the pump and pipes.
- 16 Equip an air bleed valve in circuits where it is difficult to bleed air before startup. See page C-13 for more information.
- 17 To ensure proper lubrication of the pump's rubbing surfaces, supply oil to the interior of the pump before starting operation.
- 18 When centering the pump shaft, eccentricty with the motor shaft should be no greater than 0.001 in.

  The angle error should be no greater than 1°.


### **Understanding Model Numbers**



#### **Installation Dimension Drawings**

VDS-0A-1A-\*-10

Foot Mounting Type mm (inch)



VDS-0B-1A-\*-10 **SAE A Mount** Flange Mounting Pressure adjusting screw (IN-OUT port dimension) 26 1/4" SAE DR 20 3/8" SAE 3.97 +0.03 1/2" SAE OUT IN MAX 58 10

42

118.5


Flow rate adjusting screw

4


## **Specifications**

Typical characteristics at hydraulic operating fluid kinematic viscosity of 32 centistokes


106 125



### **Axial Input at Full Cutoff**




#### **Noise Characteristics**



## **Cross-Sectional Drawing**

VDS-0B-1A\*-10



List of Sealing Parts Seal Kit: VBAS-100B00

Applicable Pump Model: VDS-0A/B-1A \*10

Part No.	Part Name	Part Number	Q'ty
18	0-ring	AS568-032	1
19	0-ring	AS568-023	1
20	0-ring	S71 (NOK)	1
21	0-ring	1A-P20	1
22	0-ring	1A-P10	2
27	Oil seal	TC-17358	1

Note:


- Oil seals are manufactured by Nippon Oil Seal Industry Co. Ltd. (NOK).
- 2. O-ring 1A/B-\*\* refers to JIS B2401-1A.

Part No.	Part Name	Part No.	Part Name
1	Body	16	Key
2	Cover (A)	17	Nut
3	Cover (B)	18	0-ring
4	Shaft	19	0-ring
5	Cam ring	20	0-ring
6	Vane	21	0-ring
7	Plate (S)	22	0-ring
8	Plate (H)	23	Screw
9	Thrust screw	24	Bearing
10	Screw	25	Screw
11	Piston	26	Screw
12	Holder	27	Oil seal
13	Spring	28	Snap ring
14	Nut	29	Pin
15	Сар	30	Nameplate

## **Uni-Pump Specifications**

(CE mark standard compliant)

**Understanding Model Numbers** 




Cartridge Kit: VBAC-100\*A\*

Includes Items: 4, 5, 6, 7, 8, 16, 29

Maximum Working Pressure	Maximum Fl	ow Rate gpm		
kgf/cm (psi)	50Hz	60Hz		
71.4 (1015)	3.30	3.94		

- 1. Standard drive motor is the fully enclosed fan-cooled B type.
- Standard voltage for drive motor is 200 VAC, 50/60 Hz or 220 VAC, 60 Hz.
- 3. Standard terminal box is B terminal (right side viewed from pump).

#### **Motor Selection Curves**



#### · How to select a motor

The area under a motor output curve in the graph to the left is the operating range for that motor under the rated output for that motor.


#### Example:


To find the motor that can produce pressure of 507 psi and a discharge rate of 3.3 gpm.

#### Selection Process:

Since the intersection of the two broken lines from a pressure of 507 psi and discharge rate of 3.3 gpm intersect in the area under the 2 hp curve, it means that a 2 hp motor should be used.

#### **Installation Dimension Drawings**





Uni-pump		Motor Dimensions mm										Frame	Output hp	Weight					
om-pump	Α	IL	С	D	Е	F	G	Н	J	L	М	N	S×T	KD	KL	0	No.	(4 poles)	lbs
USV-0A-A1-0.4-4-20																			
USV-0A-A2-0.4-4-20	121	107.5	71	150	56	45	2.3	146	30	228.5	140	110	15 × 7	φ27	151	35	71M	0.5	30
USV-0A-A3-0.4-4-20																			
USV-0A-A1-0.75-4-20																			
USV-0A-A2-0.75-4-20	133	107.5	80	170	62.5	50	4.5	165	35	240.5	165	130	18 × 10	φ27	157	27.5	80M	1.0	42
USV-0A-A3-0.75-4-20																			
USV-0A-A3-1.5-4-20	143	118.5	90	198	70	62.5	10	190	40	261.5	176	150	12 × 10	φ27	159	-	90L	2	45

 $<sup>^{\</sup>star}$  See page A-21 for the characteristics of the drive motor for the unipump (domestic standard 3 rating).

<sup>\*</sup> Select a uni-pump that has a pressure and flow rate that is within the range of the drive so that the drive will not overload.

# NACHI

### VDR Design Series Variable Volume Vane Pump

7.9 gpm at 2030 psi 10.5 gpm at 1000 psi





#### **Features**

## Stable, highly efficient operation up to 2030 psi

A biased piston that minimizes ring vibration and leak-free pressure balance construction enables highly efficient highpressure operation, and very stable performance up to 2030 psi.

## High-precision instantaneous response

Response has been improved by a special bias piston mechanism. Prompt response at both ON-OFF and OFF-ON

ensures instantaneous, stable, high-precision operation.

## Silent operation, even in the high pressure range

CQuiet journal bearings, a bias piston that allows a 3-point support system, and new suction and discharge port shapes all contribute to minimize operation noise. Silent, vibration-free operation is ensured, even in the high pressure range.

Reduced power loss

A combination of NACHI-original mechanical innovations and precision machining create a pump that minimizes power loss, especially at full cutoff.

## Solid construction stands up to harsh operating conditions

The tough and rugged construction of this pump is made possible by a long history of quality pump designs. This, in combination with specially selected materials and skilled workmanship, provides outstanding durability.

### **Specifications**

#### Single Pump

	Mode	el Type	No-load I	Discharge Rate I/n	nin (gpm)	Pressure Adjustment Range	Allowable Peak Pressure	Revolution S	peedmin -1	Weight
1	Foot Mounting	Flange Mounting	1800 rpm	1500 rpm	1200 rpm	psi	psi	Min.	Max.	lbs
٧	/DR-1A-1A2-*22	VDR-1B-1A2-*22				217 ~ 507	500			
١	/DR-1A-1A3-*22	VDR-1B-1A3-*22	30 (7.9)	25 (6.6)	20 (5.3)	435 ~ 1015	1000	800	1800	19.9
١	/DR-1A-1A4-*22	VDR-1B-1A4-*22	30 (1.3)	23 (0.0)	20 (3.3)	942 ~ 1522	1500	800	1000	19.9
٧	/DR-1A-1A5-*22	VDR-1B-1A5-*22				1305 ~ 2030	2000			
٧	/DR-1A-2A2-*22	VDR-1B-2A2-*22	40 (10.6)	33 (8.7)	27 (7.1)	214 ~ 500	500	800	1800	19.9
١	/DR-1A-2A3-*22	VDR-1B-2A3-*22	40 (10.0)	33 (6.7)	21 (1.1)	429 ~ 1000	1000	800	1800	15.5

#### **Double Pump**

Model No.	Ve	nt Side		Shaft Side	Vent Side	Shaft Side	Revolution S	Speedmin -1	Weight
Foot Mounting Type (Flange Mounting Type)	Discharge Rate gpm	Pressure Adjustment Range psi	Discharge Rate gpm	Pressure Adjustment Range psi	Allowable Peak Pressure psi		Min.	Max.	lbs
VDR-11A(B)-1A2-1A2-22 VDR-11A(B)-1A2-1A3-22	7.9	217 ~ 507		217 ~ 507 435 ~ 1015	20	30	800	1800	37
VDR-11A(B)-1A3-1A3-22	1.9	435 ~ 1015	7.9	435 ~ 1015		300	1000	31	
VDR-11A(B)-2A2-2A2-22 VDR-11A(B)-2A2-2A3-22	40.5	217 ~ 507	10.5	217 ~ 507 435 ~ 1015	2030		000	4000	37
VDR-11A(B)-2A3-2A3-22	10.5	10.5		435 ~ 1015		800	1800	31	

Note: 1. The discharge rate is the value at 1800min<sup>-1</sup> no load.

2. The change from design number 21 to design number 22 represents a change in the shaft key width from .125 in to .187 in. This means that when using a .125 in key coupling, you need to use a stepped key (VD31J-302000) or add a new key groove at .187 in.


#### Handling

- 1 Rotation Direction
- The direction of rotation is always is clockwise (rightward) when viewed from the shaft side.
- 2 Drain

Drain piping must be direct piping up to a point that is below the tank fluid level, and back pressure due to pipe resistance should not exceed 4.35 psi. When using a pump that has drain ports at two locations, use the drain port that is higher after the pump is installed.

3 Discharge Volume Adjustment
The discharge flow rate is decreased by clockwise (rightward) rotation of the discharge rate adjusting screw, and increased by counterclockwise (leftward) rotation. Loosen the lock nut before making adjustments. After adjustment is complete, re-tighten the lock nut. The graph on the right provides general guidelines for the relationship between the rotation angle of the flow rate adjusting screw and the no-load discharge rate.

(continued on following page)



Flow rate gpm:  $Q = \frac{\text{in}^3 \text{ x rpm}}{231}$ 

- Q: No-load Discharge Rate Q r/min q: Volume cm³/rev
- N: Revolution Speed min<sup>-1</sup>

The broken line shows the flow volume adjustment range lower limit value.

Note:

The values indicated above are at maximum discharge volume with the flow volume adjusting screw at the 0° position.

4 Pressure Adjustment
Pressure is decreased by clockwise
(rightward) rotation of the discharge rate

adjusting screw, and increased by counterclockwise (leftward) rotation.

- 5 Factory Default P-Q Settings (Standard Model)
  - Flow Rate Setting = Maximum flow rate for model as indicated in the catalog
  - Pressure Setting = Pressure shown in table to the right
- 6 Thrust Screw

The thrust screw is precision adjusted at the factory during assembly. Never touch the thrust screw. See callout 21 in the cross-section diagram on page B-11.

#### Factory Default Pressure Settings kgf/cm² (psi) 2:35.7 (507) 3:30.6 (435) 4:66.3 (942) 5:91.8 (1305)

#### 7 Initial Operation

Before operating the pump for the first time, put the pump discharge side into the no-load state and then repeatedly start and stop the motor to bleed all air from inside the pump and the suction piping. After confirming that the pump is discharging oil, continue the noload operation for at least 10 minutes to discharge all the air from the circuit.

Provide an air bleed valve in circuits where it is difficult to bleed air before startup.

- Sub Plate
- Use the following table for specification when a sub plate is required. For detailed dimensions, see pages B-17 through B-19.
- Profite hydraulic operating fluid, use type ISO VG32 or equivalent (viscosity index of at least 90) for pressures of 1015 psi or lower, and type ISO VG68 or equivalent (viscosity index of at least 90) for pressures greater than 10 15 psi.


Pump Model No.	Sub Plate Number	Motor(hp)
VDR-1A-1A*-22	MVD-1-115-10	1~2
VDII-1A-1A -22	MVD-1-135-10	3~5
VDR-1A-2A*-22	MVD-1-115Y-10	1~2
VDII-1A-2A -22	MVD-1-135Y-10	3~5
VDR-11A-*A* -*A*-22	MVD-11-135-10 MVD-11-135X-10	2~5

- 10 The operating temperature range is 59 to 140°F. When the oil temperature at startup is 59°F or less, perform a warm-up operation at low pressure until the oil temperature reaches 59°F. Use the pump in an area where the temperature is within the range of 32 to 140°F.
- 11 Suction pressure is 4.35 psi, and the suction port flow rate should be to greater than 6 ft/sec.
- Avoid pulley, gear, and other drive systems 12 that impart a radial or thrust load on the end of the pump shaft. Mount the pump so


its pump shaft is oriented horizontally.
(Continued on following page)

### **Understanding Model Numbers**


#### Single Pump





#### Double pump



- 13 Provide a suction strainer with a filtering grade of about 100  $\mu m$  (150 mesh). For the return line to the tank, use a 10 $\mu m$  line filter.
- 14 Manage hydraulic operating fluid so contamination is maintained at class NAS10 or lower. Take care to avoid contamination with water or other foreign matter, and watch out for discoloration. Whitish fluid indicates that air has contaminated the fluid, and brownish
- fluid indicates the fluid is dirty.
- 15 Contact your agent about using waterand glycol-based hydraulic operating fluids
- 16 At startup, repeat the inching operation (start-stop) to bleed air from the pump and pipes.
- 17 Equip an air bleed valve in circuits where it is difficult to bleed air before startup. See page C-13 for more information.
- 18 To ensure proper lubrication of the pump's rubbing surfaces, supply oil to the interior of the pump before starting operation.
- 19 When centering the pump shaft, eccentricity with the motor shaft should be no greater than 0.001 in. Use a pump mounting base of sufficient rigidity. The angle error should be no greater than 1°.









## **Performance Curves**


Typical characteristics at hydraulic operating fluid kinematic viscosity of 32 centistokes.



## **Cross-Sectional Drawing**

#### VDR-1A-\*A\*-22





Part No. | Part Name

Body (A)

## List of Sealing Parts

#### Single Pump

Part	Applicable Pump Model No.	VDR-1A-*-22	
No.	Seal Kit Number	VDBS-101A00	
140.	Part Name	Part Number	Q'ty
18	Packing	VDB32-101000	1
27	Oil seal	ISRD-224211	1
29	Backup ring	VDB34-101000	1
30	Backup ring	VDB34-201000	1
31	0-ring	S85(NOK)	1
32	0-ring	1A-P22	1
33	0-ring	1A-P5	1
34	O-ring	1A-P14	1
35	O-ring	1A-P12	1
40	O-ring	AS568-036	1
41	0-ring	AS568-029	1
42	0-ring	1A-P22	2
43	0-ring	1A-P10A	1

- 1. Oil seals are manufactured by Nippon Oil Seal Industry Co. Ltd. (NOK).
- Oring 1A.\*\* refers to JIS B2401-1A.\*\*.
   For VDR-1B-\*-22, the seal kit number becomes VDBS-101B00, without the 42 and 43 O-rings.

#### **Double Pump**

Part	Applicable Pump Model No.	VDR-11A-*-*-2	2
Name	Seal Kit Number	VDBS-111A00	
rvaine	Part Name	Part Number	Q'ty
18	Packing	VDB32-101000	2
27	Oil seal	ISRD-224211	1
29	Backup ring	VDB34-101000	2
30	Backup ring	VDB34-201000	2
31	0-ring	S85(NOK)	2
32	0-ring	1A-P22	2
33	0-ring	1A-P5	2
34	0-ring	1A-P14	2
35	0-ring	1A-P12	2
40	0-ring	AS568-036	2
41	0-ring	AS568-029	2
42	0-ring	1A-P22	4
43	0-ring	1A-P10A	2


2	Body (B)	26	Spring pin
3	Cover	27	Oil seal
4	Cover	28	Snap ring
5	Shaft	29	Backup ring
6	Rotor	30	Backup ring
7	Ring	31	0-ring
8	Vane	32	0-ring
9	Plate (S)	33	0-ring
10	Plate (H)	34	0-ring
11	Piston	35	0-ring
12	Spring	36	Screw
13	Screw	37	Screw
14	Nut	38	Nut
15	Piston	39	Plug
16	Holder	40	0-ring
17	Adapter	41	0-ring
18	Packing	42	0-ring
19	Bearing (S)	43	0-ring
20	Bearing (H)	44	Screw
21	Thrust screw	45	Key
22	Nut	46	Nameplate
23	Key	47	Сар
24	Screw	48	Pin
			l .

Part No. | Part Name

Pin 25

Cartridge Kit: VDR-1-22; VDBC-101\*A\* Includes Items: 5, 7, 8, 9, 10, 23, 25


- 1. Oil seals are manufactured by Nippon Oil Seal Industry Co. Ltd. (NOK).
- 2. O-ring 1A-\*\* refers to JIS B2401-1A-\*\*.
  3. For VDR-11B-\*.\*-22, the seal kit number becomes VDBS-111B00, without the 42 and 43 O-rings.



#### **Specifications**

Model No.	Maximum Working Pressure	Maximum Flow R	ate gpm (A*)	Maximum Flow Rate gpm (2A*)				
Woder No.	kgf/cm² (psi)	50Hz	60Hz	50Hz	60Hz			
UVD-1A UVD-11A	71.4 (1015) 71.4 (1015)	6.6	7.9	8.7	10.5			

## Motor Selection Curves



\* Select a uni-pump that has a pressure and flow rate that is within the range of the drive so that the drive will not overload.

Discharge pressure P kgf/cm<sup>2</sup> (psi)

The area under a motor output curve in the graph to the left is the operating range for that motor under the rated output for that motor.


#### Example:

To find the motor that can produce pressure of 435 psi and a discharge rate of 6.6 gpm.

#### Selection Process:

Since the intersection of the two broken lines from a pressure of 435 psi and discharge rate of 6.6 gpm intersect in the area under the 3 hp curve, it means that a 3 hp motor should be used. In the case of a double pump configuration, select a motor that is larger than the total power required by both pumps.

## Installation Dimension Drawings UVD-1A




Uni-pump	Motor Dimensions mm								Frame	Output hp	Weight										
On pamp	Α	ΙL	С	D	Е	F	G	Н	1	J	L	М	N	S×T	KD	KL	0	No I	(4 poles)	lbs	
UVD-1A-A2-0.75-4-40	133	105	80	170	62.5	50	4.5	165	-	35	238	165	130	18 × 10	φ27	157	27.5	80M	1	53	
UVD-1A-A2-1.5-4-40																					
UVD-1A-A3-1.5-4-40	143	118.5	90	198	70	62.5	10	190	-	40	261.5	176	150	12 × 10	φ27	159	-	90L	2	55	
UVD-1A-2A2-1.5-4-40																					
UVD-1A-A2-2.2-4-40																					
UVD-1A-A3-2.2-4-40	157.5	133	100	198	80	70	12	200	-	40	290.5	200	168	14 × 12	φ27	159	-	100L	3	66	
UVD-1A-2A2-2.2-4-40																					
UVD-1A-A3-3.7-4-40																					
UVD-1A-2A2-3.7-4-40	186	140	112	214	95	70	12	-	261	40	326	220	168	14 × 12	φ27	166	-	112M	5	80	
UVD-1A-2A3-3.7-4-40																					

- 1 3 hp model does not have hangers.
- 1. Standard drive motor is the fully enclosed fan-cooled B type.
- 2. Standard voltage for drive motor is 200 VAC, 50/60 Hz or 220 VAC, 60 Hz.
- 3. Standard terminal box is B terminal (right side viewed from pump).
- $4. \, \text{See page A-21 for the characteristics of the drive motor for the unipump (domestic standard 3 \, \text{rating})}.$

Selecting a motor

#### UVD-11A



Motor Dimensions mm Uni-Pump							Frame	Output hp	Weight																				
Oni-i ump	Α	IL	С	D	Е	F	G	Н	1	J	L	М	N	S×T	KD	KL	0	No.	(4 poles)	lbs									
UVD-11A-A2-A2-1.5-4-40																													
UVD-11A-A2-A3-1.5-4-40	143	118.5	90	198	70	62.5	10	190	-	40	261.5	176	150	12 × 10	φ27	159	-	90L	2	73									
UVD-11A-A3-A3-1.5-4-40																													
UVD-11A-A2-A2-2.2-4-40																													
UVD-11A-A2-A3-2.2-4-40	157.5	157.5	157.5	157.5	157.5	133	100	198	80	70	12	200		40	290.5	200	168	14 × 12	φ27	159	_	100L	3	84					
UVD-11A-A3-A3-2.2-4-40						137.3	131.3	131.3	137.3	101.0	131.3	137.3	137.3	137.3	100	100	130	00	10	12	200		40	290.5	200	100	14 ^ 12	ΨΖΙ	100
UVD-11A-2A2-2A2-2.2-4-40																													
UVD-11A-A2-A2-3.7-4-40																													
UVD-11A-A2-A3-3.7-4-40																													
UVD-11A-A3-A3-3.7-4-40	186	140	112	214	95	70	12	-	261	40	326	220	168	14 × 12	φ27	166	_	112M	5	97									
UVD-11A-2A2-2A2-3.7-4-40																													
UVD-11A-2A2-2A3-3.7-4-40																													

- 1. 2 to 3 hp model does not have hangers.
- 1. Standard drive motor is the fully enclosed fan-cooled B type.
- 2. Standard voltage for drive motor is 200 VAC, 50/60 Hz or 220 VAC, 60 Hz.
- 3. Standard terminal box is 8 terminal (right side viewed from pump).

  4. See page A-21 for the characteristics of the drive motor for the unipump (domestic standard 3 rating).



# **VDR13 Design Series Variable Volume Vane Pump**

5.2 to 11.8 gpm 870 psi





The new design number 13 was created by modifying some of the components of old design numbers 11 and 12, and the new design installation is compatible with the old design.

#### **Features**

Energy efficient, economical operation

Built-in high-precision temperature compensation mechanism

The ring is displaced by a spring, and a rise in pressure automatically moves it to the center to make the discharge rate zero.

Relief valve and unloading valve can be eliminated from the circuit. It was possible to reduce the size of the unit because there was no increase of proportional input to pressure which prevented increases in the temperature of the fluid.

New design for lower noise and improved durability

- Handling
- 1 Rotation Direction The direction of rotation is always is clockwise (rightward) when viewed from the shaft side.
- 2 Drain Drain piping must be direct piping up to a point that is below the tank fluid level, and back pressure due to pipe resistance should not exceed 4.35 psi.

## **Specifications**

#### Single Pump

Model No.	Capacity					Pressure Adjustment Range	Allowable Peak Pressure	Revolutio mi	Weight			
Woder No.	in³/rev	<sup>3</sup> /rev 1000min <sup>-1</sup> 1200min <sup>-1</sup> 1500min <sup>-1</sup> 1800min <sup>-1</sup> kgf/cm <sup>2</sup> (psi)		1.06/-		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1			kgf/cm² (psi)	Min.	Max.	lbs
VDR-1A(B) -1A1-13 -1A2- -1A3-	.84 .84 .67	3.6 3.6 2.9	4.3 4.3 3.9	5.5 5.5 4.5	6.6 6.6 5.2	10.2 ~ 20.6 (145 ~ 290) 15.3 ~ 35.7 (217 ~ 507) 30.6 ~ 61.2 (435 ~ 870)	143 (2030)	800	1800	17.6		
VDR-2A(B) -1A1-13 -1A2- -1A3-	1.5 1.5 1.3	6.6 6.6 5.8	7.9 7.9 7.0	10 10 8.9	11.8 11.8 10.5	10.2 ~ 20.6 (145 ~ 290) 15.3 ~ 35.7 (217 ~ 507) 30.6 ~ 61.2 (435 ~ 870)	143 (2030)	800	1800	46		


#### Double Pump


Model No.	Ve	nt Side		Shaft Side	Vent Side Shaft Side		Revolution	on Speed	
Foot Mounting Type (Flange Mounting Type)	Discharge Rate gpm	Pressure Adjustment Range kgf/cm² (psi)	Discharge Rate gpm	Pressure Adjustment Range kgf/cm² (psi)	Allowable Pe kgf/cn	Min.	Max.	Weight Ibs	
VDR-11A(B)-1A1-1A1-13 VDR-11A(B)-1A1-1A2-13 VDR-11A(B)-1A1-1A3-13		10.2 ~ 20.6 (145 ~ 290)	6.6	10.2 ~ 20.6 (145 ~ 290) 15.3 ~ 35.7 (217 ~ 507) 30.6 ~ 51 (435 ~ 725)	1 <sup>2</sup> (20				A:30
VDR-11A(B)-1A1-1A3-13 VDR-11A(B)-1A2-1A2-13	6.6	15.3 ~ 35.7	5.2 6.6	15.3 ~ 35.7 (217 ~ 507)	14		800	1800	B:30
VDR-11A(B)-1A3-1A3-13	5.2	(217 ~ 507) 30.6 ~ 51 (435 ~ 725)	5.2 5.2	30.6 ~ 51 (435 ~ 725) 30.6 ~ 51 (435 ~ 725)	(2030) 143 (2030)				

Note: 1. The discharge rate is the value at 1800min<sup>-1</sup> no-load.

- 2. In addition to this model, the VDC Series (maximum working pressure: 2030 psi) high-pressure variable vane pump is also available. See page B-25 for more information.
- 3. The change from VDR-1 Series design number 11 to design number 12 represents a change in the shaft key width from .125 in. to .187 in. This means that when using a .125 in. key coupling, you need to use a stepped key (VD31J-302000) or add a new key groove at .187 in.
- 4. There is no change in the mounting method with the change from the VDR-1 size design number 12 and VDR-2 design number 11 to design number 13.


### **Understanding Model Numbers**





Variable Discharge Rate Vane Pump

- 3 Discharge Volume Adjustment
  The discharge flow rate is decreased by clockwise (rightward) rotation of the discharge rate adjusting screw, and increased by counterclockwise (leftward) rotation. Loosen the lock nut before making adjustments. After adjustment is complete, re-tighten the lock nut. The graph below provides general guidelines for the relationship between the rotation angle of the flow rate adjusting screw and the no-load discharge rate.
  However:
  - Q: Flow rate gpm =  $\frac{\text{in}^3 \text{ x rpm}}{231}$
- 4 Pressure Adjustment
  Pressure is decreased by clockwise
  (rightward) rotation of the discharge rate
  adjusting screw, and increased by
  counterclockwise (leftward) rotation.



- 5 Factory Default P-Q Settings (Standard Model)
  - Flow Rate Setting = Maximum flow rate for model as indicated in the catalog

**Double Pump** 

- Pressure Setting = Pressure shown in table to the right
- 6 Initial Operation

Before operating the pump for the first time, put the pump discharge side into the no-load state and then repeatedly start and stop the motor to bleed all air from inside the pump and the suction piping. After confirming that the pump is discharging oil, continue the no-load operation for at least 10 minutes to discharge all the air from the circuit. Provide an air bleed valve in circuits where it is difficult to bleed air before startup.

- 7 Sub Plate
  - When a sub plate is required, specify a sub-plate type from the table in the installation dimension diagram.
- R&O type and wear-resistant type of ISO VG32 to 68 or equivalent (viscosity index of at least 90). Use hydraulic operating

Note) The values indicated above are at maximum pump discharge volume with the flow volume adjusting screw at the 0° position.

The broken line shows the flow volume adjustment range lower limit value.

#### Factory Default Pressure Settings kgf/cm² (psi)

1: 20.4 (290) 2: 35.7 (507) 3: 30.6 (435)

fluid that provides kinematic viscosity during operation in the range of 20 to 150 centistokes.

- The operating temperature range is 59 to 140°F. When the oil temperature at startup is 59°F or less, perform a warm-up operation at low pressure and low speed until the oil temperature reaches 59°F. Use the pump in an area where the temperature is within the range of 32 to 140°F.
- 10 Suction pressure is 4.35 psi, and the suction port flow rate should be to greater than 6 ft/sec.


- 11 Avoid pulley, gear, and other drive systems that impart a radial or thrust load on the end of the pump shaft. Mount the pump so its pump shaft is oriented horizontally.
- 12 Provide a suction strainer with a filtering grade of about 100µm (150 mesh). For the return line to the tank, use a 10µm line filter.
- 13 Manage hydraulic operating fluid so contamination is maintained at class NAS10 or lower. Take care to avoid contamination with water and other foreign matter, and watch out for

- discoloration.
- Whitish fluid indicates that air has contaminated the fluid, and brownish fluid indicates the fluid is dirty.
- 14 At startup, repeat the inching operation (start-stop) to bleed air from the pump and pipes.
- 15 Equip an air bleed valve in circuits where it is difficult to bleed air before startup. See page C-13 for more information.
- 16 To ensure proper lubrication of the pump's rubbing surfaces, supply oil to the interior of the pump before

- starting operation.
- 17 When centering the pump shaft, eccentricity with the motor shaft should be no greater than 0.05mm. Use a pump mounting base of sufficient rigidity. The angle error should be no greater than 1°.


### **Installation Dimension Drawings**

VDR-1A-\*-13 (Foot Mounting)





Note: Sub-plate is not provided. Must be provided separately if needed.


Sub Plate Number	Weight Ib	Н	h	А	В	С	Y	Z	Motor Output hp (4P)
MVD-1-115-10	8	115	61.1	188	32	26	1/2	3/8	1 to 2
MVD-1-115Y-10	°	113	01.1	100	32	20	3/4	1/2	1102
MVD-1-135-10	10.8	135	81.1	208	40	40	1/2	3/8	2+- 5
MVD-1-135Y-10	10.8	133	81.1	208	40	40	3/4	1/2	3 to 5



#### VDR-1B-\*-13 (Flange Mounting) Not SAE Mount









#### VDR-11A-\*-13 (Foot Mounting) 2-pressure adjusting 75.5 113 32.5 65 screw 2-flow rate adjusting screw 21.15-0.2 \$19.05-0 4.76 +0.024 +0.012 73 53.9-0.1 120.6 ±0.35 M10 mounting bolt 81.1 2 to 4 2 77 OUT Z BSPT 8 OUT Z 38 42 (Opposite side) **BSPT** IN 1 BSPT DR 3/8 BSPT (Opposite side) (Opposite side) 2- Φ20x12 counterbore $\varphi$ 13 holes DR 3/8 BSPT (Plug closed before shipping) Note: Sub-plate is not provided. Must be provided separately if needed. L85 L58 Applicable Pump Model Weight Sub Plate Number lbs No. MVD-11-135-10 3/8 VDR-11A-1A\*-1A\*-13 10.3 MVD-11-135X-10 1/2 IN 1 BSPT Plug closed before shipping


#### VDR-11B-\*-\*-13 (Flange Mounting) Not SAE Mount






## **Cross-sectional Drawing**

VDR-1A-\*-13 VDR-2A-\*-13





#### List of Sealing Parts


Part	Applicable Pump Model No.	VDR-1A-*-13	3	VDR-2A-*-13			
No.	Seal Kit Number	VDAS-101A0	0	VDAS-102A00			
110.	Part Name	Part Number	Q'ty	Part Number	Q'ty		
20	Packing	VD32J-101000	1	VD32J-102000	1		
21	Square ring	VD33J-101000	1	1A-G45	1		
29	Oil seal	ISRD-204010	1	ISP-284811	1		
31	0-ring	1A-P20	2	1A-G30	2		
32	0-ring	1A-P10A	1	1A-P12	1		
33	0-ring	1A-P12	1	1A-P14	1		
34	0-ring	1A-P5	1	1A-P9	1		
35	O-ring	1A-G70	1	1A-G100	1		

Note: 1. Oil seals are manufactured by Nippon Oil Seal Industry Co. Ltd. (NOK) 2. O-ring 1A.\*\* refers to JIS B2401-1A-\*\*.

3. For VDR-\*B-\*-13, the seal kit number becomes VDBS-10\*B00, without the 31 and 32 O-rings.

Part No.	Part Name	Part No.	Part Name	Part No.	Part Name
1	Body	15	Shim	29	Oil seal
2	Cover	16	Retainer	30	Snap ring
3	Cover	17	Spring	31	0-ring
4	Cover	18	Spring	32	0-ring
5	Shaft	19	Key	33	0-ring
6	Piston	20	Packing	34	0-ring
7	Ring	21	Square ring (0-ring)	35	0-ring
8	Vane	22	Needle	36	Nut
9	Plate (S)	23	Screw	37	Screw
10	Plate (H)	24	Screw	38	Screw
11	Plate	25	Nut	39	Screw
12	Holder	26	Pin	40	Screw
13	Holder	27	Pin	41	Nameplate
14	Shim	28	Bearing		

#### VDR-11A-\*-13



#### List of Sealing Parts

Part No.	Applicable Pump Model No.	VDR-11A-*-*-13		
	Seal Kit Number	VDAS-111A00		
	Part Name	Part Number	Q'ty	
24	Packing	VD32J-101000	2	
25	Square ring	VD33J-101000	2	
34	Oil seal	ISRD-204010	1	
37	0-ring	1A-P20	4	
38	0-ring	1A-P10A	2	
39	0-ring	1A-P12	2	
40	0-ring	1A-P5	2	
41	0-ring	1A-G70	2	

Part No.	Part Name	Part No.	Part Name	Part No.	Part Name
1	Body	11	Plate (S)	21	Spring
2	Body	12	Plate (H)	22	Key
3	Cover	13	Plate	23	Key
4	Cover	14	Holder	24	Packing
5	Cover	15	Holder	25	Square ring
6	Shaft	16	Shim	26	Needle
7	Piston	17	Shim	27	Screw
8	Rotor	18	Retainer	28	Screw
9	Ring	19	Spring	29	Nut
10	Vane	20	Spring	30	Pin
	I		I		l


Note: 1. Oil seals are manufactured by Nippon Oil Seal Industry Co. Ltd. (NOK).
2. O-ring 1A-\*\* refers to JIS B2401-1A-\*\*.
3. For VDR-11B-\*-\*-13, the seal kit number becomes VDBS-111B00, without the 37 and 38 O-rings.

Part No.	Part Name
31	Pin
32	Pin
33	Bearing
34	Oil seal
35	Snap ring
36	Nut
37	O-ring
38	O-ring
39	O-ring
40	O-ring
41	O-ring
42	Screw
43	Screw
44	Screw
45	Screw
46	Screw
47	Nameplate

#### **Performance Curves**

(CE mark standard compliant)


**Understanding Model Numbers** 



#### **Specifications**

Model No.	Maximum Working Pressure kgf/cm² (psi)	Maximum Flow Rate gpm		
Wiodel IVO.		50Hz	60Hz	
UVD- 1A	61.2 (870)	5.5	6.6	
UVD- 2A	51.0 (725)	10	11.8	
UVD- 11A	51.0 (725)	5.5	6.5-6.6	

#### **Motor Selection Curves**



\*Select a uni-pump that has a pressure and flow rate that is within the range of the drive so that the drive will not overload.

#### Selecting a motor


The area under a motor output curve in the graph to the left is the operating range for that motor under the rated output for that motor.

#### Example:

To find the motor that can produce pressure of 507 psi and a discharge rate of 5.5 gpm.

#### Selection Process:

Since the intersection of the two broken lines from a pressure of 507 psi and discharge rate of 5.5 gpm intersect in the area under the 3 hp curve, it means that a 3 hp motor should be used. In the case of a double pump configuration, select a motor that is larger than the total power required by both pumps.




Motor Dimensions mm								Frame	Output	Weight													
Uni-pump	Α	IL	С	D	Е	F	G	Н	J	L	М	N	S×T	KD	KL	0	No.	No. hp (4poles)	lbs				
UVD-1A-A1-0.75-4-30	133	105	80	170	62.5	50	4.5	165	35	238	165	130	18 × 10	σ27	157	27.5	80M	1	50				
UVD-1A-A2-0.75-4-30	133	133	133	133	133	103	00	110	02.5	30	4.5	100	30	230	100	130	10 ^ 10	ΨΖΙ	137	21.5	OUW	1	30
UVD-1A-A2-1.5-4-30	143	118.5	90	198	70	62.5	10	190	40	261.5	176	150	12 × 10	σ27	159	_	90L	2	53				
UVD-1A-A3-1.5-4-30	143	110.5	30	130	10	02.5	10	130	40	201.5	110	130	12 " 10	ΨΖΙ	133		301	4	33				
UVD-1A-A3-2.2-4-30	157.5	133	100	198	80	70	12	200	40	290.5	200	168	14 × 12	φ27	159	-	100L	3	64				

- No hanger.

  1. Standard drive motor is the fully enclosed fan-cooled B type.
- 2.Standard voltage for drive motor is 200 VAC, 50/60 Hz or 220 VAC, 60 Hz.
- 3.Standard terminal box is B terminal (right side viewed from pump).
  4.See page A-21 for the characteristics of the drive motor for the unipump (domestic standard 3 rating).

#### UVD-2A



	Motor Dimensions mm											Frame		Weight													
Uni-pump A		ΙL	С	D	Е	F	G	Н	-1	J	L	М	N	S×T	KD	KL	0		hp (4poles)	lbs							
UVD-2A-A1-1.5-4-30	143	118.5	90	198	70	62.5	10	190	_	40	261.5	176	150	12 × 10	φ27	159		90L	2	84							
UVD-2A-A2-1.5-4-30	143	143	143	143	143	143	143	143	110.5	90	190	10	02.5	10	190		40	201.5	1/0	130	12 ^ 10	ΨΖΙ	109		90L		04
UVD-2A-A2-2.2-4-30	157.5	133	100	198	80	70	12	200	_	40	290.5	200	168	14 × 12	σ27	159	_	100L	3	95							
UVD-2A-A3-2.2-4-30	137.3	133	100	190	00	10	12	200		40	290.5	200	100	14 ^ 12	ΨΖΙ	109		1001	3	95							
UVD-2A-A2-3.7-4-30	186	140	112	214	95	70	12		261	40	326	220	168	14 × 12	φ27	166		112M	5	108							
UVD-2A-A3-3.7-4-30	100	140	112	214	95	10	12		201	40	320	220	100	14 ^ 12	ΨΖΙ	100		112W	5	108							

- 2 to 3 hp model does not have hangers.

- 2 to 3 np model does not have hargers.


  1.Standard drive motor is the fully enclosed fan-cooled B type.

  2.Standard voltage for drive motor is 200 VAC, 50/60 Hz or 220 VAC, 60 Hz.

  3.Standard terminal box is B terminal (right side viewed from pump).

  4.See page A-21 for the characteristics of the drive motor for the unipump (domestic standard 3 rating).

#### UVD-11A



Uni-pump	Motor Dimensions mm								Frame	n hp	Weight														
Oni-pamp	A	IL	С	D	Е	F	G	Н	1	J	L	М	N	S×T	KD	KL	0	No.	(4poles)	lbs					
UVD-11A-A1-A1-1.5-4-30																									
UVD-11A-A1-A2-1.5-4-30						62.5	10																		
UVD-11A-A1-A3-1.5-4-30	143	118.5	90	198	70			190		40	261.5	176	150	12 × 10	φ27	159	_	90L	2	66					
UVD-11A-A2-A2-1.5-4-30	143	118.5	90	199	10	02.5	10	190		40	201.5	1/0	100	12 ^ 10	ΨΖΙ	159		301	4	00					
UVD-11A-A2-A3-1.5-4-30																									
UVD-11A-A3-A3-1.5-4-30																									
UVD-11A-A1-A2-2.2-4-30																									
UVD-11A-A1-A3-2.2-4-30																									
UVD-11A-A2-A2-2.2-4-30	157.5	133	133	100	198	80	70	12	200	0 -	40	10 290.5	90.5 200	168	14 × 12	φ27 159	159	_	100L	3	77				
UVD-11A-A2-A3-2.2-4-30																									
UVD-11A-A3-A3-2.2-4-30																									
UVD-11A-A1-A3-3.7-4-30																									
UVD-11A-A2-A2-3.7-4-30																			_						
UVD-11A-A2-A3-3.7-4-30	186	140	112	214	95	70	12	_	261	40	326	220	168	14 × 12	φ27	166	_	112M	5	90					
UVD-11A-A3-A3-3.7-4-30																									

No hanger on 2 and 3 hp models.

- Standard drive motor is the fully enclosed fan-cooled B type.
   Standard voltage for drive motor is 200 VAC, 50/60 Hz or 220 VAC, 60 Hz.
   Standard terminal box is B terminal (right side viewed from pump).
   See page A-21 for the characteristics of the drive motor for the unipump (domestic standard 3 rating).



# VDC Series High Pressure Type Variable Volume Vane Pump

7.9 to 31.7 gpm 2000 psi





#### **Features**

# Highly efficient and stable high-pressure operation

Innovative pressure control and pressure balance mechanisms combine with an original 3-point ring support system dramatically improves high-pressure operation. The result is outstanding performance at high pressures up to 2000 psi.

#### Low vibration and noise

A number of innovative new mechanisms are adopted to minimize vibration and noise. In particular, a 3-point support system is used for the control piston and bias piston to increase ring

stability. This minimizes ring vibration and delivers quiet operation.

# Outstanding response, high-precision operation

An innovative new ring stopper eliminates excessive ring displacement and improves response. The result is high precision operation at all times, including during starts, stops, and load changes.

# Precise characteristics for a stable discharge rate

A revolutionary new pressure compensator type pressure control mechanism

ensures a highly stable fixed discharge rate, even in the high pressure range.

# High efficiency operation with minimal power loss

New mechanical innovations minimize power loss, especially at full cutoff.

# Simplified maintenance and handling

Pressure adjusting and discharge rate adjusting mechanisms are located on the same side of the pump for simplified maintenance and handling.

## **Specifications**

#### Single Pump

Model No.		Capacity	No-load Disch	arge Rate gpm	Pressure Adjustment Range	Allowable Peak Pressure	Revolution Speed		Weight	
Foot Mounting	Flange Mounting	in³/rev	1500min <sup>-1</sup>	1800min <sup>-1</sup>	kgf/cm (psi)	kgf/cm (psi)	Min.	Max.	lbs	
VDC-1A-1A2-*20 VDC-1A-1A3-*20	VDC-1B-1A2-*20/35 VDC-1B-1A3-*20/35	1.0	6.6	7.9	15.3 to 35.7 (217 to 507) 20.4 to 71.4 (290 to 1000)	143 (2000)	800	1800	21	
VDC-1A-1A4-*20 VDC-1A-1A5-*20	VDC-1B-1A4-*20/35 VDC-1B-1A5-*20/35	1.0	0.0	7.5	51 to 107 (725 to 1500) 71.4 to 143 (1000 to 2000)	214 (3000)	000	1000	21	
VDC-1A-2A2-*20 VDC-1A-2A3-*20	VDC-1B-2A2-*20/35 VDC-1B-2A3-*20/35	1.3	8.7	10.5	15.3 to 35.7 (217 to 507) 20.4 to 71.4 (290 to 1000)	143 (2000)	800	1800	21	
VDC-2A-1A2-*20 VDC-2A-1A3-*20	VDC-2B-1A2-*20/35 VDC-2B-1A3-*20/35	1.8	11.8	14.2	15.3 to 35.7 (217 to 507) 20.4 to 71.4 (290 to 1000)	143 (2000)	800	1800	55	
VDC-2A-1A4-*20 VDC-2A-1A5-*20	VDC-2B-1A4-*20/35 VDC-2B-1A5-*20/35	1.0	11.0	14.2	51 to 107 (725 to 1500) 71.4 to 143 (1000 to 2000)	214 (3000)	800	1800		
VDC-2A-2A2-*20 VDC-2A-2A3-*20	VDC-2B-2A2-*20/35 VDC-2B-2A3-*20/35	2.3	15.3	18.4	15.3 to 35.7 (217 to 507) 20.4 to 71.4 (290 to 1000)	143 (2000)	800	1800	55	
VDC-3A-1A2-*20 VDC-3A-1A3-*20	VDC-3B-1A2-*20 VDC-3B-1A3-*20	4.0	26.4	31.7	15.3 to 35.7 (217 to 507) 20.4 to 71.4 (290 to 1000)	143 (2000)	800	1800	103	
VDC-3A-1A4-*20 VDC-3A-1A5-*20	VDC-3B-1A4-*20 VDC-3B-1A5-*20	4.0	20.4	31.7	51 to 107 (725 to 1500) 71.4 to 143 (1000 to 2000)	214 (3000)	800	1900	103	

#### **Double Pump**

Model No.		Vent Side	е		Shaft Sic	le	Revol	lution	
Foot Mounting Type	Discharge Rate gpm		Pressure Adjustment Range	Discharge	Rate gpm	Pressure Adjustment Range		Speed min <sup>-1</sup>	
(Flange Mounting)	1800min <sup>-1</sup>	1500min <sup>-1</sup>	kgf/cm (psi)	1800min <sup>-1</sup>	1500min <sup>-1</sup>	kgf/cm (psi)	Min.	Max.	lbs
VDC-11A(B)-2A3-2A*20/35	10.5	8.7	20.4 to 71.4	10.5	8.7	20.4 to 71.4 (290 to 1000)	800	1800	Type A 59
VDC-11A(B)-2A3-1A*20/35			(290 to 1000)	7.9	6.6	71.4 to 143 (1000 to 2000)			Type B 44
VDC-12A(B)-2A3-2A*20/35			20.4 to 71.4	18.4	15.3	20.4 to 71.4 (290 to 1000)			
VDC-12A(B)-2A3-1A*20/35	10.5	8.7	(290 to 1000)	14.2	11.8	71.4 to 143 (1000 to 2000)	800	1800	Type A 92
VDC-12A(B)-1A5-2A*20/35	7.9	6.6	71.4 to 143	18.4	15.3	20.4 to 71.4 (290 to 1000) 71.4 to 143 (1000 to 2000)		1800	Type B 77
VDC-12A(B)-1A5-1A*20/35	1.0	0.0	(1000 to 2000)	14.2	11.8	71.4 (0 143 (1000 (0 2000)			
VDC-22A(B)-2A3-2A*20/35	18.4	15.3	20.4 to 71.4	18.4	15.3	20.4 to 71.4 (290 to 1000)	800	1800	Type A 136
VDC-22A(B)-2A3-1A*20/35			(290 to 1000)	17.2	11.8	71.4 to 143 (1000 to 2000)	300	1800	Type B 110
VDC-13A(B)-2A3-1A*20			20.4 to 71.4			20.4 to 71.4 (290 to 1000)			
VDC-13A(B)-2A3-1A*20	10.5	8.7	(290 to 1000)	31.7	26.4	71.4 to 143 (1000 to 2000)	800	1800	Type A 136
VDC-13A(B)-1A5-1A*20	7.9	6.6	71.4 to 143	] 01.7	25.4	20.4 to 71.4 (290 to 1000) 71.4 to 143 (1000 to 2000)		1800	Type B 105
VDC-13A(B)-1A5-1A*20	7.5	0.0	(1000 to 2000)			71.4 (0 145 (1000 (0 2000)			

Note: 1. VDC-3A, VDC-11A, VDC-12A and VDC-13A are foot mounting types, and come with foot mountings.

2. VDC-1A and VDC-2A are sub plate types. Sub plates are not included.


- Handling
- 1 Rotation Direction The direction of rotation is always is clockwise (rightward) when viewed from the shaft side.
- 2 Drain Drain piping must be direct piping up to a point that is below the tank fluid level, and piping should comply with the conditions shown in the table below to ensure that back pressure due to pipe resistance does not exceed 14 psi. When using a pump that has drain ports at two locations, use the drain port that is higher after the pump is installed. In the case of a double pump, run separate pipes from both the shaft side and the head side drains directly connect to the tank, so the drain pipe is below the surface of the oil.
- 3 Discharge Volume Adjustment

Model No.	VDC-1	VDC-2	VDC-3
Pipe Joint	At least	At least	At least
Size	1/4"	1/4"	3/8"
Pipe I.D.	At least	At least	At least
	.29	.29	.37
Pipe Length	1m or less	1m or less	1m or less

The discharge flow rate is decreased by clockwise (rightward) rotation of the discharge rate adjusting screw, and increased by counterclockwise (leftward) rotation.

Loosen the lock nut before making adjustments. After adjustment is complete, re-tighten the lock nut. The graph below provides general guidelines for the relationship between the rotation angle of the flow rate adjusting screw and the no-load discharge rate.

Q: Flow rate gpm = 
$$\frac{\text{in}^3 \text{ x rpm}}{231}$$



#### Note:

The values indicated above are at maximum pump discharge volume with the flow volume adjusting screw at the 0° position.

The broken line shows the flow volume adjustment range lower limit value.

- 4 Pressure Adjustment Pressure is increased by clockwise (rightward) rotation of the discharge rate adjusting screw, and decreased by counterclockwise (leftward) rotation. Loosen the lock nut before making adjustments. After adjustment is complete, re-tighten the lock nut.
- 5 Factory Default P-Q Settings (Standard Model)
  - Flow Rate Setting = Maximum flow rate for model as indicated in the catalog
  - Pressure Setting = Pressure shown in table below
- 6 Thrust Screw and Stopper
  The thrust screw and stopper are
  precision adjusted at the factory during
  assembly. Never touch them.
  See callouts 15/43 and 15/38 in the
  VDC-1A and 2A/3A cross-section
  diagrams on pages B-33 and B-34.
- 7 An unload circuit is required when the motor is started under condition WYE Delta. Contact your agent about the unload circuit.
- Before operation
  Before operating the pump for the first time, put the pump discharge side into the noload state and then repeatedly start and stop the motor to bleed all air from inside the pump and the suction piping. After confirming that the pump is discharging oil, continue the no-load operation for at least 10 minutes to discharge all the air from the circuit. Provide an air bleed valve in circuits where it is difficult to bleed air before startup.
- 9 Sub Plate Use the table below for to specify a sub plate type when one is required.

Factory Default Pressure Settings kgf/cm² (psi)
2: 35.7 (507)
3: 30.6 (435)
4: 5.1 (725)
5: 71.4 (1000)

10 Foot Mounting

For a double pump with VDC-3 foot mounting, the foot mounting kit and pump are sold as a set. When only the mounting feet are required, pump mounting bolts, washers and other parts are sold together as the Foot Mounting Kit.

- See page B-36 for detailed dimensions.

  For the hydraulic operating fluid, use type ISO VG32 or equivalent (viscosity index of at least 90) for pressures of 1000 psi or lower, and type ISO VG68 or equivalent (viscosity index of at least 90) for pressures greater than 1000 psi.
- 12 The operating temperature range is 59 to 140°F. When the oil temperature at startup is 59°F or less, perform a warm-up operation at low pressure until the oil temperature reaches 59°F. Use the pump in an area where the temperature is within the range of 32 to 140°F.
- 13 Suction pressure is 4.35 psi, and the suction port flow rate should be no greater than 6 ft/sec.
- Avoid pulley, gear, and other drive systems that impart a radial or thrust load on the end of the pump shaft. Mount the pump so its pump shaft is oriented horizontally.
- 15 Provide a suction strainer with a filtering grade of about 100μm (150 mesh). For the return line to the tank, use a 10μm line filter.
- Manage hydraulic operating fluid so contamination is maintained at class NAS10 or lower. Take care to avoid contamination with water and other foreign matter, and watch out for discoloration. Whitish fluid indicates that water has contaminated the fluid, and brownish fluid indicates the fluid is dirty.
- 17 Contact your agent about using waterand glycol-based hydraulic operating fluids.
- 18 At startup, repeat the inching operation (start-stop) to bleed air from the pump and pipes.

(Continued on following page)

#### Sub Plate Number


Pump Model No.	Sub Plate Number	Motor (hp)
VDC-1A-1A*-20	MVD-1-115-10	1-2
VDC-1A-1A20	MVD-1-135-10	3 - 5
VDC-1A-2A*-20	MVD-1-115Y-10	1 - 2
VDC-1A-2A "-20	MVD-1-135Y-10	3 - 5
VDC-2A-*A*-20	MVD-2-135-10	3-5
VD0-2A-"A"-20	MVD-2-160-10	7
VDC-2A-2A*-20	MVD-2-160Z-10	7

Note: See pages B-17 and B-18 for detailed dimensions.

- 19 Equip an air bleed valve in circuits where it is difficult to bleed air before startup. See page C-13 for more information.
- 20 To ensure proper lubrication of the pump's rubbing surfaces, supply oil to the interior of the pump before starting operation.
- 21 When centering the pump shaft, eccentricity with the motor shaft should be no greater than 0.001 in.
  Use a pump mounting base of sufficient rigidity. The angle error should be no greater than 1°.


## **Understanding Model Numbers**


#### Single Pump




The ZR-T02-\*-5895\* is the recommended remote control valve. Provide piping to the remote control valve at a pipe volume of 9 cu in or less.


#### **Double Pump**








## **Installation Dimension Drawings**





Code 61 - 1 1/2




#### **Performance Curves** Typical characteristics at hydraulic operating fluid kinematic viscosity of 32 centistokes VDC-1A(B)-2A3-20/35 VDC-1A(B)-1A3-20/35 VDC-2A(B)-2A3-20/35 1800min<sup>-1</sup> Q 1800min<sup>-1</sup> Q 7.9 1800min<sup>-1</sup> 10.5 18.5 1500min 1500min<sup>-1</sup> 6.7 15.8 e rate Q gpm Discharge rate Q gpm සූ 13.2 1.0 hb F.C 10.7 ≒ Lin 5.3 0.8 Discharge 2.6 5.3 5.4 2.6 1.3 1.3 2.7 2.6 DR l<sub>0</sub> 429 571 714 857 1000 571 714 857 1000 429 714 286 429 286 571 143 Discharge pressure P psi Discharge pressure P psi Discharge pressure P psi VDC-2A(B)-1A3-20/35 VDC-3A(B)-1A3-20/35 VDC-1A(B)-1A5-20/35 -1800min<sup>-1</sup> 20.1 1800min<sup>1</sup> 15.8 Q 1500min . 1500min 13.2 26.4 1500min<sup>1</sup> ate 0 gbm 7.5 ₩ 21.1 0 13.4 10.7 Discharge rate Q 5.3 Input Lin hp 9.4 은 rate 8.0 In the line of Lin 15.8 4.0 8.0 Lin 10.5 5.4 2.6 5.3 4 0 2.7 5.2 rate 1.3 2.7 1.3 DR 0 0 0 286 429 571 714 857 1000 429 571 714 2000 1000 1500 Discharge pressure P psi Discharge pressure P ps Discharge pressure P psi VDC-2A(B)-1A5-20/35 VDC-3A(B)-1A5-20/35 1800min-1 15.8 40.2 31.7 1800min<sup>-1</sup> Q 13.2 26.4 33.5 Discharge rate Q gpm 26.8 습 Tate 21.1 21.4 d 18.8 in 16.1 m 13.4 l Ë 20.1 a 10.7 10.5 13.4 8.0 2.6 5.2 6.7 2.7 DR : 1000 1500 2000 1000 1500 2000 Discharge pressure P psi Discharge pressure P psi Axial input at full cutoff VDC-1 VDC-2 VDC-3 2.6 5.3 6.7 hp linput at full cutoff h t at full cutoff h 5.3 4.0 5.6 5.3 Axial input at full cutoff 2.0 1.3 Axial input .67 Axial 507 1000 1500 2000 507 1000 1500 2000 0 507 1000 1500 2000 Discharge pressure P psi Discharge pressure P psi Discharge pressure P psi

#### **Noise Characteristics**










## **Cross-sectional Drawing**

VDC-1A-\*A\*-20 VDC-2A-\*A\*-20







Seal Component Table (VDC-1\*, VDC-2\*)

Part	Applicable Pump Model No.	VDC-1A-*-20	)	VDC-2A-*-2	0
No.	Seal Kit Number	VCBS-101A0	0	VCBS-102A0	0
140.	Part Name	Part Number	Q'ty	Part Number	Q'ty
24	Oil seal	TCV-224211	1	TCN-325211	1
25	0-ring	S85(NOK)	1	1A-G115	1
26	0-ring	AS568-034	1	AS568-150	1
27	0-ring	AS568-026	1	AS568-134	1
28	0-ring	1A-P14	1	1A-P18	1
29	0-ring	1A-P22	1	1A-G35	1
30	0-ring	1A-P20	1	1A-G35	1
31	0-ring	1A-P5	2	1A-P9	2
32	0-ring	1A-P6	4	1A-P7	4
33	0-ring	1A-P25	1	1A-G35	1
34	O-ring	1A-P22	1	1A-G35	1
35	0-ring	1A-P10A	1	1A-P15	1
36	Backup ring	VCB34-101000	1	VCB34-102000	1
37	Backup ring	VCB34-201000	1	VCB34-202000	1
57	O-ring	1A-P14	1	1A-P14	1
58	O-ring	1B-P6(Hs90)	3	1B-P6(Hs90)	3

Note: 3	<ol> <li>Oil seals are</li> </ol>	manufactured b	y Nippon Oil Seal	Industry Co. Ltd. (NOK).	
---------	-----------------------------------	----------------	-------------------	--------------------------	--

<sup>2.</sup> O-ring 1A-\*\* refers to JIS B2401-1A-\*\*.


<sup>3.</sup> For VDR-\*B-\*-20, the seal kit number becomes VDBS-10\*B00, without the 33, 24, and 35 0-rings.

Part No.	Part Name	Part No.	Part Name	Part No.	Part Name
1	Body (1)	21	Holder	41	Screw
2	Body (2)	22	Holder	42	Screw
3	Cover (1)	23	Orifice	43	Screw (stopper)
4	Cover (2)	24	Oil seal	44	Screw
5	Shaft	25	O-ring	45	Plug
6	Ring	26	O-ring	46	Plug
7	Vane	27	O-ring	47	Pole
8	Plate (S)	28	O-ring	48	Nameplate
9	Plate (H)	29	O-ring	49	Valve body
10	Piston (1)	30	O-ring	50	Spool
11	Piston (2)	31	O-ring	51	Holder
12	Bearing	32	O-ring	52	Plunger
13	Bearing	33	O-ring	53	Spring
14	Spring	34	O-ring	54	Retainer
15	Thrust screw	35	O-ring	55	Screw
16	Screw	36	Backup ring	56	Nut
17	Nut	37	Backup ring	57	O-ring
18	Nut	38	Cap	58	O-ring
19	Key	39	Snap ring	59	Plug
20	Pin	40	Screw	60	Plug
	0	17.1		61	Screw

Cartridge Kits: VDC-1 | VCBC-101\*A\* VDC-2 | VCBC-102\*A\*

Includes Items: 5, 6, 7, 8, 9, 19, 20

## **Performance Curves**



#### Seal Component Table (VDC-3\*)

Part	Applicable Pump Model No.	VDC-3A(B)-*-2	20
No.	Seal Kit Number	VCBS-103B0	0
140.	Part Name	Part Number	Q'ty
23	Oil seal	TCN-385811	1
24	0-ring	1A-G130	1
25	0-ring	AS568-154(Hs90)	1
26	0-ring	AS568-151(Hs90)	1
27	0-ring	1A-G40	2
28	0-ring	1A-P22	1
29	0-ring	1A-P9	2
30	0-ring	1A-P7	2
31	0-ring	1A-P7	2
52	O-ring	1A-P14	1
53	O-ring	1B-P6(Hs90)	3

Note: 1. Oil seals are manufactured by Nippon Oil Seal Industry Co. Ltd. (NOK).

2. O-ring 1A-\*\* refers to JIS B2401-1A-\*\*.

Part No.	Part Name	Part No.	Part Name	Part No.	Part Name
Part No.	Part Name	Part No.	Part Name	Part NO.	Part Name
1	Body (1)	20	Pin	39	Screw
2	Body (2)	21	Holder	40	Plug
3	Mounting	22	Orifice	41	Washer
4	Cover (1)	23	Oil seal	42	Nameplate
5	Cover (2)	24	O-ring	43	Pole
6	Shaft	25	O-ring	44	Valve body
7	Ring	26	O-ring	45	Spool
8	Vane	27	O-ring	46	Holder
9	Plate (S)	28	O-ring	47	Plunger
10	Plate (H)	29	O-ring	48	Spring
11	Piston (1)	30	O-ring	49	Retainer
12	Piston (2)	31	O-ring	50	Screw
13	Bearing	32	Сар	51	Nut
14	Spring	33	Snap ring	52	O-ring
15	Thrust screw	34	Screw	53	0-ring
16	Screw	35	Screw	54	Plug
17	Nut	36	Screw	55	Plug
18	Nut	37	Screw	56	Screw
19	Key	38	Screw (stopper)		I


#### **Compensator Kits:**

VDC-1 Thru -3 are same VDC-A2 ZR-G01-A2-1688C -A3 ZR-G01-A3-1688C -A4 ZR-G01-A4-1688C -A5 ZR-G01-A5-1688C P-Remote ZR-G01-P-E1235A

#### Cartridge Kits:

VDC-2-20/35 VCBC-1021A2 (A2,A3) VCBC-1021A4 (A4,A5) VCBC-1022A2 (2A2,2A3) Includes Items: 6, 7, 8, 9, 10, 19, 20

## **VDC Series Double Pump**



Part Name
Body (2)
Body (3)
Shaft (S)
Shaft (H)
Joint
O-ring
O-ring
Screw
Screw
Screw

Note: In the case of a double pump, use single pump parts in addition to the 10 parts listed above.


#### List of Sealing Parts


Part	Part Name	VDC-11A	-*-*-20	VDC-12A	ı-*-*-20	VDC-22A	ı-*-*-20	VDC-13A	N-*-*-20
No.	rarramo	Part Number	Q'ty	Part Number	Q'ty	Part Number	Q'ty	Part Number	Q'ty
6	0-ring			1A-G60	1	1A-G60	1		
7	0-ring	1A-G85	1	1A-G45	1	1A-G60	1	1A-G85	1

Note: 1. See the description of the single pump for seal parts that are not included in the list. 2. O-ring 1A-\*\* refers to JIS B2401-1A-\*\*.


## **Foot Mounting Installation Measurement Chart**

For VDC-11A, VDC-12 and VDC-22 (for double pump)





#### For VDC-3A and VDC-13A



Foot Mounting	Applicable Pump		Access	sories				Dimensio	ons (mm)		
Kit Model No.	Model No.	Bolt	Q'ty	Washer	Q'ty	А	В	С	Е	F	Н
VCM-11-20	VDC-1 (20) VDC-11 (20)	TH-10 × 30	4	WS-B-10	4	171.45	204	107.95	1	95.25	150
VCM-22-20	VDC-2 (20) VDC-12 (20) VDC-22 (20)	TH-12 × 35	4	WS-B-12	4	235	267	139.7	1	127	193
IHM-45-10	VDC-3 (20) VDC-13 (20)	TB-16 × 40	2	WP-16	2	295.3	334	152.4	1	139.7	203


Foot Mounting							Dimensio	ns (mm)							Weight
Kit Model No.	(1)	(J)	K	N	Р	Q	S	Т	U	φD	$\varphi d_{_1}$	$\varphi d_{_{2}}$	$\varphi d_{_3}$	$\varphi d_{_4}$	Ibs
VCM-11-20	66.5	33	18	18	M10	180	32.5	50	90	95.02	22	11		40	14.3
VCM-22-20	84.5	40	20	20	M12	232	44.5	57.5	124	135	22	14		40	26.4
IHM-45-10	104.5	60	25	25	M16	259	44.5	61		127	35	18	181	86	29.7

## **Uni-Pump Specifications**

(CE mark standard compliant)

Single Pump


**Double Pump** 



#### **Specifications**

Model No.	Maximum Working Pressure	Maximum Flow	Rate gpm (A*)	Maximum Flow Rate gpm(2A*)				
Wiodel Wo.	kgf/cm² (psi)	50Hz	60Hz	50Hz	60Hz			
UVC- 1A UVC-11A	71.4 (1015)	6.6	7.9	8.7	10.3			

#### Motor selection curves



\* Select a uni-pump that has a pressure and flow rate that is within the range of the drive so that the drive will not overload.

#### · Selecting a motor

The area under a motor output curve in the graph to the left is the operating range for that motor under the rated output for that motor.

#### Example:


To find the motor that can produce pressure of 507 psi and a discharge rate of 6.6 gpm.

#### Selection Process:

Since the intersection of the two broken lines from a pressure of 507 psi and discharge rate of 6.6 gpm intersect in the area under the 3 hp curve, it means that a 3 hp motor should be used. In the case of a double pump configuration, select a motor that is larger than the total power required by both pumps.

## **Installation Dimension Drawings**

#### UVC-1A




Uni-pump	Uni-pump Motor Dimensions mm													Frame	Output h p	Weight				
	Α	IL	С	D	Е	F	G	Н	- 1	J	L	М	N	S ×T	KD	KL	0	No.	(4 poles)	lbs
UVC-1A-A2-0.75-4-30	133	105	80	170	62.5	50	4.5	165	-	35	238	165	130	18 × 10	φ27	157	27.5	80M	1	53
UVC-1A-A2-1.5-4-30																				
UVC-1A-A3-1.5-4-30	143	118.5	90	198	70	62.5	10	190	-	40	261.5	176	150	12 × 10	φ27	159	-	90L	2	56
UVC-1A-2A2-1.5-4-30																				
UVC-1A-A2-2.2-4-30																				
UVC-1A-A3-2.2-4-30	157.5	133	100	198	80	70	12	200	-	40	290.5	200	168	14 × 12	φ27	159	-	100L	3	67
UVC-1A-2A2-2.2-4-30										1 40	250.5	.50.5								
UVC-1A-A3-3.7-4-30																				
UVC-1A-A4-3.7-4-30	186	140	440	214	95	70	40	_	261	40	200	220	100	14 × 12	σ27	100	_	11011	5	80
UVC-1A-2A2-3.7-4-30	190	140	112	214	95	10	12	_		40 32	326	220	168	14 " 12	ΨΖΙ	166	_	112M	٥	80
UVC-1A-2A3-3.7-4-30	1																			

- 0.75 to 2.2kW model does not have hangers.

- 1. Standard drive motor is the fully enclosed fan-cooled B type.
  2. Standard voltage for drive motor is 200 VAC, 50/60 Hz or 220 VAC, 60 Hz.
  3. Standard terminal box is B terminal (right side viewed from pump).
  4. See page A-21 for the characteristics of the drive motor for the unipump (domestic standard 3 rating).

#### UVC-11A



Uni-pump							Motor	Dime	nsions	mm							Frame	Output h p	Weight									
	Α	IL	С	D	Е	F	G	Н	-1	J	L	М	N	S ×T	KD	KL	No.	(4 poles)	lbs									
UVC-11A-A2-A2-1.5-4-30																												
UVC-11A-A2-A3-1.5-4-30	143	118.5	90	198	70	62.5	10	190	-	40	261.5	176	150	12 × 10	φ27	159	90L	2	79									
UVC-11A-A3-A3-1.5-4-30	1																											
UVC-11A-A2-A2-2.2-4-30																												
UVC-11A-A2-A3-2.2-4-30	157.5	133	100	198	80	70	12	200	_	40	290.5	200	168	14 × 12 φ	φ27	159	100L	3	90									
UVC-11A-A3-A3-2.2-4-30	137.3	133	100	130	00		12	200		10	230.3	200	100		ΨΖΙ	133	1001	3	30									
UVC-11A-2A2-2A2-2.2-4-30																												
UVC-11A-A2-A2-3.7-4-30																												
UVC-11A-A2-A3-3.7-4-30																												
UVC-11A-A3-A3-3.7-4-30	186	140	112	214	95	70	12	-	261	40	40 326	26 220 168	168	14 × 12	φ27	166	112M	5	103									
UVC-11A-2A2-2A2-3.7-4-30	]																											
UVC-11A-2A2-2A3-3.7-4-30	1																											

No hanger on 2 and 3 hp models.

- Standard drive motor is the fully enclosed fan-cooled B type.
   Standard voltage for drive motor is 200 VAC, 50/60 Hz or 220 VAC, 60 Hz.
   Standard terminal box is B terminal (right side viewed from pump).
   See page A-21 for the characteristics of the drive motor for the unipump (domestic standard 3 rating).

## **UVN Series Variable Volume Vane Uni-Pump NSP Uni-Pump**

7.9 to 31.7 gpm 2000 psi





#### **Features**

**Energy efficient high performance** All the performance of a vane pump, right from the low pressure range, is enhanced even further by eliminating the external drain and optimizing the pressure balance, creating a design that generates little heat. The result is a pump that contributes to the energy efficiency of the mother machine, as well as to process precision

#### Lightweight, compact design

The pump and motor are designed for exclusive uni-pump use, making them lightweight, compact, easy to handle, and suitable for a wide range of applications.

#### Low noise. long life


The pump and motor shaft are linked by a joint, which minimizes noise by eliminating the effects of shaft vibration and an off-center shaft. The coupling is constructed to allow constant lubrication, for friction-free long life.

## **Specifications**

Model No.	Pump Capacity	Pressure Adjustment Range	No-load Discha	irge Rate gpm
Widder No.	in <sup>3</sup> /rev	kgf/cm² (psi)	50Hz	60Hz
UVN-1A-0A2- 0.7 1.5		15.3 to 40.8 (217 to 580)		
UVN-1A-0A3- 0.7 1.5	.49	35.7 to 61.2 (507 to 870)	3.1	3.8
UVN-1A-0A4- 0.7 1.5		56.1 to 81.6 (797 to 1160)		
UVN-1A-1A2- 1.5-4-11 2.2		15.3 to 40.8 (217 to 580)		
UVN-1A-1A3- 1.5 2.2	.98	35.7 to 61.2 (507 to 870)	6.3	7.6
UVN-1A-1A4- <sup>1.5</sup> -4-11 <sub>2.2</sub>		56.1 to 81.6 (797 to 1160)		
UVN-1A-2A3- <sup>2.2</sup> -4-11	1.59	(507 to 870)	10	3.7 - 12
UVN-1A-2A4- <sup>2.2</sup> -4-11 <sub>3.7</sub>	1.59	(797 to 1160)	10	5.7 - 12

Note: Contact your agent for combinations other than those noted above.

## **Understanding Model Numbers**




- Handling
- 1. Installation and Piping Precautions 1 Provide a mounting base of sufficient
- rigidity, and install so that the pump shaft is oriented horizontally.
- 2 Make sure the flow rate of the suction piping is no more than 6 ft/s, and that the suction pressure at the pump suction port is in the range of 4.35 psi.
- 3 Drain piping must be direct piping up to a point that is below the tank fluid level, and back pressure due to pipe resistance should not exceed 14 psi.
- Provide a suction strainer with a filtering grade of about 100 µm (150 mesh).
- 2. Running Precautions
- 1 The direction of rotation is clockwise (rightward) when viewed from the motor fan side.
- 2 At startup, repeat the inching operation (start-stop) with the pump discharge side at no-load to bleed air from the pump and suction piping.
- 3 Equip an air bleed valve in circuits where it is difficult to bleed air before

- startup.
- 4 Make sure the maximum peak pressure (setting pressure + surge pressure) during operation does not exceed 2000
- Refer to the following piping conditions as a guideline to keep the maximum peak pressure below 2000 psi. 1/2" x 2 m rubber hose (for 2000 psi) (pipe volume: approximately 15 in<sup>3</sup>)
- 5 Install a relief valve to cut surges in the circuit if pressure exceeds 2000 psi.

- 3. Management of Hydraulic Operating Fluid
- 1 Use only good-quality hydraulic operating fluid with a kinematic viscosity at a fluid temperature of 104°F within the range of (30 to 50cSt).
- 2 Normally, you should use an R&O type and wear-resistant type of ISO VG32 or 46, or equivalent.
- The operating temperature range is 59 to 140°F. When the oil temperature at startup is 59°F or less, perform a warm-up operation at low pressure until the oil temperature reaches 59°F. Use the pump in an area where the temperature is within the range of 50 to 104°F.
- 3 For the return line to the tank, use a 10μm line filter
- 4 Manage hydraulic operating fluid so contamination is maintained at class NAS10 or lower. Take care to avoid contamination with water, foreign matter, and other oil, and watch out for discoloration.

- 4. Setting the Pressure and Discharge Rate
- 1 When adjusting pressure, pressure is increased by clockwise (rightward) rotation of the adjusting screw and decreased by counterclockwise (leftward) rotation. After adjustment is complete, securely tighten the lock nut.
- 2 Turn adjustment screw right to decrease or left to increase volume of discharge. Refer to guidelines in the following diagram for the relationship of the non-load volume of discharge and the position of the flow adjustment screw.



- After adjustment is complete, securely tighten the lock nut.
- 3 Factory Default P-Q Settings (Standard Model)
- Flow Rate Setting = Maximum flow rate for model as indicated in the catalog
- Pressure Setting = Pressure shown in table below

Factory Default Pressure Settings kgf/cm² (psi)
2: 35.7 (507)
3: 51.0 (725)
4: 71.4 (1015)


4 All adjustments, except the flow volume adjusting screw, are precision adjusted at the factory during assembly, do not adjust them. (Do not make any adjustments other than the pressure adjustment screw and the flow rate adjusting screw.)

#### Note:

The values indicated above are at maximum pump discharge volume with the flow volume adjusting screw at the  $0^{\circ}$  position. The broken lines show the flow volume adjustment range lower limit value.

## **Installation Dimensions**

#### Installation method is the same as design number 10D (old design).



	Model No.	Output - Poles							N	lotor D	imens	ions m	nm (m	ım)							Weight
		(hp - 4P)	Α	IL	С	φKD	Е	F	G	Н	J	L	М	N	T×S	R*	φΚΒ	0	Р	-1	lbs
	UVN-1A-*A*-0.7*-4-11	1 - 4	20	90	80	157	62.5	50	2.3	120	72	230	155	120	15 × 10	R5	110	65	130	92	37
	UVN-1A-*A*-1.5*-4-11	2 - 4	20	100	90	175	70	62.5	3.2	128	80	255	170	150	15 × 10	R5	120	65	130	100	46
	UVN-1A-*A*-2.2*-4-11	3 - 4	20	110	100	195	80	70	3.2	138	90	285	200	165	17 × 12	R6	134	65	135	110	57

#### No hanger.

- 1. Standard drive motor is the fully enclosed fan-cooled E type.
- 2. Standard voltage for drive motor is 200 VAC, 50/60 Hz or 220 VAC, 60 Hz.
- 3. Standard terminal box is B terminal (right side viewed from pump).

#### Characteristics of drive motor for Uni-Pump (domestic standard 3 rating)

Output hp	Poles	(Note1). Model Number	Voltage [V]	Frequency [Hz]	Current rating [A]	RPM rating [min <sup>-1</sup> ]	Heat resistance
			230 200 460	50	3.9	1400	
1	4		230 200 460	60	3.6	1690	E
		The drive motor is spe-	230 220 460	60	3.5	1710	
		cialized for the	230 200 460	50	7.1	1390	
2	4		230 200 460	60	6.6	1670	E
		unipump and is not a	230 220 460	60	6.3	1700	
		specific model.	230 200 460	50	9.0	1410	
3	4		230 200 460	60	8.7	1700	E
			230 220 460	60	8.2	1720	

#### **Performance Curves**

UVN-1A-\*A\*-\*-4-11 Operating Fluid : ISO VG 32 Oil temperature : 104°F

Motor selection curves

The area under a motor output curve in the graph below is the operating range for that motor under the rated output for that motor.

Example:


To find the motor that can produce pressure of 507 psi and a discharge rate of 3.1 gpm.


Selection Process

Since the intersection of the two broken lines from a pressure of 507 psi and discharge rate of 3.1 gpm intersect in


the area under the 2 hp curve, it means that a 2 hp motor should be used.

\* Select a uni-pump that has a pressure and flow rate that is within the range of the drive so that the drive will not overload.






Motor Power Loss at Full Cutoff




DR Volume at Full Cutoff




Discharge pressure P kgf/cm² (psi)

FC setting pressure P kgf/cm<sup>2</sup> (psi)

Motor Power Loss at Full Cutoff



DR Volume at Full Cutoff



# NACHi

## **IPH Series IP Pump**

.21 to 7.68 in<sup>3</sup>/rev 4350 psi





This is a new design series in which all pump types are installation compatible with previous designs. Note, however, that there is no longer compatibility for some of the seal components between the IPH-3 and IPH-4 sizes and design numbers 10 and 12.

#### **Features**

**IPH Series IP Pump** 

A patented axial and radial pressure loading system provides high efficiency and generates pressures up to 4350 psi.

Outstanding durability and very long life. A modified involute short-tooth gear enables internal gearing for greatly reduced pulsation and noise, and

exceptionally quiet operation.
A simple structure makes maintenance and inspection easier.

## **Specifications**


Model No.	Capacity	Rated Pressure	Maximum Operating Pressure	Minimum Revolution Speed	Maximum Revolution Speed	Weigl	nt lbs
Model No.	cm <sup>3</sup> /rev (in <sup>3</sup> )	psi	psi	min <sup>-1</sup>	min <sup>-1</sup>	Type A	Type B
IP H-2A(B)- 3.5-11	3.60 (.21)					9.7	5.2
5	5.24 (.31)	3625	4350	600	2000	9.9	5.5
6.5	6.55 (.39)	3025	4330	000	2000	10.1	5.7
8	8.18 (.49)					10.5	6.1
IPH-3A(B) - 10-20	10.2 (.62)	3625	4250			23.1	10.5
13	13.3 (.81)	3025	4350	600	2000	23.5	11.0
16	15.8 (.96)					24.2	11.6
IPH-4A(B) - 20-20	20.7 (1.26					33.5	20.9
25	25.7 (1.56)	3625	4350	500	2000	34.6	22.0
32	32.3 (1.97)					35.7	23.1
IPH-5A(B)- 40-21(11)	40.8 (2.48)					70.5	41.8
50	50.3 (3.06)	3625	4350	400	2000	72.7	44.1
64	63.9 (3.89)					74.9	46.3
IPH-6A(B)- 80-21(11)	81.3 (4.96)					136.7	85.9
100	101.6 (6.19)	3625	4350	300	2000	141.1	90.4
125	125.9 (7.68)					145.5	94.8

#### Note:

- 1. Suction Pressure: 3.6 psi.
- 2. Maximum working pressure shown here is the pressure limit when there are frequent pressure changes.
- 3. Avoid installation with the suction port towards the bottom of the pump.
- 4. Specify using the model number format shown below when pipe flanges are required.
- Handling
- 1 For the hydraulic operating fluid, use an R&O type and wear-resistant type of ISO VG32 to 68 or equivalent (viscosity index of at least 90). Use hydraulic operating fluid that provides kinematic viscosity during operation in the range of 20 to 150 centistokes.
- 2 The operating temperature range is 40 to 149°F. When the oil temperature at
- startup is 40°F or less, perform a warm-up operation at low pressure until the oil temperature reaches 40°F. Use the pump in an area where the temperature is within the range of 32 to 140°F.
- 3 Suction pressure 3.6 psi, and the suction port flow rate should be to greater than 5 ft/sec.
- 4 Avoid pulley, gear, and other drive systems that impart a radial or thrust load on the end of the pump shaft.
- 5 Mount the hydraulic pump so its pump shaft is oriented horizontally. Provide a suction strainer with a filtering grade of about 100µm (150 mesh). For the return line to the tank, use a 10µm line filter.
- 6 Manage hydraulic operating fluid so contamination is maintained at class NAS10 or lower. Take care to avoid contamination with water and other foreign matter, and watch out for discoloration. Whitish fluid indicates that air has contaminated the fluid, and brownish fluid indicates the fluid is dirty.

(continued on following page)

## **Understanding Model Numbers**



Catalog 1501

- 7 Operate within the RPM range in the catalog for the minimum RPM of the pump. Unload the pump's load pressure to operate at variable speeds. Condition of inflow piping must produces as little inflow load pressure as possible to minimize effect of cavitation.
- 8 When using water- or glycol-based hydraulic operating fluid, refer to page 0-3 for details on applicable models
- of hydraulic pumps.
- 9 At startup, repeat the inching operation (start-stop) to bleed air from the pump and pipes.
- 10 Equip an air bleed valve in circuits where it is difficult to bleed air before startup. See page C-13 for more information.
- 11 To ensure proper lubrication of the pump's rubbing surfaces, supply oil to
- the interior of the pump before starting operation.
- 12 When centering the pump shaft, eccentricity with the motor shaft should be no greater than 0.001 in. Use a pump mounting base of sufficient rigidity. The angle error should be no greater than 1°.
- 13 Contact your agent for information about engines.

#### Discharge Rate and Required Input for Each Pump Speed

Speed	Pressure psi		[	Discharge	Rate gpm					Required	Input hp		
Speed	Model No.	100	1015	2030	3045	3625	4350	100	1015	2030	3045	3625	4350
	IPH-2A(B)- 3.5-11	1.1	1.1	1.0	1.0	1.0	1.0	.14	.68	1.6	2.4	2.8	3.5
	5	1.6	1.6	1.5	1.5	1.5	1.4	.20	1.2	2.3	3.5	4.1	5.0
	6.5	2.0	2.0	1.9	1.9	1.8	1.8	.25	1.5	2.9	4.3	5.1	6.2
	8	2.5	2.5	2.4	2.4	2.3	2.3	.30	1.9	3.6	5.3	6.3	7.6
	IPH-3A(B)- 10-20	3.2	3.1	3.0	3.0	2.9	2.9	.40	2.4	4.3	6.6	7.9	9.6
	13	4.2	4.2	4.0	3.9	3.9	3.8	.52	3.1	5.7	8.6	10.1	12.4
	16	4.9	4.8	4.8	4.7	4.6	4.5	.60	3.7	6.8	10.2	12	14.8
1200 min <sup>-1</sup>	IPH-4A(B)- 20-20 25 32	6.5 8.1 10.2	6.7 8.0 10.0	6.28 7.8 9.8	6.1 7.7 9.7	6.1 7.6 9.5	6.0 7.5 9.4	.83 1.0 1.2	5.0 6.1 7.5	8.9 11.0 13.9	13.2 16.4 20.7	15.8 19.7 24.6	19.0 23.4 29.5
	IPH-5A(B)- 40-21(11)	12.9	12.6	12.4	12.1	12.0	11.8	1.6	9.9	17.2	26.1	30.9	38.0
	50	15.9	15.6	15.4	15.1	14.9	14.7	1.9	11.9	21.7	32.1	38.3	45.9
	64	20.2	19.8	19.5	19.2	19.0	18.8	2.4	15.0	27.6	40.9	48.6	58.3
	IPH-6A(B)- 80-21(11)	25.7	25.2	24.7	24.2	24.0	29.8	3.2	19.1	35.1	51.8	61.9	75.2
	100	32.2	31.6	31.0	30.5	30.2	32.2	3.9	23.4	43.3	64.9	77.3	92.7
	125	39.8	39.2	38.5	37.8	37.4	37.0	4.8	28.8	53.7	86.5	96.0	115.1
	IPH-2A(B)- 3.5-11	1.7	1.6	1.6	1.5	1.5	1.5	.22	1.5	2.7	3.9	4.6	5.5
	5	2.4	2.4	2.3	2.3	2.2	2.2	.32	1.9	3.5	4.6	6.1	7.5
	6.5	3.0	3.0	2.9	2.9	2.8	2.8	.40	2.3	4.3	6.5	7.6	9.2
	8	3.8	3.8	3.7	3.6	3.5	3.5	.49	2.9	5.4	8.1	9.4	11.4
	IPH-3A(B)- 10-20	4.8	4.7	4.6	4.5	4.5	4.4	.65	3.8	6.7	10.0	11.9	14.4
	13	6.3	6.2	6.1	5.9	5.9	5.8	.83	4.9	8.8	12.9	15.1	18.6
	16	7.3	7.3	7.2	7.1	7.0	6.9	.96	5.7	10.4	15.2	18.1	22.1
1800 min <sup>-1</sup>	IPH-4A(B)- 20-20 25 32	9.8 12.2 15.3	9.6 12.0 15.1	9.5 11.8 14.9	9.3 11.7 14.6	9.2 11.5 14.5	9.1 11.4 14.3	1.3 1.6 1.9	7.5 9.1 11.3	13.4 16.6 20.9	19.9 24.8 30.9	23.6 29.0 36.8	28.4 35.2 44.2
	IPH-5A(B)- 40-21(11)	19.3	19.0	18.7	18.4	18.2	17.9	2.6	15.6	27.0	40.2	47.7	58.6
	50	23.9	23.5	23.2	22.8	22.6	22.4	3.1	18.9	33.0	49.4	58.7	70.5
	64	30.3	29.9	29.4	29.0	28.8	28.5	3.9	23.6	42.3	62.7	74.6	89.7
	IPH-6A(B)- 80-21(11)	38.6	37.9	37.3	36.7	36.3	35.8	5.2	30.0	53.9	79.9	95.0	115
	100	46.2	47.6	46.9	46.2	45.8	45.3	6.3	37.1	67.4	99.7	118	142
	125	59.8	58.9	58.1	57.3	56.8	56.1	7.4	45.3	83.4	123.7	147	176

Note: Values in the table are general values at an operating fluid viscosity of 46 centistokes. Use the values when selecting the model for your needs.

#### Parts for IPH Pump (Standard)

ard)	Seal Kit	Najimi 3 Parts Set*	Radial Piston Kit**	Axial Plate Kit***
Single Pump	Mineral Oil/ Water Glycoloi	Mineral Oil	Mineral Oil	Mineral Oil
IPH-2B-***-(L)-11	IHAS-2S2***-10	FZD-7004-***	IHP-2-***-10	IHQ-2-10
IPH-3B-**-(L)-20	IHAS-2S30**-20	FZD-7004-0**	IHP-3-0**-10	IHQ-3-10
IPH-4B-**-(L)-20	IHAS-2S40**-30	FZD-7004-0**	IHP-4-0**-10	IHQ-4-10
IPH-5B-**-(L)-11	IHAS-2S50**-10	FZD-7004-0**	IHP-5-0**-10	IHQ-5-10
IPH-6B-***-(L)-11	IHAS-2S6***-10	FZD-7004-***	IHP-6-***-10	IHQ-6-10


\*Najimi set includes: Stopper-pin, axial plate-1, axial plate-2, feeler piece, axial backup ring, O-ring; \*\*Radial Piston Kit includes: Radial piston, radial backup ring, backup ring, O-ring and washer \*\*\*Axial Plate Kit includes: Axial plate-1, axial plate-2, axial backup ring and O-ring

	Head (Rear)	Side Pump	Shaft Sid	e Pump
Double Pump	Pump Model	Seal Kit	Pump Model	Seal Kit
IPH-22B-***-(L)-11	IPH-2H-***-(L)-11	IHAS-2H2***-10	IPH-2S-***-(L)-11	IHAS-2S2***-10
IPH-23B-***-(L)-11	IPH-2H-***-(L)-11	IHAS-2H2***-10	IPH-3S-**-(L)-11	IHAS-2S30**-20
IPH-24B-***-(L)-11	IPH-2H-***-(L)-11	IHAS-2H2***-10	IPH-4S-**-H(L)-11	IHAS-2S40**-30
IPH-25B-***-**-(L)-11	IPH-2H-***-(L)-11	IHAS-2H2***-10	IPH-5S-**-H(L)-11	IHAS-2S50**-10
IPH-26B-***-**-(L)-11	IPH-2H-***-(L)-11	IHAS-2H2***-10	IPH-6S-***-H(L)-11	IHAS-2S6***-10
IPH-33B-**-**-(L)-11	IPH-3H-**-(L)-11	IHAS-2H30**-20	IPH-3S-**-(L)-11	IHAS-2S30**-20
IPH-34B-**-**-(L)-11	IPH-3H-**-(L)-11	IHAS-2H30**-20	IPH-4S-**-(L)S-11	IHAS-2S40**-30
IPH-35B-**-**-(L)-11	IPH-3H-**-(L)-11	IHAS-2H30**-20	IPH-5S-**-H(L)-11	IHAS-2S50**-10
IPH-36B-**-***-(L)-11	IPH-3H-**-(L)-11	IHAS-2H30**-20	IPH-6S-***-H(L)-11	IHAS-2S6***-10
IPH-44B-**-**-(L)-11	IPH-4H-**-(L)-11	IHAS-2H40**-30	IPH-4S-**-(L)S-11	IHAS-2S40**-30
IPH-45B-**-**-(L)-11	IPH-4H-**-(L)-11	IHAS-2H40**-30	IPH-5S-**-(L)S-11	IHAS-2S50**-10
IPH-46B-**-**-(L)-11	IPH-4H-**-(L)-11	IHAS-2H40**-30	IPH-6S-***-H(L)-11	IHAS-2S6***-10
IPH-55B-**-**-(L)-11	IPH-5H-**-(L)-11	IHAS-2H50**-10	IPH-5S-**-F(L)-11	IHAS-2S50**-10
IPH-56B-**-**-(L)-11	IPH-5H-**-(L)-11	IHAS-2H50**-10	IPH-6S-***-F(L)-11	IHAS-2S6***-10
IPH-66B-***-(L)-11	IPH-6H-***-(L)-11	IHAS-2H6***-10	IPH-6S-***-F(L)-11	IHAS-2S6***-10


 $<sup>{\</sup>rm *Regarding\ Shaft\ side\ pump:\ H,\ F\ means\ the\ way\ of\ the\ bolt\ -\ H:\ 2-Bolt\ type,\ F:\ 4-Bolt\ type}$ 

## **Installation Dimension Drawings**

IPH-2A-\*-11 (Foot Mounting, Clockwise Rotation)




IPH-2B-\*-11 (Flange Mounting, Clockwise Rotation) SAE A Mount




Model No.	Dimensions (mm)				
Wodel No.	LA	LB	φD		
IPH-2*-3.5-*-11	107	51.0	8.9		
IPH-2*-5 -*-11	112	53.5	11		
IPH-2*-6.5-*-11	116	55.5	12		
IPH-2*-8 -*-11	121	58.0	13		

Note: IPH-2A (B)-\*-L-11 (foot mounting/flange mounting, counterclockwise rotation) are the mirror image of the drawings shown above. In the case the suction port flange is facing upwards, the discharge port flange is positioned to the right when viewed from the shaft side.






IPH-3B-\*-20 (Flange Mounting, Clockwise Rotation) SAE B Mount 3/4 Shaft




Model No.	Dimensions (mm)				
Woder No.	LA	LB	φD		
IPH-3*-10-*-20	128.5	60.0	14		
IPH-3*-13-*-20	134.5	63.0	17		
IPH-3*-16-*-20	139.5	65.5	18		

Note: IPH-3A (B)-\*-L-20 (foot mounting/flange mounting, counterclockwise rotation) are the mirror image of the drawings shown above. In the case the suction port flange is facing upwards, the discharge port flange is positioned to the right when viewed from the shaft side.






IPH-4B-\*-20 (Flange Mounting, Clockwise Rotation) SAE BB Mount




Model No.	Dim	ensions (r	nm)
Woder No.	LA	LB	φD
IPH-4*-20-*-20	164.5	71	18
IPH-4*-25-*-20	170.5	74	20
IPH-4*-32-*-20	178.5	78	24


Note: IPH-4A (B)-\*-L-20 (foot mounting/flange mounting, counterclockwise rotation) are the mirror image of the drawings shown above. In the case the suction port flange is facing upwards, the discharge port flange is positioned to the right when viewed from the shaft side.


## IPH-5A-\*-21 (Foot Mounting, Clockwise Rotation)





IPH-5B-\*-11 (Flange Mounting, Clockwise Rotation) SAE C Mount







Model No.	Dimensions (mm)					
Wiodol No.	LA	LB	φD			
IPH-5*-40-*-21 (11)	201.5	91.0	24			
IPH-5*-50-*-21 (11)	208.5	94.5	26			
IPH-5*-64-*-21 (11)	218.5	99.5	28			

Note: IPH-5A (B)-\*-L-21 (11) (foot mounting/flange mounting, counterclockwise rotation) are the mirror image of the drawings shown above. In the case the suction port flange is facing upwards, the discharge port flange is positioned to the right when viewed from the shaft side.

#### IPH-6A-\*-21 (Foot Mounting, Clockwise Rotation)



IPH-6B-\*-11 (Flange Mounting, Clockwise Rotation) SAE D Mount





Model No.	Dim	ensions (r	nm)
Widdel No.	LA	LB	φD
IPH-6*- 80-*-21 (11)	241.5	111.5	32
IPH-6*-100-*-21 (11)	251.5	116.5	36
IPH-6*-125-*-21 (11)	263.5	122.5	38

Note: IPH-6A (B)-\*-L-21 (11) (foot mounting/flange mounting, counterclockwise rotation) are the mirror image of the drawings shown above. In the case the suction port flange is facing upwards, the discharge port flange is positioned to the right when viewed from the shaft side.

## **Performance Curves**


Revolution Speed 1200 rpm Operating Hydraulic Fluid Viscosity 46 centistokes Representative Characteristics Under Above Conditions






## **Cross-sectional Drawing**


IPH-\*B-\*-\*\*






Note: Drawings shown above are the IPH-5 and IPH-6.

The lower left cross-sectional drawing is the IPH-4, the radial seal #18 was removed and a wave washer was added. The lower right cross-sectional drawing is the IPH-2 and IPH-3, the bushing #8 was removed, the spring pin #11 was replaced with a guide pin, and the radial seal #18 was removed and a wave washer #32 was added.





Part No.	Part Name
1	Body -1
2	Body -2
3	Mounting
4	Rear cover
5	Pinion shaft
6	Radial piston
7	Internal gear
8	Bushing
9	Knock pin
10	Stopper pin
11	Spring pin (guide pin)
12	Axial plate -1
13	Axial plate -2
14	Feeler piece
15	Spring holder
16	Spring
17	Key
18	Radial seal
19	Radial backup ring
20	Axial backup ring
21	Backup ring
22	Bearing
23	Oil seal
24	Pin
25	O-ring
26	O-ring
27	O-ring
28	O-ring
29	Snap ring
30	Screw
31	Washer
32	Wave washer
ee nage	e C2 for Parts/Kit Numbers

\*Note: See page C2 for Parts/Kit Numbers

## **IPH Series Seal Kit**

Understanding Seal Kit Model Numbers :

IHAS - 2 S \* \*\*\* - 10 (20, 30) - Design Number (IPH3: 20D, IPH4: 30D) - Capacity Classification D35 to 125 - Size 2, 3, 4, 5, 6 S: Shaft Side Single Pump or Double Pump H: Head Side Double Pump Indoor/Outdoor Use Sealing - IPH Series Seal Kit

		Component Part Numbers							
Seal Kit Number	Applicable Pump Model No.	18	Q'ty	19	Q'ty	20	Q'ty	21	Q'ty
	T amp meder no	Radial Seal	Qty	Radial Backup Ring	Qty	Axial Backup Ring	Qty	Backup ring	Qty
IHAS-2S2D35-10	IPH-2A(B)-3.5-11			IH34J-102D35-1A	2	IH34J-202000	2	IH34J-402D35	1
2\$2005-10	5			102005-1A	2	"	2	402005	1
2S2D65-10	6.5			102D65-1A	2	"	2	402D65	1
2\$2008-10	8			102008-1A	2	"	2	402008	1
IHAS-2S3010-20	IPH-3A(B)-10-20			IH34J-103010-1A	2	IH34J-203000	2	IH34J-403010	1
2\$3013-20	13			103013-1A	2	"	2	403013	1
2\$3016-20	16			103016-1A	2	"	2	403016	1
IHAS-2S4020-30	IPH-4A(B)-20-20			IH34J-104020-2A	2	IH34J-204000-1A	2	IH34J-404020	1
2\$4025-30	25			104025-2A	2	"	2	404025	1
2\$4032-30	32			104032-2A	2	"	2	404032	1
IHAS-2S5040-10	IPH-5A(B)-40-21(11)	IH33J-105040-1A	2	IH34J-105040-1A	2	IH34J-205000	2	IH34J-405040	1
2\$5050-10	50	105050-1A	2	105050-1A	2	"	2	405050	1
2\$5064-10	64	105064-1A	2	105064-1A	2	"	2	405064	1
IHAS-2S6080-10	IPH-6A(B)-80-21(11)	IH33J-106080-1A	2	IH34J-106080-1A	2	IH34J-206000	2	IH34J-406080	1
2\$6100-10	100	106100-1A	2	106100-1A	2	"	2	406100	1
2\$6125-10	125	106125-1A	2	106125-1A	2	"	2	406125	1

					Component Part Numb	ers				
Seal Kit Number	23	Q'ty	25	Q'ty	26	04,	27	Q'ty	28	Q'ty
	Oil seal	] Q ty	O-ring	Qıy	O-ring	Q'ty	O-ring	Qty	O-ring	- Q ty
IHAS-2S2D35-10	ISD-20328	1	R68 × 2	3	R23 × 2	2	R10 × 2	1	R10 × 2	2
2\$2005-10	"	1	"	3	"	2	R12 × 2	1	R12 × 2	2
2S2D65-10	"	1	"	3	"	2	R14 × 2	1	R14 × 2	2
2\$2008-10	"	1	"	3	"	2	R16 × 2	1	R16 × 2	2
IHAS-2S3010-20	ISD-25388	1	R86 × 2	3	R30 × 2	2	R15 × 2.5	1	R15 × 2.5	2
2\$3013-20	"	1	"	3	"	2	R18 × 2.5	1	R18 × 2.5	2
2\$3016-20	"	1	"	3	"	2	R20 × 2.5	1	R20 × 2.5	2
IHAS-2S4020-30	ISD-32458	1	R108 × 3	3	R38 × 2.5	2	R21 × 2.5	1	R21 × 2.5	2
2\$4025-30	"	1	"	3	"	2	R23 × 3	1	R23 × 3	2
2\$4032-30	"	1	"	3	"	2	R26 × 3	1	R26 × 3	2
IHAS-2S5040-10	ISD-40558	1	R140 × 3	3	R49 × 3	2	R26 × 3	1		
2\$5050-10	"	1	"	3	"	2	R29 × 3.5	1		
2\$5064-10	"	1	"	3	"	2	R33 × 3.5	1		
IHAS-2S6080-10	ISD-50659	1	R172 × 4	3	R60 × 3.5	2	R34 × 3.5	1		
2\$6100-10	"	1	"	3	"	2	R38 × 4	1		
2\$6125-10	"	1	"	3	"	2	R43 × 4	1		


Note: 1. Oil seals are manufactured by Nippon Oil Seal Industry Co. Ltd. (NOK).
2. O-rings are not available through retail sources. Consult your agent for more information.

## **IPH Series Pipe Flange Kit**

#### **Understanding Flange Kit Model Numbers:**

The pipe flange kit combines the flanges, bolts, washers, and O-rings required for each type of pump into a single kit.

The component parts table shows the screw in type flange kit. In the case of the welded type flange, the flange part number is IH03J-200040 (1 of IH03J-100040 changes to 2). All other included parts are the same.



Screw in type	Applicable Pump	Code 61			I	IN Fla	ange			
Flange Kit model No.	Model No.	Size	Flange Part No	).	Bolt		Washer		0-ring	
IHF-2-T-20	IPH-2A(B)-*-11	1/2"	IH03J-100040	1	TH- 8 × 45	4	WS-B- 8	4	IB-P22	1
IHF-3-T-20	IPH-3A(B)-*-20	1"	IH03J-100080	1	TH-10 × 50	4	WS-B-10	4	IB-G35	1
IHF-4-T-20	IPH-4A(B)-*-20	1 1/4"	IH03J-100100	1	TH-10 × 55	4	11	4	IB-G40	1
IHF-5-T-20	IPH-5A(B)-*-21(11)	1 1/2"	IH03J-100120	1	TH-12 × 55	4	WS-B-12	4	IB-G50	1
IHF-6-T-20	IPH-6A(B)-*-21(11)	2"	IH03J-100160	1	TH-12 × 60	4	n	4	IB-G60	1

Code 61			Ol	JT F	lange				Plug	
Size	Flange Part No.		Bolt		Washer		O-ring		riug	
1/2"	IH03J-100040	1	1 TH- 8 × 45 4 WS-B- 8				IB-P22	1	TPHA-1/4	2
1/2"	IH03J-100040	1	1 TH- 8 × 45		"	4	IB-P22	1	"	2
3/4"	IH03J-100060	1	TH-10 × 50	4	WS-B-10	4	IB-G30	1	"	1
1"	IH03J-100080	1	. TH-10 × 50		"	" 4		1	"	2
1 1/2"	IH03J-100120	1 TH-12 × 60		4	WS-B-12	4	IB-G50	1	"	1

Note: 1. In the case of a double pump, the flange kit includes three flanges: one for the common IN port and two OUT port flanges. When using separate IN ports, use separate single pump flange kits, one each for the head side and the shaft side.


Note: 2. There is no common IN port in the case of the double pump models IPH-55, IPH-56, and IPH-66, or a single IN port is used.

Screw in type	Applicable Pump Model				IN Fla	ange			
Flange Kit model No.	No.	Flange Part No.		Bolt		Washer		0-ring	
IHF-22-T-20	IPH- 22B-*-*-11	IH03J-100060	1	TH-10 × 50	4	WS-B-10	4	IB-G30	1
IHF-23-T-20	23	IH03J-100080	1	"	4	"	4	IB-G35	1
IHF-24-T-20	24	IH03J-100120	1	TH-12 × 55	4	WS-B-12	4	IB-G50	1
IHF-25-T-20	25	IH03J-100160	1	TH-12 × 60	4	"	4	IB-G60	1
IHF-26-T-20	26	IH03J-100200	1	TH-12 × 65	4	"	4	IB-G75	1
IHF-33-T-20	IPH- 33B-*-*-11	IH03J-100100	1	TH-10 × 55	4	WS-B-10	4	IB-G40	1
IHF-34-T-20	34	IH03J-100120	1	TH-12 × 55	4	WS-B-12	4	IB-G50	1
IHF-35-T-20	35	IH03J-100160	1	TH-12 × 60	4	"	4	IB-G60	1
IHF-36-T-20	36	IH03J-100200	1	TH-12 × 60	4	"	4	IB-G75	1
IHF-44-T-20	IPH- 44B-*-*-11	IH03J-100120	1	TH-12 × 55	4	"	4	IB-G50	1
IHF-45-T-20	45	IH03J-100200	1	TH-12 × 65	4	"	4	IB-G75	1
IHF-46-T-20	46	IH03J-100240	1	TH-16 × 75	4	WS-B-16	4	IB-G85	1

<sup>\*</sup>IFH Numbers include both Inlet and Outlet Flange Kits

		OUT Flange	(Sh	aft Side)						OUT Flange	(Не	ad Side)				Plug	
Flange Part No.		Bolt		Washer		0-ring		Flange Part No.		Bolt		Washer		0-ring		Flug	
IH03J-100040	1	TH- 8 × 45	4	WS-B- 8	4	IB-P22	1	IH03J-100040	1	TH- 8 × 45	4	WS-B- 8	4	IB-P22	1	TPHA-1/4	3
IH03J-100040	1	"	4	"	4	IB-P22	1	"	1	"	4	"	4	"	1	"	3
IH03J-100060	1	TH-10 × 50	4	WS-B-10	4	IB-G30	1	"	1	"	4	"	4	"	1	"	3
IH03J-100080	1	"	4	"	4	IB-G35	1	"	1	"	4	"	4	"	1	"	2
IH03J-100120	1	TH-12 × 60	4	WS-B-12	4	IB-G50	1	"	1	"	4	"	4	"	1	"	2
IH03J-100040	1	TH- 8 × 45	4	WS-B- 8	4	IB-P22	1	IH03J-100040	1	TH- 8 × 45	4	WS-B- 8	4	IB-P22	1	"	2
IH03J-100060	1	TH-10 × 50	4	WS-B-10	4	IB-G30	1	"	1	"	4	"	4	"	1	"	3
IH03J-100080	1	"	4	"	4	IB-G35	1	"	1	"	4	"	4	"	1	"	2
IH03J-100120	1	TH-12 × 60	4	WS-B-12	4	IB-G50	1	"	1	"	4	"	4	"	1	"	2
IH03J-100060	1	TH-10 × 50	4	WS-B-10	4	IB-G30	1	IH03J-100060	1	TH-10 × 50	4	WS-B-10	4	IB-G30	1	"	3
IH03J-100080	1	"	4	"	4	IB-G35	1	"	1	"	4	"	4	"	1	"	2
IH03J-100120	1	TH-12 × 60	4	WS-B-12	4	IB-G50	1	"	1	"	4	"	4	"	1	"	2

#### Pipe Flange Installation Dimension Diagram



#### Screw in type

	Pipe Flange Kit	SAE Standard	Nominal			Dime	ensions (r	nm)			Weight
	Part Number	Code 61	Diameter	Α	В	С	D	Т	φ d <sub>1</sub>	φd4	Ibs
	IH03J -100040	SAE J518b <sup>1</sup> / <sub>2</sub>	1/2	54	46	38.1	17.5	33	9	12.7	.88
	-100060	SAE J518b <sup>3</sup> / <sub>4</sub>	3/4	65	52	47.5	22.0	33	11	20	1.3
	-100080	SAE J518b 1	1	70	59	52.4	26.2	33	11	27	1.3
☆	-100100	SAE J518b 1 <sup>1</sup> / <sub>4</sub>	1 <sup>1</sup> /4	79	73	58.7	30.2	38	11	33	2.2
	-100120	SAE J518b 1 <sup>1</sup> / <sub>2</sub>	1 <sup>1</sup> / <sub>2</sub>	94	83	70.0	36.0	38	13	37.5	3.0
☆	-100160	SAE J518b 2	2	102	97	77.8	42.9	38	13	50	3.7
☆	-100200	SAE J518b 2 <sup>1</sup> / <sub>2</sub>	<b>2</b> <sup>1</sup> / <sub>2</sub>	114	109	88.9	50.8	43	13	60	4.6
☆	-100240	SAE J518b 3	3	135	131	106.4	61.9	48	17.5	71	7.2

#### Welded Type

	Pipe Flange Kit	SAE Standard	Pipe					Dimensio	ns (mm)					Weight
	Part Number	Code 61	Diameter	Α	В	С	D	Т	е	<i>φ</i> d <sub>1</sub>	<b>φ</b> d₂	φd₃	<i>φ</i> d₄	Ibs
	IH03J -200040	SAE J518b ½	1/2	54	46	38.1	17.5	33	11	9	22.2	27	12.7	.88
	-200060	SAE J518b <sup>3</sup> / <sub>4</sub>	3/4	65	52	47.5	22.0	33	12	11	27.7	35	20	1.3
	-200080	SAE J518b 1	1	70	59	52.4	26.2	33	14	11	34.5	42	27	1.3
☆	-200100	SAE J518b 1 <sup>1</sup> / <sub>4</sub>	1 <sup>1</sup> /4	79	73	58.7	30.2	38	16	11	43.2	48	33	2.2
	-200120	SAE J518b 1 <sup>1</sup> / <sub>2</sub>	1 <sup>1</sup> /2	94	83	70.0	36.0	38	18	13	49.1	58	37.5	3.0
☆	-200160	SAE J518b 2	2	102	97	77.8	42.9	38	19	13	61.1	68	50	3.7
☆	-200200	SAE J518b 2 <sup>1</sup> / <sub>2</sub>	2 <sup>1</sup> /2	114	109	88.9	50.8	43	22	13	77.1	82	60	4.6
☆	-200240	SAE J518b 3	3	135	131	106.4	61.9	48	25	17.5	90.0	97	71	7.2

## **Recommended Tightening Torque for Flange Installation Bolts**

#### For aluminum body

#### For cast body (shared IN port)

Mounting bolt	Tightening Torque ft/lbs
M8	14 to 17
M10	36 to 43
M12	65 to 83

Mounting bolt	Tightening Torque ft/lbs
M10	36 to 47
M12	64 to 82
M16	158 to 202


Note: There is no BSPT (previously PT) 1/4 tap for the above flange numbers (exclusively for suction port use) marked with a star ( ☆).


## **IPH Series Pipe Flange Kit**


# Understanding Foot Mounting Kit Numbers:

When only the mounting feet are required for a single pump or double pump, pump mounting bolts, washers and other parts are sold together as the Foot Mounting Kit.

# Foot Mounting Installation Measurement Chart SAE-2BOLT-MOUNTING







#### SAE-2BOLT-MOUNTING

Foot Mounting	Appl	icable Pump Model No.		Access	sories		Dimensions (mm)						
Kit Model No.	SINGLE PUMP	DOUBLE PUMP	Bolt	Q'ty	Washer	Q'ty	А	В	С	Е	F	Н	
IHM-2-10	IPH-2	-	TB-10 × 30	2	WP-10	2	127	152.5	69.8	1	50.8	96	
IHM-4-10	IPH-3	-	TB-12 × 30	2	WG-12	2	220.7	246	107.95	1	114.3	140	
IHM-4-10	IPH-4	-	TB-12 × 30	2	WG-12	2	220.7	246	107.95	1	114.3	140	
IHM-22-10		IPH-22	TB-10 × 30	2	WP-10	2	171.45	204	107.95	1	95.25	150	
IHM-44-10		IPH23, IPH-33	TB-12 × 30	2	WG-12	2	235	267	139.7	1	127	193	
IHM-44-10		IPH-24, IPH-34, IPH-44	TB-12 × 30	2	WG-12	2	235	267	139.7	1	127	193	
IHM-45-10	IPH-5	IPH-25, IPH-35, IPH-45	TB-16 × 40	2	WP-16	2	295.3	334	152.4	1	139.7	203	
IHM-46-10	IPH-6	IPH-26, IPH-36, IPH-46	TB-20 × 50	2	WP-20	2	330.2	374	203.2	1	149.2	220.7	

Foot Mounting	Dimensions (mm)													
Kit Model No.	- 1	(J)	K	N	Р	Q	(S)	T	φD	<b>φ</b> d₁	φd₂	φd₃	φd₄	Ibs
IHM-2-10	74	41.5	17.5	13	M10	135	32.5	36.5	82.55	22	11	106.4	50	4.4
IHM-4-10	61.7	49	16	16	M12	195.5	12.7	53	101.6	22	11	146	40	12.1
IHM-4-10	74.7	62	16	16	M12	195.5	12.7	53	101.6	22	11	146	40	12.1
IHM-22-10	73.5	41	18	18	M10	180	32.5	50	82.55	22	11	106.4	40	14.3
IHM-44-10	89.5	45	20	20	M12	232	44.5	57.5	101.6	22	14	146	40	26.4
IHM-44-10	102.5	58	20	20	M12	232	44.5	57.5	101.6	22	14	146	40	26.4
IHM-45-10	104.5	60	25	25	M16	259	44.5	61	127	35	18	181	86	29.7
IHM-46-10	119.5	70	30	30	M20	337	49.5	64	152.4	37	20	228.6	100	48.5

<sup>\*</sup>IHM-2-10, IHM-4-10, and IHM-45-10 are the same as PVS pump foot mounting PSM-101000, PSM102000, and PSM103000 respectively.

#### SAE-4BOLT-MOUNTING

Foot Mounting	Applicable Pump Model No.		Access	sories					Dimensio	ons (mm)			
Kit Model No.	DOUBLE PUMP	Bolt	Bolt Q'ty Washer Q'ty				В	С	Е	F	G	Н	1
IHM-55-10	IPH-55	TH-20 × 50	4	WS-B-20	4	330	370	200	1	125	125	300	17
IHM-66-10	IPH56, IPH-66	TH-24 × 60	4	WS-B-24	4	380	430	260	1	140	140	340	17

Foot Mounting							Dimensio	ns (mm)							Weight
Kit Model No.	(J)	K	L	М	N	Р	Q	R	(S)	T	φD	φ d <sub>1</sub>	$\varphi d_2$	φ d <sub>4</sub>	lbs
IHM-55-10	47	30	224.6	224.6	30	M20	340	275	20	90	165.1	34	18	140	70.5
IHM-66-10	52	40	247.5	247.5	40	M24	415	310	25	105	177.8	34	18	150	105.8

## **Air Bleed-off Valve**

Equipping an air bleed-off valve on the pump's discharge side helps to simplify air bleeding during test operation.

## **Specifications**


Air inside the pump and the suction pipe is exhausted rapidly when the pump is started up.

When discharge pressure reaches 29 psi or greater after the pump intakes oil, a valve closes to prevent oil from leaking.


Maximum operating pressure: 4350 psi.

Provide piping to ensure that the tank port is under the oil level surface.

# JIS symbol



## **Understanding Model Numbers**



Part No.	Part Name	Q'ty
1	Valve body	1
2	Snap ring	1
3	Valve	1
4	Spring	1


Note: 1) If chattering occurs in a circuit when CAB-T02-1-11 is used, use CAB-T02-A-11 instead.

2) If chattering occurs in a circuit when CAB-T02-A-11 is used, use of a CAB air bleed-off valve is not required.


## **Application Examples**

Example of Circuits that Require an Air Bleed-off Valve:

- 1) When using a Type 2 or Type 3 check valve (Sample Circuit A)
- 2) When unload circuit function cannot be achieved (Sample Circuit A)
- 3) When the discharge sides of multiple pumps run together (Sample Circuit B)



Circuit Diagram A



Circuit Diagram B

# NACHİ

## **IPH Series Double IP Pump**

.21 to 7.68 in<sup>3</sup>/rev 4350 psi





All the types in this new design (11D) series are installation compatible with the previous design (10D). Note, however, that there is no longer compatibility for some of the seal components between the IPH-3 and IPH-4 sizes and the 3 and 4 sizes.

#### **Features**

Configured with the high-pressure, low-noise IPH Series and IP pumps, these double pumps greatly expand

the range of application for the IP pump.

A wide selection of pump combinations

provides options that are perfect for just about any type of application imaginable.

## **Specifications**

	Discharge Rate (12	200min <sup>-1</sup> No-load)	Revolutio	n Speed	Operating Pressure	Required Power at
Model No.	Vent Side	Shaft Side	Min.	Max.	MPa (psi)	1200min <sup>1</sup> , 3045 psi
	gpm	gpm	min -1	min -1	a (po.)	hp
IPH-22B-*-*-(*)-11		4.3 to 9.8				10.7
IPH-23B		12.2 to 18.9				15.5
IPH-24B	1.1 to 2.5	24.8 to 38.7				26.1
IPH-25B		48.9 to 76.6				46.2
IPH-26B		97.5 to 151.0	600			85.8
IPH-33B		12.2 to 18.9	Rated: 21	20.5		
IPH-34B	3.2 to 4.9	24.8 to 38.7			(3045) Max: 30	30.9
IPH-35B	3.2 (0 4.9	48.9 to 76.6		2000		51.0
IPH-36B		97.5 to 151.0			(4350)	90.7
IPH-44B		24.8 to 38.7			(4330)	41.5
IPH-45B	6.5 to 10.2	48.9 to 76.6	500			61.6
IPH-46B		97.5 to 151.0				101.3
IPH-55B	12.9 to 20.2	48.9 to 76.6	400			81.8
IPH-56B	12.9 (0 20.2	97.5 to 151.0	400			121.4
IPH-66B	25.7 to 39.8	97.5 to 151.0	300			159.9

#### Note:

1.Maximum Pressure: Maximum pressure limit when there are frequent pressure changes. However, maximum pressure is the same as rated pressure when load is applied to the head side and shaft side simultaneously.

2.Suction Pressure: 4.3 psi

3.Avoid installation with the suction port towards the bottom of the pump. If the revolution speed will exceed 1800mm-1, provide separate piping for shaft side and head size IN ports.

4. Specify using the model number format shown below when pipe flange is required.

5. Working pressure is continuous operating pressure when the same pressure exists on the head side and shaft side.


on the head side and shaft side is the same as that of the single pumps. Required power is the sum of the power required by each of the two pumps. 7.The "Required Power at 1200min-1, 3045 psi (hp)" column in the above table are based on combinations that provide the maximum capacity for each model number, when pressure at both the head side and shaft side is 3045 psi. Examples

combinations that provide "the maximum capacity for each model number" are IPH-22B-8-8-11 for IPH-22b, and IPH-46B-32- 125-11 for IPH-46B.

Handling

1 Handling is in accordance with procedures for the IPH pump. See page C-1 for more information.

## **Understanding Model Numbers**



• IPH Series Double IP Pump Foot Mounting Kit See the IPH Series (single) IP pump section in page C-12. • IPH Series Double IP Pump Pipe Flange See the IPH Series (single) IP pump section in page C-10.

None: Clockwise (viewed from shaft end)

• L : Counterclockwise (viewed from shaft end)

• T : Includes Screw IN Flange Kit (for shared IN port)

• TT : Includes Screw IN Flange Kit (for individual IN port)


• E : Includes Welded Flange Kit (for shared IN port)


• EE : Includes Welded Flange Kit (for individual IN port)

Auxiliary symbol must be provided in alphabetic order.


## **Installation Dimension Drawings**

IPH-22B-\*-\*-11 (Flange Mounting, Clockwise Rotation)







IPH-23B-\*-\*-11 (Flange Mounting, Clockwise Rotation)



Auxiliary View A




Note: IPH-22B (23B)-\*-\*-L-11 (foot mounting/flange mounting, counterclockwise rotation) are the mirror image of the drawings shown above. In the case the individual port is facing upwards, the discharge port flange is positioned to the right when viewed from the shaft side.





Specifications									
Volume in <sup>3</sup>		Weight	Dimensions (mm)						
Vent Side	Shaft Side	lbs	LA	LB	LC	LD			
	.21	12.7	211.5	160	105.5	51			
.21	.31	13.0	216.5	165	110.5	53.5			
	.39	13.2	220.5	169	114.5	55			
	.49	13.6	225.5	174	119.5	58			
	.31	13.2	221.5	167.5	110.5	53.5			
.31	.39	13.4	225.5	171.5	114.5	55			
	.49	13.8	230.5	176.5	119.5	58			
20	.39	13.6	229.5	173.5	114.5	55			
.59	.49	14.1	234.5	178.5	119.5	58			
.49	.49	14.5	239.5	181	119.5	58			
	.21 .31 .39	Vent Side         Shaft Side           .21         .31           .39         .49           .31         .39           .49         .39           .49         .39           .49         .49	Vent Side         Shaft Side         lbs           .21         12.7           .31         13.0           .39         13.2           .49         13.6           .31         13.2           .39         13.4           .49         13.8           .39         13.6           .49         14.1	Vent Side         Shaft Side         lbs         LA           .21         12.7         211.5           .31         13.0         216.5           .39         13.2         220.5           .49         13.6         225.5           .31         13.2         221.5           .39         13.4         225.5           .49         13.8         230.5           .39         13.6         229.5           .49         14.1         234.5	Vent Side         Shaft Side         Ibs         LA         LB           .21         12.7         211.5         160           .31         13.0         216.5         165           .39         13.2         220.5         169           .49         13.6         225.5         174           .31         13.2         221.5         167.5           .39         13.4         225.5         171.5           .49         13.8         230.5         176.5           .39         13.6         229.5         173.5           .49         14.1         234.5         178.5	Vent Side         Shaft Side         Ibs         LA         LB         LC           .21         12.7         211.5         160         105.5           .31         13.0         216.5         165         110.5           .39         13.2         220.5         169         114.5           .49         13.6         225.5         174         119.5           .31         13.2         221.5         167.5         110.5           .39         13.4         225.5         171.5         114.5           .49         13.8         230.5         176.5         119.5           .39         13.6         229.5         173.5         114.5           .49         14.1         234.5         178.5         119.5			

Note: Dimensions shown in this diagram are for a single pump.



Specifications	'	'						
Model No.	Volun	ne in³	Weight	Dimensions (mm)				
Woder No.	Vent Side	Shaft Side	Ibs	LA	LB	LC	LD	
IPH-23B-3.5 -10-11		.62	18.0	230.5	179	126	60	
-13	.21	.81	18.5	236.5	185	132	63	
-16		.96	19.1	241.5	190	137	65.5	
IPH-23B-5 -10-11	.31	.62	18.3	235.5	181.5	126	60	
-13		.81	18.7	241.5	187.5	132	63	
-16		.96	19.4	246.5	192.5	137	65.5	
IPH-23B-6.5 -10-11		.62	18.5	239.5	183.5	126	60	
-13	.39	.81	18.9	245.5	189.5	132	63	
-16		.96	19.6	250.5	194.5	137	65.5	
IPH-23B-8 -10-11		.62	18.9	244.5	186	126	60	
-13	.49	.81	19.4	250.5	192	132	63	
-16		.96	20.0	255.5	197	137	65.5	





Note: Dimensions shown in this diagram are for a single pump.





image of the drawings shown above. In the case the individual IN port is facing upwards, the discharge


port flange is positioned to the right when viewed from the shaft side.

58.7

4-M10x15

# IPH-34B-\*-\*-11 (Flange Mounting, Clockwise Rotation)







#### Specifications

Model No.	Volun	ne in³	Weight	Dimensions (mm)			
Widdel No.	Vent Side	Shaft Side	lbs	LA	LB	LC	LD
IPH-34B-10 -20-11		1.26	32.8	272	209	153	71
-25	.62	1.56	33.9	278	215	159	74
-32		1.97	35.0	286	223	167	78
IPH-34B-13 -20-11		1.26	33.2	278	212	153	71
-25	.81	1.56	34.3	284	218	159	74
-32		1.97	35.5	292	226	167	78
IPH-34B-16 -20-11		1.26	33.9	283	214.5	153	71
-25	.96	1.56	35.0	289	220.5	159	74
-32		1.97	36.1	297	228.5	167	78


Note: Dimensions shown in this diagram are for a single pump.

# IPH-35B-\*-\*-11 (Flange Mounting, Clockwise Rotation)






Note: IPH-34B (35B).\*-\*-L-11 (foot mounting/flange mounting, counterclockwise rotation) are the mirror image of the drawings shown above. In the case the individual IN port is facing upwards, the discharge port flange is positioned to the right when viewed from the shaft side.





#### Specifications

Model No.	Volun	ne in³	Weight	Dimensions (mm)			
Wodel No.	Vent Side	Shaft Side	lbs	LA	LB	LC	LD
IPH-35B-10 -40-11		2.48	58.2	323.5	257	197	91
-50	.62	3.06	60.4	330.5	264	204	94.5
-64		3.89	62.6	340.5	274	214	99.5
IPH-35B-13 -40-11		2.48	58.6	329.5	260	197	91
-50	.81	3.06	60.8	336.5	267	204	94.5
-64		3.89	63.0	346.5	277	214	99.5
IPH-35B-16 -40-11		2.48	59.3	334.5	262.5	197	91
-50	.96	3.06	61.5	341.5	269.5	204	94.5
-64		3.89	62.7	351.5	279.5	214	99.5

IPH-36B-\*-\*-11 (Flange Mounting, Clockwise Rotation)









#### Specifications

Model No.	Volun	Volume in <sup>3</sup>		Dimensions (mm)			
Woder No.	Vent Side	Shaft Side	lbs	LA	LB	LC	LD
IPH-36B-10 - 80-11		4.96	105	370.5	304	240	111.5
-100	.62	6.19	110	380.5	314	250	116.5
-125		7.68	114	392.5	326	262	122.5
IPH-36B-13 - 80-11		4.96	106	376.5	307	240	111.5
-100	.81	6.19	110	386.5	317	250	116.5
-125		7.68	115	398.5	329	262	122.5
IPH-36B-16 - 80-11		4.96	106	381.5	309.5	240	111.5
-100	.96	6.19	111	391.5	319.5	250	116.5
-125		7.68	115	403.5	331.5	262	122.5

Note) Dimensions shown in this diagram are for a single pump.

IPH-44B-\*-\*-11 (Flange Mounting, Clockwise Rotation)







#### Specifications

Model No.	Volume in <sup>3</sup>		Weight	Dimensions (mm)				
Woder No.	Vent Side	Shaft Side	lbs	LA	LB	LC	LD	
IPH-44B-20 -20-11		1.26	42.9	307	219	145	71	
-25	1.26	1.56	44.1	313	225	151	74	
-32		1.97	45.2	321	233	159	78	
IPH-44B-25 -25-11	1.56	1.56	45.2	319	228	151	74	
-32	1.50	1.97	46.3	327	236	159	78	
IPH-44B-32 -32-11	1.97	1.97	47.4	335	240	159	78	

Note: IPH-36B (44B)-\*-\*-L-11 (foot mounting/flange mounting, counterclockwise rotation) are the mirror image of the drawings shown above. In the case the individual IN port is facing upwards, the discharge port flange is positioned to the right when viewed from the shaft side.

IPH-45B-\*-\*-11 (Flange Mounting, Clockwise Rotation)







Specifications


Model No.	Volun	ne in³	Weight	Dimensions (mm)			
Widdel No.	Vent Side	Shaft Side	lbs	LA	LB	LC   203   210   220   203   210   220   203   210   220   203   210	LD
IPH-45B-20 -40-11		2.48	66.3	357	276	203	91
-50	1.26	3.06	68.5	364	283	210	94.5
-64		3.89	70.7	374	293	220	99.5
IPH-45B-25 -40-11		2.48	67.4	363	279	203	91
-50	1.56	3.06	69.6	370	286	210	94.5
-64		3.89	71.3	380	296	220	99.5
IPH-45B-32 -40-11		2.48	68.5	371	283	203	91
-50	1.97	3.06	70.7	378	290	210	94.5
-64		3.89	72.9	388	300	220	99.5

Note: Dimensions shown in this diagram are for a single pump.

IPH-46B-\*-\*-11 (Flange Mounting, Clockwise Rotation)








#### Specifications


Model No.	Volume in <sup>3</sup>		Weight	Dimensions (mm)			
Woder No.	Vent Side	Shaft Side	lbs	LA	LB	LC	LD
IPH-46B-20 - 80-11		4.96	115	404	323	250	111.5
-100	1.26	6.19	119	414	333	260	116.5
-125		7.68	124	426	345	272	122.5
IPH-46B-25 - 80-11		4.96	116	410	326	250	111.5
-100	1.56	6.19	120	420	336	260	116.5
-125		7.68	125	432	348	272	122.5
IPH-46B-32 - 80-11		4.96	117	418	330	250	111.5
-100	1.97	6.19	121	428	340	260	116.5
-125		7.68	126	440	352	272	122.5

Note: Dimensions shown in this diagram are for a single pump.

Note: IPH-45B (46B)-\*-\*-L-11 (foot mounting/flange mounting, counterclockwise rotation) are the mirror image of the drawings shown above. In the case the individual IN port is facing upwards, the discharge port flange is positioned to the right when viewed from the shaft side.

IPH-55B-\*-\*-11 (Flange Mounting, Clockwise Rotation)






Specifications

Model No.	Volume in <sup>3</sup>		Weight	Dimensions (mm)			
Woder No.	Vent Side	Shaft Side	lbs	LA	LB	LD	
IPH-55B-40 -40-11		2.48	100	385	286	99	
-50	2.48	3.06	102	392	293	102.5	
-64		3.89	105	402	303	107.5	
IPH-55B-50 -50-11	3.06	3.06	104	399	296.5	102.5	
-64	3.00	3.89	107	409	306.5	107.5	
IPH-55B-64 -64-11	3.89	3.89	109	419	311.5	107.5	


Note: Dimensions shown in this diagram are for a single pump.

IPH-56B-\*-\*-11 (Flange Mounting, Clockwise Rotation)




Note: Dimensions shown in this diagram are for a single pump.

Note: IPH-55B (56B)-\*-\*-L-11 (foot mounting/flange mounting, counterclockwise rotation) are the mirror image of the drawings shown above. In the case the individual IN port is facing upwards, the discharge port flange is positioned to the right when viewed from the shaft side.



Specifications

Model No.	Volum	Volume in <sup>3</sup>		Dimensions (mm)			
Woder No.	Vent Side	Shaft Side	lbs	LA	LB	LC	LD
IPH-56B-40 - 80-11		4.96	156	427	328	221	120.5
-100	2.48	6.19	160	437	338	231	125.5
-125		7.68	164	449	350	243	131.5
IPH-56B-50 - 80-11		4.96	158	434	331.5	221	120.5
-100	3.06	6.19	162	444	341.5	231	125.5
-125		7.68	167	456	353.5	243	131.5
IPH-56B-64 - 80-11		4.96	160	444	336.5	221	120.5
-100	3.89	6.19	164	454	346.5	231	125.5
-125		7.68	169	466	358.5	243	131.5



#### Specifications


Model No.	Volume in <sup>3</sup>		Weight	Dimensions (mm)			
	Vent Side	Shaft Side	lbs	LA	LB	LC	LD
IPH-66B- 80- 80-11	4.96	4.96	196	470	347.5	234	120.5
-100		6.19	201	480	357.5	244	125.5
-125		7.68	205	492	369.5	256	131.5
IPH-66B-100-100-11	6.19	4.96	205	490	362.5	244	125.5
-125		7.68	209	502	374.5	256	131.5
IPH-66B-125-125-11	7.68	7.68	214	514	380.5	256	131.5

Note: Dimensions shown in this diagram are for a single pump.

Note: IPH-66B-\*-L-11 (foot mounting/flange mounting, counterclockwise rotation) are the mirror image of the drawings shown above. In the case the suction port flange is facing upwards, the discharge port flange position is to the right when viewed from the shaft side.



**IPH Series Double IP Pump** 



Part No. Part Name

1 Pinion shaft -1
2 Pinion shaft -2
3 Body -3
4 Joint
5 Key

Note: In the case of a double pump, use single pump parts in addition to the 5 parts listed above.

• IPS Series Double IP Pump Seal Kit The double pump seal kit combines a shaft side nump seal kit with a

a shaft side pump seal kit with a head side pump seal kit. The shaft side pump seal kit (IHAS-2S\*\*\*\*-\*\*) is the same as the single pump seal

- kit. The head side pump seal kit (IHAS-2H\*\*\*\*-\*\*) includes the same component parts as the single pump seal kit, except that it does not have a #23 oil seal. See the IPH Series (single) IP pump section in page C-9 for more information.
- Air bleed-off valve See the IPH Series (single) IP pump section in page C-13.